



Diagnostic devices

Additions And Modifications In Software Version 68

Things to know – an overview

Functions according to manufacturer

This list merely gives a basic overview of the scope of our data additions. A complete list with all the model additions for every manufacturer would be simply too extensive.



Diagnostic devices

Extended and revised manufacturers

Alfa Romeo

Trouble codes	
Parameters	
Actuators	
Basic settings	<p>Resetting self-adaptation parameters ((147 (937), 937), (156 (932), 932 '98->), (166 (936), 936), (156 (932), 932 '02->), (GT (937), 937), (GTV (916), 916), (Spider (916), 916))</p> <p>Selespeed adaptation ((Mito (955), 955), (Giulietta (940), 940))</p> <p>Bleeding the clutch ((GT (937), 937))</p> <p>Resetting differential pressure sensor learning values ((Brera (939), 939))</p> <p>Resetting engine adaptation values of auxiliary aggregates/systems ((Mito (955), 955))</p> <p>Learning the steering-angle sensor ((Mito (955), 955), (Spider (939), 939))</p>
Codings	Registering the battery ((4C (960), 960))
Service resets	
DolP/CAN	
Capable for diagnostics only with mega macs X	
Cyber Security Management (CSM)	
Capable for diagnostics only with Cyber Security Management	

Audi

Trouble codes	(A1, GB), (A6, 4A), (A8, 4N), (S8, 4N)
Parameters	(A1, GB), (A6, 4A), (A8, 4N), (S8, 4N)
Actuators	(A1, GB), (A6, 4A)
Basic settings	Initializing electric seats ((A6, 4A))



Diagnostic devices

- Initializing the adaptive cruise control ((A1, GB), (A6, 4A))
- Adapting the radiator shutter ((A1, GB))
- Filling fuel lines of parking heater/auxiliary heater ((A1, GB))
- Bleeding the cooling system ((Q7, 4M), (A1, GB))
- Regenerating the soot particulate filter ((A1, GB))
- Resetting the diesel exhaust fluid level ((S5, 8T))
- Air conditioning ((Q4 e-tron, FZ))
- Adapting the normal position of ride-height levelling ((A6, 4F))
- Regenerating the soot particulate filter ((A3, 8P), (A4, 8H))
- Bleeding the fuel system ((A1, GB))
- Performing maintenance work on the refrigerant circuit ((Q7, 4M), (e-tron, GE), (e-tron GT, FW), (Q5, FY))
- Filling/bleeding the cooling system ((e-tron, GE), (e-tron GT, FW))
- Regenerating the soot particulate filter ((A4, 8K), (A6, 4G), (A3, 8V), (A5, 8T), (A5, 8F), (TT, FW), (A1, 8X), (A7, 4G), (Q3, 8U), (Q2, GA), (Q5, FY), (A1, GB), (Q3, F3))
- Burning off aux. heater/independent car heater ((A1, GB), (A6, 4A))
- Performing transmission adaptations ((Q3, 8U), (RS Q3, 8U), (TT, 8J), (RS3, 8P), (Q7, 4M), (A4, 8W), (S4, 8W), (A5, F5), (S5, F5), (Q5, FY), (RS5, F5), (RS4, 8W), (A8, 4N), (A6, 4A), (A7, 4K), (Q8, 4M), (S6, 4A), (S7, 4K), (RS6, 4A), (RS7, 4K), (S8, 4N), (A1, GB))
- Initializing the seat belt tensioner ECU ((A1, GB))
- Locking/unlocking the ride height leveling ((A6, 4A))
- Standardizing the liftgate ((A6, 4A))
- Adapt the intake manifold flap ((A6, 4F), (A4, 8E), (A4, 8H))
- Multitronic transmission adaptation drive cycle ((A7, 4G), (A6, 4G), (S7, 4G), (S6, 4G), (RS7, 4G), (RS6, 4G))
- Adapting the soot particulate filter ((A1, GB))
- Learning the steering-angle sensor ((A1, GB))
- Learning the throttle valve ((A1, GB))
- Learning the steering-angle sensor ((A6, 4F), (Q3, 8U), (TT, 8J), (RS Q3, 8U), (S6, 4F), (RS6, 4F), (Q7, 4M), (A4, 8W), (A5, F5), (S5, F5), (Q5, FY), (A8, 4N), (A6, 4A), (A7, 4K), (S6, 4A), (S7, 4K), (e-tron, GE), (e-tron GT, FW), (RS6, 4A), (RS7, 4K), (S8, 4N), (S4, 8W))
- Initializing the tilt/slide sunroof ((A1, GB))
- Reset learned values of injectors. ((A1, GB))
- De-energizing the 48 V system ((A6, 4A))
- Resetting the brake pad wear indicator ((Q4 e-tron, FZ))
- Initialising the boost pressure regulator ((A1, GB))
- Resetting gearbox learning values ((A4, 8E))
- Initializing the brake-pressure sensor ((Q4 e-tron, FZ))
- Performing basic settings of emergency call system/telematics system ((Q4 e-tron, FZ))
- Initializing the brake-pedal travel sensor ((Q4 e-tron, FZ))



Diagnostic devices

Performing the initial run-in of the air conditioning compressor ((A1, GB), (A6, 4A))
Resetting the refrigerant loss counter ((A6, 4A))
Retracting parking brake ((A6, 4A))
Special bleeding ((A1, GB))
Reducing fuel high pressure ((A1, GB))
Initializing the A/C flap actuators ((Q7, 4L), (A1, 8X), (S1, 8X), (A8, 4E), (A4, 8E), (A4, 8H), (S8, 4E), (A8, 4N), (A6, 4A), (A7, 4K), (S6, 4A), (S7, 4K), (e-tron, GE), (S3, 8Y), (RS6, 4A), (RS7, 4K), (S8, 4N), (A1, GB))
Initializing the alternator ((A1, GB))
Activating the retrofitted parking heater ((A1, GB))
Learning the turbocharger ((A4, 8E), (A4, 8K), (Q7, 4L), (Q5, 8R))
Initializing the ESC sensors ((Q4 e-tron, FZ), (A1, GB))
Adapting the cabin fragrance system ((A6, 4A))
Configuring the lane change assist ((A6, 4A))
Resetting the impact mode ((A1, GB), (A6, 4A))
Initializing the neutral position sensor ((A1, GB))
Calibrating the parking brake ((A6, 4A))
Adjusting the xenon headlight ((A4, 8K), (A5, 8F), (A5, 8T), (S5, 8T), (S4, 8K), (Q5, 8R), (RS5, 8T), (S5, 8F), (RS4, 8K), (RS5, 8F))
Adjusting the headlights ((A1, GB), (A6, 4A))
Adapting the radiator shutter 1 ((e-tron, GE), (e-tron GT, FW))
Adapting the radiator shutter 2 ((e-tron, GE), (e-tron GT, FW))
Calibrating the camera ECU ((Q4 e-tron, FZ), (A1, GB), (A6, 4A))
Adapting the fuel burning heater remote control ((A1, GB), (A6, 4A))
Filling/bleeding the pneumatic suspension system ((A6, 4A))
Putting the 48 V system back into operation ((A6, 4A))
Replacing emergency battery of emergency call system/telematics system ((A6, 4A))
Extending parking brake ((A6, 4A))
Unlocking aux. heater/independent car heater ((A1, GB), (A6, 4A))
Unlocking/locking the self-steering rear axle ((A6, 4A))
Calibrating the front edge radar ((A6, 4A))
Changing and checking DCT fluid ((A6, 4A))
Filling/topping up the rear axle differential ((A6, 4A))
Checking emergency battery of emergency call system/telematics system ((A6, 4A))

Codings

Adjust parking assistance volume ((A1, GB))
General ECU replacement ((A1, GB), (A6, 4A))
De/activating the trailer hitch ((A6, 4A))
Expert mode ECU coding ((A1, GB), (A6, 4A))



Diagnostic devices

Coding the rain/light sensor ((A1, GB), (A6, 4A))
Deactivating/activating the transport mode ((Q4 e-tron, FZ), (A1, GB), (A6, 4A))
Coding the trailer detection ((Q3, F3), (RS Q3, F3), (A6, 4A))
Coding the ABS ECU (Bosch) ((Q7, 4L))
Coding the language version of instrument cluster ((A1, GB))
Adapting the trailer hitch to advanced driver assistance systems ((A6, 4A))
Coding the gearbox ECU ((A4, 8E))
Registering the battery ((A1, GB), (A6, 4A))
Coding the gateway installation list ((S3, 8L), (A6, 4B), (R8, 42), (A6, 4F), (A1, GB))

Service resets (A1, GB), (A6, 4A), (Q4 e-tron, FZ)

DoIP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM) (S3, 8Y), (Q4 e-tron, FZ)

Capable for diagnostics only with Cyber Security Management

BMW

Trouble codes (2 Ser., U06), (3 Ser., G21), (5 Ser., G30), (5 Ser., G31), (7 Ser., G12), (X1, U11)

Parameters (2 Ser., U06), (3 Ser., G21), (5 Ser., G30), (7 Ser., G12), (X1, U11)

Actuators (2 Ser., U06), (3 Ser., G21), (4 Ser., F82), (5 Ser., G31), (X1, U11)

Basic settings Adapting the longitudinal acceleration sensor ((3 Ser., E91), (3 Ser., E92), (X5, E70), (1 Ser., E81), (1 Ser., E87), (2 Ser., F22), (3 Ser., E90), (3 Ser., E93), (5 Ser., E60), (5 Ser., E61), (1 Ser., E88))

Initializing the SCR system ((6 Ser., G32), (7 Ser., F02), (5 Ser., F10))

Resetting adaptation values of the EGR cooling system ((7 Ser., G12), (7 Ser., G11), (5 Ser., G30), (X3, G01), (X4, G02), (6 Ser., G32), (X5, G05))

Resetting differential pressure sensor learning values ((X2, F39), (3 Ser., G21))

Resetting the body control module ((Z4, E89), (X1, E84))

Reset equipment variant ((3 Ser., G21))

Resetting learned values of the induction system ((7 Ser., G11), (7 Ser., G12), (5 Ser., G31), (5 Ser., G30), (X3, G01), (6 Ser., G32), (X4, G02), (X5, G05), (3 Ser., G20), (X7, G07), (3 Ser., G21))

Initialize minimum quantity deviation of the injectors ((5 Ser., G31))

Resetting EGR valve learning values ((X1, F48), (2 Ser., F22), (2 Ser., F23), (X2, F39), (7 Ser., F02), (5 Ser., F10), (3 Ser., E92), (X5, E70), (5 Ser., F11))



Diagnostic devices

Adapting the active roll stabilizer ((X5, E70), (X6, E71), (6 Ser., E63), (6 Ser., E64), (X6, E72), (2 Ser., F22), (3 Ser., E92))

Resetting the mixture adjustment ((2 Ser., F45), (1 Ser., F20), (1 Ser., F21), (2 Ser., F46), (2 Ser., F22), (2 Ser., F23), (4 Ser., F33), (4 Ser., F32), (4 Ser., F36), (X1, F48), (3 Ser., F30), (3 Ser., F31), (7 Ser., G12), (3 Ser., F34), (7 Ser., G11), (5 Ser., G31), (5 Ser., G30), (X3, G01), (X2, F39), (6 Ser., G32), (X4, G02), (X5, G05), (X7, G07), (8 Ser., G16), (8 Ser., G14), (8 Ser., G15), (X3, F97), (X4, F98), (4 Ser., G82))

Initializing the brake-pressure sensor ((3 Ser., E91), (3 Ser., E92), (X5, E70), (Z4, E89), (1 Ser., E81), (1 Ser., E87), (2 Ser., F22), (3 Ser., E90), (3 Ser., E93), (5 Ser., E60), (5 Ser., E61), (1 Ser., E88))

Resetting learned values of the DEF injection system ((5 Ser., G31))

Adapting the A/C compressor ((i3, I01), (i8, I12))

Draining/filling the refrigerant circuit ((3 Ser., G21))

Calibrating the front camera ((i3, I01), (X1, F48), (7 Ser., G11), (7 Ser., G12), (1 Ser., F20), (1 Ser., F21), (3 Ser., F80), (2 Ser., F45), (6 Ser., F06), (5 Ser., G31), (5 Ser., G30), (2 Ser., F22), (2 Ser., F23), (X3, G01), (X2, F39), (6 Ser., G32), (7 Ser., F02), (5 Ser., F90), (5 Ser., F10), (X5, E70), (3 Ser., F31), (3 Ser., E92), (3 Ser., F30), (5 Ser., F11), (X4, G02), (8 Ser., G15), (X5, G05), (3 Ser., G20), (Z4, G29), (8 Ser., G14), (1 Ser., F40), (3 Ser., G21), (8 Ser., G16), (8 Ser., F91), (X6, G06), (8 Ser., F92), (8 Ser., F93), (X3, F97), (X4, F98), (3 Ser., G80), (4 Ser., G23), (4 Ser., G22), (2 Ser., U06), (4 Ser., G82), (X1, U11))

Resetting the start inhibitor of DEF injection system ((X6, G06), (4 Ser., G22), (4 Ser., G23), (4 Ser., G26))

De/activating the parking brake service mode ((3 Ser., G21), (2 Ser., U06), (X1, U11))

Resetting learned values of throttle valve actuator ((3 Ser., G21))

Learning the steering-angle sensor ((X3, F25), (5 Ser., F07), (5 Ser., F11), (5 Ser., F10), (7 Ser., F01), (7 Ser., F02), (6 Ser., F13), (6 Ser., F06), (1 Ser., F20), (1 Ser., F21), (3 Ser., F30), (6 Ser., F12), (7 Ser., F04), (7 Ser., F03), (3 Ser., F31), (3 Ser., F34), (2 Ser., F87), (i3, I01), (X4, F26), (4 Ser., F32), (4 Ser., F33), (4 Ser., F36), (3 Ser., F80), (2 Ser., F45), (2 Ser., F22), (4 Ser., F82), (4 Ser., F83), (2 Ser., F46), (2 Ser., F23), (X1, F48), (X2, F39), (2 Ser., F44))

Initializing the tilt/slide sunroof ((i3, I01), (X1, F48))

Filling/bleeding the SCR passive system ((4 Ser., G22), (4 Ser., G23), (4 Ser., G26))

Bleeding the electronic stability control ((X3, F25), (5 Ser., F07), (5 Ser., F11), (5 Ser., F10), (7 Ser., F01), (7 Ser., F02), (6 Ser., F13), (6 Ser., F06), (1 Ser., F20), (1 Ser., F21), (3 Ser., F30), (6 Ser., F12), (7 Ser., F04), (X5, F85), (3 Ser., F31), (3 Ser., F34), (i3, I01), (i8, I12), (X5, F15), (X4, F26), (4 Ser., F32), (4 Ser., F33), (4 Ser., F36), (3 Ser., F80), (2 Ser., F45), (2 Ser., F22), (4 Ser., F82), (2 Ser., F46), (2 Ser., F23), (X1, F48), (X6, F86), (X6, F16), (7 Ser., G11), (7 Ser., G12), (4 Ser., F83), (5 Ser., G31), (5 Ser., G30), (X3, G01), (X2, F39), (6 Ser., G32), (5 Ser., F90), (X4, G02), (8 Ser., G15), (8 Ser., G14), (i8, I15), (8 Ser., G16), (X3, F97), (X4, F98), (X5, F95), (2 Ser., F44), (4 Ser., G82))

Resetting transfer case adaptation values ((4 Ser., F82), (4 Ser., F83), (7 Ser., G11), (7 Ser., G12), (X7, G07), (X6, G06), (4 Ser., G22), (4 Ser., G23), (4 Ser., G26))

Activating the assembly position of the exhaust gas flap actuator ((7 Ser., G11), (5 Ser., G30), (X3, G01), (X4, G02), (6 Ser., G32), (3 Ser., G20), (3 Ser., G21), (X5, G05))

Adapt shifting speed regulation ((3 Ser., G21))

Bleeding the ABS/ESC system ((3 Ser., E91), (3 Ser., E92), (X5, E70), (Z4, E89), (1 Ser., E81), (1 Ser., E87), (2 Ser., F22), (3 Ser., E90), (3 Ser., E93), (5 Ser., E60), (5 Ser., E61), (1 Ser., E88))



Diagnostic devices

- Activating the axle alignment mode for self-steering rear axle ((X5, G05), (X7, G07), (X6, G06))
- Setting vehicle into sleep mode ((4 Ser., F82))
- Initializing the rain/light sensor ((2 Ser., F87))
- Initializing the exhaust gas flap ((3 Ser., G21))
- Adjusting the boost control rod ((3 Ser., G21), (5 Ser., G31))
- Learning the steering-angle sensor ((Z4, E89), (5 Ser., E60), (1 Ser., E87), (6 Ser., E63), (6 Ser., E64), (3 Ser., E92), (5 Ser., E61), (3 Ser., E90), (3 Ser., E91), (1 Ser., E81), (3 Ser., E93), (1 Ser., E88), (1 Ser., E82), (X5, E70), (2 Ser., F22), (1 Ser., 1C))
- Adapting the induction system ((X2, F39), (1 Ser., F40))
- Initialize acceleration sensor ((4 Ser., G22), (3 Ser., G21), (4 Ser., G23), (4 Ser., G26))
- Adapting the exhaust gas flap actuator ((X5, G05), (X7, G07), (X6, G06))
- Initializing the lateral acceleration sensor ((Z4, E89), (5 Ser., E60), (1 Ser., E87), (6 Ser., E63), (6 Ser., E64), (3 Ser., E92), (5 Ser., E61), (3 Ser., E90), (3 Ser., E91), (1 Ser., E81), (3 Ser., E93), (1 Ser., E88), (1 Ser., E82), (X5, E70), (2 Ser., F22), (1 Ser., 1C))
- Initializing the A/C flap actuators ((1 Ser., F20), (1 Ser., F21), (3 Ser., F30), (X5, F85), (3 Ser., F31), (3 Ser., F34), (2 Ser., F87), (i8, I12), (X5, F15), (X4, F26), (4 Ser., F32), (4 Ser., F36), (3 Ser., F80), (2 Ser., F45), (2 Ser., F22), (4 Ser., F82), (4 Ser., F83), (2 Ser., F46), (2 Ser., F23), (X1, F48), (X6, F86), (X6, F16), (4 Ser., F33), (X2, F39), (i8, I15), (X5, F95), (2 Ser., F44))
- Calibrating the radar sensor ((2 Ser., U06), (X1, U11))
- Resetting the quantity mean value adaptation ((Z4, G29), (3 Ser., G21))
- Resetting gearbox learning values ((3 Ser., G21))
- Standardizing the liftgate ((8 Ser., G14))
- Learning the power windows ((3 Ser., F30), (3 Ser., F31), (3 Ser., F34), (2 Ser., F87), (i8, I12), (4 Ser., F32), (4 Ser., F33), (3 Ser., F80), (2 Ser., F22), (4 Ser., F82), (X1, F48), (4 Ser., F36), (1 Ser., F20), (1 Ser., F21), (4 Ser., F83), (2 Ser., F45), (6 Ser., F06), (X2, F39), (7 Ser., F02), (5 Ser., F10), (i3, I01), (1 Ser., E87), (5 Ser., F11), (1 Ser., E81), (1 Ser., E88), (i8, I15))
- Resetting the DME adaptation values ((3 Ser., E90), (3 Ser., E91), (3 Ser., E93), (3 Ser., E92), (1 Ser., F20), (1 Ser., F21), (2 Ser., F22), (2 Ser., F23), (4 Ser., F33), (4 Ser., F32), (4 Ser., F36), (X1, F48), (3 Ser., F30), (3 Ser., F31), (3 Ser., F34), (3 Ser., G20), (3 Ser., G21))
- De-energizing the 48 V system ((3 Ser., G21), (5 Ser., G31))
- Unlocking aux. heater/independent car heater ((X3, F25), (5 Ser., F07), (5 Ser., F11), (5 Ser., F10), (6 Ser., F13), (6 Ser., F06), (1 Ser., F20), (1 Ser., F21), (3 Ser., F30), (6 Ser., F12), (7 Ser., F03), (3 Ser., F31), (3 Ser., F34), (2 Ser., F87), (X4, F26), (4 Ser., F32), (4 Ser., F33), (4 Ser., F36), (3 Ser., F80), (2 Ser., F45), (2 Ser., F22), (4 Ser., F82), (4 Ser., F83), (2 Ser., F46), (2 Ser., F23), (X1, F48), (X2, F39), (7 Ser., F02), (3 Ser., E91), (3 Ser., E92), (X5, E70), (1 Ser., E81), (1 Ser., E87), (3 Ser., E90), (3 Ser., E93), (5 Ser., E60), (5 Ser., E61), (8 Ser., G14), (1 Ser., E88))
- Resetting learned values of swirl flap actuators ((X3, F25), (5 Ser., F07), (5 Ser., F11), (5 Ser., F10), (7 Ser., F01), (7 Ser., F02), (6 Ser., F06), (1 Ser., F20), (3 Ser., F30), (6 Ser., F12), (6 Ser., F13), (1 Ser., F21), (3 Ser., F31), (3 Ser., F34), (X5, F15), (X4, F26), (4 Ser., F32), (4 Ser., F33), (4 Ser., F36), (2 Ser., F22), (X6, F16), (4 Ser., G22), (4 Ser., G23), (4 Ser., G26))
- De/activating the parking brake service mode ((1 Ser., F20), (1 Ser., F21), (3 Ser., F30), (3 Ser., F31), (3 Ser., F34), (2 Ser., F22), (2 Ser., F23), (4 Ser., F32), (4 Ser., F33), (4 Ser., F36), (7 Ser., G11), (7 Ser., G12), (8 Ser., G14), (X1, F48))
- Readdressing air distribution flaps ((i8, I12))



Diagnostic devices

Deactivating the service mode of SCR ECU ((5 Ser., F07), (5 Ser., F11), (5 Ser., F10), (X5, F15), (X6, F16), (7 Ser., G11), (7 Ser., G12), (5 Ser., G30), (X3, G01), (6 Ser., G32), (X4, G02), (8 Ser., G15), (X5, G05), (3 Ser., G20), (8 Ser., G14), (X7, G07), (3 Ser., G21), (8 Ser., G16), (4 Ser., G23), (4 Ser., G22), (5 Ser., G31))

Resetting mass airflow sensor adaptation values ((7 Ser., E65), (3 Ser., E46), (X5, E53), (7 Ser., E66), (7 Ser., E67), (7 Ser., F02), (5 Ser., F10), (3 Ser., E92), (X5, E70))

Interchanged brake pipe check ((3 Ser., F31), (3 Ser., F30))

Resetting learned values of fuel pressure regulator ((7 Ser., F02), (5 Ser., F10), (3 Ser., E92), (X5, E70), (4 Ser., G22), (4 Ser., G23), (4 Ser., G26))

Initializing the gear sensor ((3 Ser., G21))

Bleeding the fuel system ((5 Ser., E60), (5 Ser., E61), (6 Ser., E64), (6 Ser., E63), (X1, F48), (2 Ser., F22), (2 Ser., F23), (X2, F39), (5 Ser., F10), (3 Ser., E92), (X5, E70), (5 Ser., F11), (1 Ser., F40))

Resetting learned values of the transmission ECU ((X3, F25), (5 Ser., F07), (5 Ser., F11), (5 Ser., F10), (6 Ser., F13), (6 Ser., F06), (1 Ser., F20), (1 Ser., F21), (3 Ser., F30), (X5, E53), (7 Ser., E65), (5 Ser., E60), (7 Ser., E66), (7 Ser., E67), (6 Ser., F12), (3 Ser., F31), (3 Ser., F34), (X5, F15), (X4, F26), (4 Ser., F32), (4 Ser., F33), (4 Ser., F36), (2 Ser., F22), (7 Ser., E68), (2 Ser., F23), (X6, F16), (2 Ser., F45), (X1, F48), (X2, F39), (7 Ser., F02), (3 Ser., E91), (3 Ser., E92), (X5, E70), (Z4, E89), (1 Ser., E81), (1 Ser., E87), (3 Ser., E90), (3 Ser., E93), (5 Ser., E61), (1 Ser., E88), (i8, I12))

Initializing the tilt/slide sunroof manually ((3 Ser., E91), (3 Ser., E92), (X5, E70), (1 Ser., E81), (1 Ser., E87), (2 Ser., F22), (3 Ser., E90), (3 Ser., E93), (5 Ser., E60), (5 Ser., E61), (7 Ser., E65), (1 Ser., E88))

Initializing the adaptive suspension control ((4 Ser., F82), (4 Ser., F83))

Initializing ride height sensors ((5 Ser., F07), (5 Ser., F11), (5 Ser., F10), (6 Ser., F06), (1 Ser., F20), (1 Ser., F21), (3 Ser., F30), (6 Ser., F12), (X5, F85), (3 Ser., F31), (3 Ser., F34), (2 Ser., F87), (i8, I12), (X5, F15), (X4, F26), (4 Ser., F32), (4 Ser., F33), (4 Ser., F36), (3 Ser., F80), (2 Ser., F45), (2 Ser., F22), (4 Ser., F82), (2 Ser., F46), (2 Ser., F23), (X6, F86), (X6, F16), (4 Ser., F83), (X2, F39), (i8, I15), (X5, F95), (2 Ser., F44), (X1, F48))

Resetting starter learning values ((3 Ser., G21))

Activating the roller test stand mode ((7 Ser., F01), (7 Ser., F02), (7 Ser., F04), (1 Ser., F20), (1 Ser., F21), (3 Ser., F80), (2 Ser., F22), (2 Ser., F23), (3 Ser., F31), (3 Ser., F30))

Codings

Registering the battery ((3 Ser., G21))

Coding injectors ((3 Ser., G21))

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management



Diagnostic devices

Chevrolet/Daewoo

Trouble codes	
Parameters	
Actuators	
Basic settings	<p>Resetting learned values of the power window ((Trax, KL1B))</p> <p>Initializing idle speed ((Trax, KL1B))</p> <p>Initializing the crankshaft position ((Trax, KL1B))</p> <p>Learning the throttle valve ((Cruze, J300), (Captiva, C140), (Orlando, J309), (Cruze, J305), (Cruze, J308))</p> <p>Resetting differential pressure sensor learning values ((Cruze, J300), (Captiva, C140), (Orlando, J309), (Cruze, J305), (Cruze, J308))</p> <p>Resetting the particulate filter learning values ((Cruze, J300), (Cruze, J305), (Cruze, J308))</p> <p>Initializing the EGR valve ((Captiva, C140))</p>
Codings	
Service resets	
DolP/CAN	
Capable for diagnostics only with mega macs X	
Cyber Security Management (CSM)	
Capable for diagnostics only with Cyber Security Management	

Citroen

Trouble codes	(C4 Picasso, U), (C5 X, N)
Parameters	(C4 Picasso, U), (C5 X, N), (SpaceTourer,)
Actuators	(C4 Picasso, U), (C5 X, N), (SpaceTourer,)
Basic settings	<p>Learning the steering-angle sensor ((C4 Picasso, U), (C8, V), (Berlingo-III, 7), (C5, R), (DS3, S), (C3 Picasso, SH), (C3, SC), (DS4, N), (Berlingo-I, M49), (Xsara, C), (C5, D), (C3, FC), (C8, E), (C2, J), (C3 Pluriel, HB), (Berlingo-II, M59), (C4, L), (C4, N), (Jumpy-III, X), (DS5, K), (C-Elysee, D), (C4 Picasso, 3), (Xsara, N), (C4 Cactus-I, 0), (Jumpy-IV, V), (SpaceTourer, V), (C3, SX), (C3 Aircross, None), (Berlingo-II, M4), (Jumpy-III, VDECAIRC8), (Berlingo-IV, E), (C4 Cactus-I, 3), (C4 SpaceTourer, 3), (C4 Cactus-II, 0), (C5 Aircross, A), (SpaceTourer,), (C5 X, N), (C3, S), (DS5,), (C5, N), (C3, SX, SY))</p> <p>Initializing the transmission selector actuator ((C4, L), (C4 Picasso, 3))</p>



Diagnostic devices

Replacing engine parts ((C5, R), (C4 Picasso, U))

Filling the regeneration additive container ((C4 Picasso, U), (C3 Picasso, SH), (C3, SC), (C4, L), (Xsara, C), (C5, R), (C3, FC), (DS3, S), (C2, J), (Berlingo-III, 7), (C4 Cactus-I, 0), (DS4, N))

Adapting the accelerator sensor ((C8, V), (Xsara, C), (C5, D), (C3, FC), (C8, E), (C2, J), (C3 Pluriel, HB), (C5, R), (C4, L), (Xsara, N), (C3, SC), (C4 Picasso, U))

Replacing the regeneration additive container ((C5, D), (C3 Picasso, SH), (C5, R))

Learning the lambda sensor ((C3, FC), (DS3, S))

Initializing the transmission ECU ((C4 Picasso, 3))

Self-adaptation of A/C system ((Jumpy-III, X))

Adapting the clutch biting point ((C5 Aircross, A))

Replacing/filling the regeneration additive container ((C8, V), (C8, E), (C2, J), (C3, FC), (C3 Picasso, SH))

Resetting the fluid level of the regeneration additive system ((C8, V), (Berlingo-III, 7), (C3, SC), (C8, E), (C5, R), (C6, T), (C3, FC), (Jumpy-III, X), (C4, N), (C4 Picasso, 3), (C4 Cactus-I, 0), (C4 Picasso, U))

Performing transmission adaptations ((C4 Picasso, U), (C3 Picasso, SH), (Berlingo-III, 7), (DS4, N), (DS3, S), (C4, N), (C5, R), (DS5, K), (C4 Picasso, 3), (C4 Cactus-I, 0), (C-Elysee, D), (C4 Cactus-I, 3), (C4 Cactus-II, 0), (DS5,))

Adapting the longitudinal acceleration sensor ((Berlingo-III, 7), (C5 X, N))

Learning the turbocharger ((C5, D), (C5, R), (C3, SC))

ECU of high-voltage safety shutdown ((Berlingo-IV, E))

Replace brake parts ((Berlingo-III, 7), (C4, L), (C5 X, N))

Bleeding the regeneration additive pump/line ((C5, D), (DS5, K), (DS3, S), (DS4, N))

Initializing the rotation rate/acceleration sensor ((Berlingo-III, 7))

Initialising adaptive functions ((C8, V), (C5, D), (C8, E), (C6, T), (C3, FC), (C4 Picasso, 3), (C3 Aircross, None), (C4 SpaceTourer, 3), (C4, B))

Special bleeding ((C6, T))

Suspension pressure increase/-decrease ((Jumpy-III, X), (Jumpy-III, VDECAIRC8))

Initializing the sunroof anti-pinch protection ((C4 Picasso, U), (C6, T), (C3 Picasso, SH), (C5, D), (C3, FC), (C2, J), (C3 Pluriel, HB), (C5, R), (C4, L), (C3, SC), (C4 Picasso, 3))

Learning the turbocharger ((DS4, N), (C4, N))

Initializing the fuel level ((C5 X, N))

Learning the injection valve ((C4 Picasso, U))

Calibrating the cornering light ((C4 Picasso, U))

Leaving the ECO mode ((C5 X, N))

Bleeding the ABS/ESC system ((Berlingo-I, M49), (C4 Picasso, 3), (C4 Cactus-I, 0), (Berlingo-III, 7), (Jumpy-IV, V), (SpaceTourer, V), (C3, SX), (C3 Aircross, None), (C4 Cactus-I, 3), (C4 SpaceTourer, 3), (C4 Cactus-II, 0), (SpaceTourer,), (C5 X, N), (C4, B))

Initializing the start/stop system ((C4 Picasso, U))

Replacing the particle filter ((Xsara, C), (Berlingo-II, M59))



Diagnostic devices

Calibrating the camera ECU ((Jumper-III, Y (EU5)), (C1, P), (Berlingo-III, 7), (Jumper-IV, Y (EU6)), (Jumpy-IV, V), (SpaceTourer, V), (C3, SX), (C4 Picasso, 3), (C3 Aircross, None), (Berlingo-IV, E), (C4 SpaceTourer, 3), (C4 Cactus-II, 0), (C5 Aircross, A), (SpaceTourer,), (C5 X, N), (Jumper-IV, V), (C1, P*****), (C5, N))

Initializing the EGR valve ((C3, FC), (DS3, S))

Activating the start/stop function ((C4 Picasso, U))

Regenerating the soot particulate filter at standstill ((C4 Picasso, U))

Resetting headlight leveling adaptation values ((C-Crosser, V))

Codings

Coding the characteristic line ((C4 Picasso, U))

Coding transmission readings ((C4 Picasso, U))

Coding injectors ((Jumper-III, Y (EU5)), (C4 Picasso, U))

Coding the engine ECU ((Jumper-III, Y (EU5)))

Service resets

(C5 X, N)

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

Cupra

Trouble codes

(Formentor, KM)

Parameters

(Formentor, KM)

Actuators

(Formentor, KM)

Basic settings

Initializing electric seats ((Formentor, KM))

Filling fuel lines of parking heater/auxiliary heater ((Formentor, KM))

Regenerating the soot particulate filter ((Formentor, KM))

Resetting engine adaptation values ((Formentor, KM))

Initializing the ESC sensors ((Born, K1), (Formentor, KM))

Air conditioning ((Born, K1))

Adapting the electronic damper control ((Formentor, KM))

Burning off aux. heater/independent car heater ((Formentor, KM))

Performing transmission adaptations ((Formentor, KM))



Diagnostic devices

Standardizing the liftgate ((Formentor, KM))
Adapting the soot particulate filter ((Formentor, KM))
Learning the steering-angle sensor ((Formentor, KM))
Learning the throttle valve ((Formentor, KM))
Initializing the tilt/slide sunroof ((Formentor, KM))
Initializing the brake-pressure sensor ((Born, K1), (Formentor, KM))
Checking and resetting wear values of AWD clutch fluid ((Formentor, KM))
Resetting the brake pad wear indicator ((Born, K1))
Performing basic settings of emergency call system/telematics system ((Born, K1))
Initializing the brake-pedal travel sensor ((Born, K1))
Initializing the adaptive cruise control ((Formentor, KM))
Performing the initial run-in of the air conditioning compressor ((Formentor, KM))
Retracting parking brake ((Formentor, KM))
Special bleeding ((Formentor, KM))
Reducing fuel high pressure ((Formentor, KM))
Initializing the A/C flap actuators ((Formentor, KM))
Activating the retrofitted parking heater ((Formentor, KM))
Resetting timing chain adaptation values ((Formentor, KM))
Initializing the neutral position sensor ((Formentor, KM))
Calibrating the parking brake ((Formentor, KM))
Adjusting the headlights ((Formentor, KM))
Calibrating the camera ECU ((Born, K1), (Formentor, KM))
Adapting the fuel burning heater remote control ((Formentor, KM))
Extending parking brake ((Formentor, KM))
Unlocking aux. heater/independent car heater ((Formentor, KM))
Activating the roller test stand mode ((Formentor, KM))

Codings

Adjust parking assistance volume ((Formentor, KM))
Registering the battery ((Formentor, KM))
Coding the rain/light sensor ((Formentor, KM))
Deactivating/activating the transport mode ((Born, K1), (Formentor, KM))
Coding the trailer detection ((Formentor, KM))
De/activating the trailer hitch ((Formentor, KM))

Service resets

(Formentor, KM)



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security Management (CSM) (Born, K1), (Formentor, KM)

Capable for diagnostics
only with Cyber Security Management

Dacia

Trouble codes

Parameters

Actuators (Dokker, OSSJL), (Duster-III, HSDA), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Sandero-II, B8JL)

Basic settings Resetting oxygen sensor adaptation values ((Lodgy, JSDC,JSDD), (Duster-II, HSAL), (Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Initializing the exhaust gas flap ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Duster-III, HSAL,HMAA), (Duster-III, HMAB), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Learning the lambda sensor ((Duster-III, HSAL,HMAA), (Duster-III, HMAB))

Reset learned values of intake-air flap. ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Initializing the fuel pressure sensor or the fuel rail ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Duster-III, HSAL,HMAA), (Duster-III, HMAB), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Initializing the differential pressure sensor ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Duster-III, HSAL,HMAA), (Duster-III, HMAB), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Initializing the starter ring gear ((Lodgy, JSDC,JSDD), (Sandero-II, 5SDA,5SDL), (Sandero-II, 5SDG), (Logan-II, 4SDA,4SDA,4SDL), (Duster-II, HSDA), (Logan-II, 7SDA), (Duster-II, HSD3,HSDF), (Duster-II, HSAL), (Logan-II, 4SDC,4SDK), (Sandero-II, 5SDA,5SDA,5SDL), (Dokker, OSD), (Dokker, 8SD), (Logan-II, 4SDG,4SDN), (Logan-II, 7SDG,7SDN), (Logan-II, 7SDG,7SDN,4SDG), (Dokker, 0SDC), (Dokker, 0SDTV), (Lodgy, JSDC), (Lodgy, JSDM), (Dokker, 0SDCV), (Sandero-II, 5SDC,5SDC,5SDK), (Duster-II, SD), (Duster-II, HSAU), (Duster-



Diagnostic devices

I, H79), (Duster-I, HSDA), (Sandero-II, 5SD0,5SD4,5SD8), (Sandero-II, 5SD4,5SD4,5SD8), (Sandero-II, 5SDA,5SDK,5SDC), (Logan-II, 4SRK), (Dokker, 0ES), (Dokker, 0ESNB), (Dokker, 0EVNB,0ESNB), (Duster-III, HMMA), (Duster-III, HMM1), (Lodgy, JSNB,JESNB), (Logan-II, 4ESJR), (Logan-II, 4SDCH,4SDKH,4SD4H,4SD8H), (Logan-II, 4SDCJ,4SDKJ,4SD4J,4AD8J), (Logan-II, 7SDL1), (Logan-II, 7ESJR,7EVJR), (Logan-II, 7EVJR,7DVJL), (Logan-II, 7SDCH,7SDKH,7DSJW), (Logan-II, 7SDA1,7SDL1), (Logan-II, 4SDA,4SDL), (Sandero-II, 5SDAA), (Sandero-II, 5ESJR), (Sandero-II, 5SDG,5EVJR), (Sandero-II, 5ESDG1), (Sandero-II, B8JR), (Sandero-II, 5ESDS1), (Logan-II, 7SDCJ), (Lodgy, JSNB), (Logan-II, SD))

After particulate filter replacement ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Resetting learned values of fuel injector of soot particulate filter ((Duster-I, H79), (Duster-I, HSDA))

Initializing the mass airflow sensor ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Duster-III, HSAL,HMAA), (Duster-III, HMAB), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Resetting the start inhibitor of DEF injection system ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Regenerating the soot particulate filter ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Duster-III, HSAL,HMAA), (Duster-III, HMAB), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Initializing the exhaust gas flap ((Lodgy, JSDC,JSDD), (Duster-II, HSAL))

Calibrating the steering-angle sensor ((Duster-II, HSD3,HSDF), (Duster-II, SD))

Initializing the intake-air flap ((Lodgy, JSDC,JSDD), (Duster-II, HSAL), (Duster-III, HSAL,HMAA), (Duster-III, HMAB))

Resetting learned values of the low-pressure EGR valve ((Lodgy, JSDC,JSDD), (Duster-II, HSAL))

Regenerating the soot particulate filter ((Lodgy, JSDC,JSDD), (Duster-II, HSAL), (Dokker, 8SD))

Resetting EGR valve learning values ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Resetting high-pressure fuel pump adaptation values ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Duster-III, HSAL,HMAA), (Duster-III, HMAB), (Lodgy, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Lodgy, 7SD*L))

Initializing the low pressure EGR valve ((Duster-III, HSAL,HMAA), (Duster-III, HMAB))

Initializing the soot particulate filter upon replacement ((Duster-III, HSAL,HMAA), (Duster-III, HMAB))

Initializing the engine ECU ((Duster-I, H79), (Duster-I, HSDA))



Diagnostic devices

Adapting the variable camshaft timing ((Sandero-III, DJ))

Initializing the EGR valve ((Duster-III, HSAL,HMAA), (Duster-III, HMAB))

Reset low-pressure EGR learned values ((Dokker, OSSJL), (Dokker, 0DSJW), (Dokker, 0DSJW,7DSJW), (Duster-III, HSDA), (Duster-III, HMAF), (Duster-III, HMAD), (Logan, JSJT,JDSJT), (Logan-II, 4DSJL), (Logan-II, 4DSJW), (Logan-II, 7DVJL), (Dokker, FEJW), (Dokker, FEJL), (Sandero-II, B8JL), (Sandero-II, B8JW), (Logan-II, 7SD*L), (Logan, 7SD*L))

Resetting starter learning values ((Duster-III, HSAL,HMAA), (Duster-III, HMAB))

Codings

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM) (Sandero-III, DJ)

Capable for diagnostics only with Cyber Security Management

Dodge

Trouble codes

Parameters

Actuators

Basic settings

Bleeding the ABS/ESC system ((Durango, WD))

Initializing the ABS/ESC system ((Challenger, LA), (Charger, LD), (Durango, WD))

Resetting engine adaptation values ((Challenger, LC), (RAM, DD,DJ,DP,DS,D2))

Learning the throttle valve ((Challenger, LC), (Challenger, LA), (Charger, LD), (Durango, WD))

Initializing crankshaft/camshaft position ((Challenger, LC), (Challenger, LA), (Charger, LD), (Durango, WD))

Resetting gearbox learning values ((Durango, HB), (Nitro, KA), (Caliber, PM), (Avenger, JS), (RAM, DC,DH,DM,DR,D1), (Challenger, LC), (Durango, WD))

Calibrating the tire pressure monitoring system ((RAM, DD,DJ,DP,DS,D2))

Codings

Service resets



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

DS Automobiles

Trouble codes

Parameters

Actuators

Basic settings

- Initialising adaptive functions ((DS3 Crossback, U))
- Calibrating the camera ECU ((DS7, J))
- Adapting the clutch biting point ((DS7, J))
- Learning the steering-angle sensor ((DS7, J))

Codings

Service resets

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

Fiat

Trouble codes (Ducato-VI (290), 290 (EU6))

Parameters (Ducato-VI (290), 290 (EU6))

Actuators

Basic settings Adapting the longitudinal acceleration sensor ((Punto (199), 199))



Diagnostic devices

Learning the steering-angle sensor ((Doblo (152/263), 263), (Scudo (270), 270), (Tipo (356), 356), (Aegea (356), 356), (500 (312), 312))
Adapting the camshaft ((Panda (319), 319))
Replace diesel exhaust fluid pressure sensor ((Ducato-VI (290), 290 (EU6)))
Replacing the fuel pressure sensor ((Scudo (270), 270))
Resetting engine adaptation values ((Ducato-V (250), 250), (500 (312), 312))
Initializing the oxidation catalyst ((Punto (199), 199))
Learning the lambda sensor ((Doblo (152/263), 263), (500L (330), 330))
Adapting the zero position of the pulse-generator ring ((Punto (199), 199), (Fiorino (225), 225), (Doblo (152/263), 263), (Panda (319), 319))
Resetting adaptation values of alternator ((Punto (199), 199), (Doblo (152/263), 263), (500 (312), 312))
Resetting the indicator light "Water in fuel" ((500L (330), 330))
Initializing the fuel high-pressure sensor ((500L (330), 330))
Initializing the differential pressure sensor ((Ducato-V (250), 250FL), (Idea (350), 350), (Bravo (198), 198), (Linea (323), 323), (500L (330), 330))
Replacing the lambda probe ((Punto (199), 199))
Initializing the high-pressure EGR valve ((500L (330), 330))
Replacing the diesel exhaust fluid pump ((Ducato-VI (290), 290 (EU6)))
Learning the steering-angle sensor ((Punto (199), 199))
Learning the throttle valve ((Tipo (356), 356))
Resetting learned values of NOx adsorption catalyst ((500L (330), 330), (Panda (319), 319))
Resetting engine adaptation values of auxiliary aggregates/systems ((Punto (199), 199), (500 (312), 312), (500L (330), 330), (Panda (319), 319))
Regenerating the soot particulate filter ((Punto (199), 199), (Fiorino (225), 225), (Ducato-V (250), 250), (Scudo (270), 270), (500L (330), 330))
Performing transmission adaptations ((Punto (199), 199), (Fiorino (225), 225), (Qubo (300), 300), (Ducato-V (250), 250), (Ducato-V (250), 250FL), (Punto (188), 188), (Stilo (192), 192), (Idea (350), 350), (Panda (169), 169), (500 (312), 312), (Bravo (198), 198), (Linea (323), 323), (Stilo (192), 192/ 292), (Ducato-VI (290), 290 (EU5)))
Initializing the high-pressure pump/flow control ((Panda (319), 319), (Tipo (356), 356), (Aegea (356), 356))
IDLE SPEED CONTROLLER ((Uno (146), 146 A), (Tipo (160), 160))
Resetting learned values of diesel exhaust fluid pump ((Ducato-VI (290), 290 (EU6)))
Bleeding the regeneration additive pump/line ((Scudo (270), 270))
Reset learned values for diesel exhaust fluid tank system ((Ducato-VI (290), 290 (EU6)))
Initializing the fuel high-pressure sensor ((Punto (199), 199), (Fiorino (225), 225), (Doblo (152/263), 263))
Initializing the adaptive cruise control ((Tipo (356), 356))
Resetting mass airflow sensor adaptation values ((Fiorino (225), 225), (Ducato-V (250), 250FL), (Punto (199), 199), (500L (330), 330), (500X (334), 334), (Panda (319), 319), (Tipo (356), 356), (Aegea (356), 356))



Diagnostic devices

Resetting differential pressure sensor learning values ((Punto (199), 199), (Fiorino (225), 225), (Doblo (152/263), 263), (Panda (319), 319), (Tipo (356), 356))
Learning the turbocharger ((500 (312), 312), (Panda (319), 319), (Tipo (356), 356), (Aegea (356), 356))
Bleeding the brake system ((500 (332), 332))
Resetting the diesel exhaust fluid level ((Ducato-VI (290), 290 (EU6)))
Bleed DEF injection system ((Ducato-VI (290), 290 (EU6)))
Initializing the low pressure EGR valve ((500L (330), 330), (Panda (319), 319))
Initializing the clutch pedal position ((Panda (319), 319), (500 (312), 312), (500L (330), 330), (Tipo (356), 356), (Aegea (356), 356))
Replace DEF injector ((Ducato-VI (290), 290 (EU6)))
Resetting the learned values for DEF injector ((Ducato-VI (290), 290 (EU6)))
Deactivate power-output limitation ((500 (312), 312))
Resetting the variable turbocharger adaptation values ((Scudo (270), 270))
Bleeding the cooling system ((500 (332), 332))
Replacing the particle filter ((Fiorino (225), 225), (Ducato-V (250), 250), (500L (330), 330))
Calibrating the camera ECU ((Tipo (356), 356))
Initializing the EGR valve ((Ulysse-III (179), 179), (Tipo (356), 356), (Aegea (356), 356))
Resetting camshaft adaptation values ((Punto (199), 199))
Resetting throttle valve adaptation values ((Punto (199), 199))
Replace diesel exhaust fluid tank ((Ducato-VI (290), 290 (EU6)))
Replacing the differential pressure sensor ((Punto (199), 199))
Replace diesel exhaust fluid line ((Ducato-VI (290), 290 (EU6)))
Initializing the neutral position sensor ((500 (312), 312), (500L (330), 330), (Punto (199), 199), (Panda (319), 319), (Tipo (356), 356), (Aegea (356), 356))
Calibrating the tire pressure monitoring system ((Tipo (356), 356), (Aegea (356), 356))

Codings

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM) (Doblo (152/263), 263), (500L (330), 330), (500X (334), 334), (500 (332), 332)

Capable for diagnostics only with Cyber Security Management



Diagnostic devices

Ford

- | **Trouble codes** (Fiesta 08, JHH), (Kuga 02, DM2)
- | **Parameters** (Fiesta 08, JHH), (Kuga 02, DM2)
- | **Actuators**
- | **Basic settings**
 - Adapting the longitudinal acceleration sensor ((Transit 09, FAE6), (Transit 10, FAC), (Transit 10, FCC), (Transit 10, 81BE), (Transit 10, FED, FFD), (Transit 10, FAD, FBD), (Transit 10, FCD, FDD), (Transit 10, FCD), (Transit 10, FFD), (Transit 10, FED), (Transit 10, FDD), (Transit 10, SX), (Transit 10, 81), (Galaxy 04, WA6), (S-Max 02, WA6), (Transit 10, SXS), (Transit 09, FCC), (Transit 09, SXSF), (Transit 09, SXS), (Transit 09, FDF6, FDG6, FDE6, FBE6, FZE6), (Transit 10, FAD), (Tourneo Connect 03, FAC), (Transit 09, FDA6, FDC6, FDB6), (Transit 11, FAC), (Transit 09, FAC), (Transit 11, FCC), (Transit 09, FAA6, FEB6, FEC6, FAB6, FED6, FAD6, FAC6), (Transit 09, FAE6, FAB6, FAD6, FAC6, FSA6, FSB6, FSC6), (Transit 09, FNF6, FMG6, FMF6, FME6), (Transit 09, FMB6, FN6, FMC6, FNC6, FMA6, FND6, FMD6), (Transit 09,), (Transit 11, FAD), (Transit 11, FCD, FDD), (Transit 11, FFD, FED), (Transit 09, FDE6, FDF6, FDG6, FZE6), (Transit 09, FEF6, FEG6, FAG6, FAE6, FAF6, FSE6, FSF6, FSG6), (Transit 09, FAE6, FAG6, FSE6, FSF6, FSG6, FAF6, FEF6, FEG6), (Transit 09, FEB6, FAA6, FEC6, FAB6, FED6, FAD6, FAC6), (Transit 09, FNF6, FMG6, FMH6, FMF6, FFF6, FFG6, FME6), (Transit 09, FME6, FMG6, FMH6, FN6, FMF6, FFG6, FFF6, FFE6), (Transit 09, FGD6, FGC6, FGB6, FFB6, FFD6, FFC6, FMB6, FNB6, FMC6, FNC6, FMA6, FND6, FMD6), (Transit 09, FBE6), (Transit 11,), (Transit 11, FCD), (Transit 11, FED, FFD), (Transit 10, FFD, FED), (Transit 11, FBD), (Transit 11, FED), (Tourneo Connect 03, SK))
 - Adapting the camshaft ((Mondeo 04, BA7))
 - Initializing the lateral acceleration sensor ((Focus 04, DYB), (Mondeo 04, BA7), (Fiesta 07, JA8), (Ecosport, JK8), (Fiesta 07, JR8), (KA+, KAF), (Fiesta 06, JR8), (Tourneo Connect 01, PT2), (Tourneo Connect 01, PJ2), (Galaxy 03, WA6), (S-Max 01, WA6), (C-Max 03, DXA), (B-Max, JK8), (Focus 05, DYB), (C-Max 04, DXA), (Fiesta 06, JA8), (C-Max 02, DM2), (Fusion, JU2), (Tourneo Connect 02, PT2), (Mondeo 04, BA7-LPG), (Focus 03, DYB))
 - Activating the tire pressure sensors ((Kuga 02, DM2), (Fiesta 08, JHH))
 - Deactivating the transport mode ((Kuga 02, DM2))
 - Calibrating the steering wheel position sensor ((Ecosport, JK8), (Kuga 02, DM2))
 - Correcting straight-running stability ((Kuga 02, DM2))
 - Initialize tire pressure sensors ((Kuga 02, DM2), (Fiesta 08, JHH))
 - Resetting EGR valve learning values ((Galaxy 03, WA6), (S-Max 01, WA6), (Mondeo 04, BA7))
 - Resetting oxygen sensor adaptation values ((Galaxy 03, WA6), (S-Max 01, WA6))
 - Initializing the fuel high-pressure sensor ((Focus 05, DYB), (Ranger 05, 2AB))
 - Adapting the longitudinal acceleration sensor ((Kuga 02, DM2))
 - Initializing the tilt/slide sunroof ((Kuga 02, DM2))
 - Resetting the fuel low pressure adaptation values ((Focus 04, DYB), (Focus 05, DYB))
 - Teach-in battery sensor module ((Kuga 02, DM2), (Fiesta 08, JHH))
 - Standardizing the liftgate ((Focus 05, DYB), (C-Max 04, DXA), (C-Max 03, DXA), (Focus 04, DYB), (Kuga 02, DM2), (Focus 03, DYB))



Diagnostic devices

Deactivating the crash mode ((Fiesta 07, JA8), (Ecosport, JK8), (Fiesta 07, JR8), (Kuga 02, DM2))

Resetting learned values of the interface module ((Fiesta 08, JHH))

Initializing the wipers ((Kuga 02, DM2))

Learning the steering-angle sensor ((Kuga 02, DM2), (Focus 05, DYB), (C-Max 04, DXA), (Focus 04, DYB), (Galaxy 03, WA6), (C-Max 03, DXA), (S-Max 01, WA6), (Focus 03, DYB))

Resetting the particulate filter learning values ((Kuga 02, DM2), (Ranger 04, 2AB), (Mondeo 05, BA7), (S-Max 02, WA6), (Galaxy 04, WA6))

Resetting learned values of the DEF injection system ((Ranger 05, 2AB))

Resetting adaptation values of high-pressure fuel system ((Transit 09, FME6, FMG6, FMH6, FNF6, FMF6, FFG6, FFH6, FFF6), (Transit 09, FAE6), (Transit 09, FAE6, FAG6, FSE6, FSF6, FSG6, FAF6, FEC6, FEG6), (Transit 09, FDE6, FDF6, FDG6, FZE6), (Transit 09, H2), (Transit 09, 421), (Ranger 04, 2AB), (Transit 09, FBE6), (Transit 09, SXS))

Resetting adaptation values of ABS ECU ((Focus 04, DYB), (C-Max 03, DXA))

Initializing the adaptive cruise control ((Kuga 02, DM2), (Fiesta 08, JHH))

Adjusting the xenon headlight ((Kuga 02, DM2))

Resetting engine adaptation values ((Kuga 02, DM2))

Initializing the yaw rate sensor ((Mondeo 04, BA7), (Fiesta 07, JA8), (Ecosport, JK8), (Fiesta 07, JR8), (Fiesta 06, JR8), (Galaxy 03, WA6), (S-Max 01, WA6), (B-Max, JK8), (Fiesta 06, JA8), (Mondeo 04, BA7-LPG))

Initializing the lateral acceleration sensor ((Kuga 02, DM2))

Initializing the SCR system ((C-Max 04, DXA))

Calibrating the lane departure warning system camera ((Mondeo 05, BA7), (S-Max 02, WA6), (Galaxy 04, WA6), (Kuga 02, DM2), (Fiesta 08, JHH))

Resetting mass airflow sensor adaptation values ((Kuga 02, DM2), (Transit 09, FAE6), (Transit 09, FDF6, FDG6, FDE6, FBE6, FZE6), (Ranger 04, 2AB), (Transit 10, FAC), (Transit 10, FCC), (Mondeo 05, BA7), (Ranger 05, 2AB), (S-Max 02, WA6), (Galaxy 04, WA6), (Transit 10, 81BE), (Transit 10, 81), (Galaxy 03, WA6), (C-Max 03, DXA), (Mondeo 04, BA7), (S-Max 01, WA6), (Transit 10, FED), (Transit 10, SX), (Transit 10, SXS), (Transit 09, SXS), (Transit 10, FAD, FBD), (Transit 10, FCD, FDD), (Transit 10, FAD), (Transit 09, FDA6, FDC6, FDB6), (Transit 09, FAC), (Transit 09, FCC), (Transit 09, FAA6, FEB6, FEC6, FAB6, FED6, FAD6, FAC6), (Transit 09, FAA6, FAB6, FAD6, FAC6, FSA6, FSB6, FSC6), (Transit 09, FNF6, FMG6, FMF6, FME6), (Transit 09, FMB6, FNB6, FMC6, FNC6, FMA6, FND6, FMD6), (Transit 09,), (Transit 10, FED, FFD), (Focus 04, DYB), (Transit 09, FDE6, FDF6, FDG6, FZE6), (Transit 09, FEF6, FEG6, FAG6, FAE6, FAF6, FSE6, FSF6, FSG6), (Transit 09, FAE6, FAG6, FSE6, FSF6, FSG6, FAF6, FEC6, FEG6), (Transit 09, FEB6, FAA6, FEC6, FAB6, FED6, FAD6, FAC6), (Transit 09, FNF6, FMG6, FMH6, FMF6, FFF6, FFG6, FME6), (Transit 09, FME6, FMG6, FMH6, FNF6, FMF6, FFG6, FFH6, FFF6), (Transit 09, FGD6, FGC6, FGB6, FFB6, FFD6, FFC6, FMB6, FNB6, FMC6, FNC6, FMA6, FND6, FMD6), (Transit 09, FBE6), (Transit 10, FFD, FED))

Resetting differential pressure sensor learning values ((C-Max 03, DXA), (Mondeo 04, BA7), (C-Max 04, DXA))

Initializing the forward collision warning system ((Kuga 02, DM2))

Reset fuel pump learning values ((Mondeo 05, BA7))



Diagnostic devices

Resetting the injection pump learning values ((Transit 09, FED), (Focus 04, DYB), (Transit 10, FED), (Transit 10, FCD,FDD), (Transit 10, FAC), (Transit 10, SXS), (Transit 10, FAD,FBD), (Transit 10, FDD))

Calibrating the parking brake ((Kuga 02, DM2))

Adapting the radiator shutter ((Focus 05, DYB), (C-Max 04, DXA), (Kuga 02, DM2))

Resetting self-adaptation parameters ((Ranger 04, 2AB), (Ranger 05, 2AB))

Initializing the brake-pressure sensor ((Focus 04, DYB), (Transit 09, FME6,FMG6,FMH6,FNF6,FMF6,FFG6,FFH6,FFF6), (Transit 09, FMB6), (Transit 09, FNB6,FMC6,FMB6,FMA6,FMD6,FND6,FNC6), (Transit 09, FMD6), (Transit 09, FNB6,FNC6,FND6,FMC6,FMD6,FMB6), (Transit 09, FNF6), (Transit 09, FNC6,FMD6,FNB6,FMB6,FMA6,FMC6,FND6), (Transit 09, FND6), (Transit 09, FDB6), (Transit 09, FDC6), (Transit 09, FDG6), (Transit 09, FED6), (Transit 09, FFA6), (Transit 09, FEF6,FEG6,FAG6,FAE6,FAF6,FSE6,FSF6,FSG6), (Transit 09, FSF6), (Transit 09, FSG6), (Transit 09, FZE6), (Transit 09, FCD6,FCC6), (Transit 09, FGD6,FGC6,FGB6,FFB6,FFD6,FFC6,FMB6,FNB6,FMC6,FNC6,FMA6,FND6,FMD6), (Transit 09, FMC6), (Transit 09, FAA6,FAB6,FAD6,FAC6,FSA6,FSB6,FSC6), (Transit 09, FNF6,FMG6,FMH6,FMF6,FFF6,FFG6,FME6), (Transit 09, FMF6,FMH6,FMG6,FME6,FNF6), (Transit 09, FGD6), (Transit 09, FGB6), (Transit 09, FGC6), (Transit 09, FMB6,FNB6,FMC6,FNC6,FMA6,FND6,FMD6), (Transit 09, FNC6), (Transit 09, FDF6,FDG6,FDE6,FBE6,FZE6), (Transit 09, 411), (Fiesta 07, JA8), (Ecosport, JK8), (Fiesta 07, JR8), (Tourneo Connect 03, JU2), (Tourneo Connect 03, PU2), (Tourneo Connect 03, PJ2), (Transit 09, FAE6), (Tourneo Connect 03, JN8), (KA+, KAF), (Fiesta 06, JR8), (Tourneo Connect 01, PT2), (Tourneo Connect 01, PJ2), (C-Max 03, DXA), (B-Max, JK8), (Focus 05, DYB), (C-Max 04, DXA), (Transit 09, FAA6,FAC6,FAB6), (Transit 09, FBE6,FDE6,FDF6,FDG6,FZE6), (Transit 09, FSB6), (Transit 09, FSA6,FSB6,FSC6,FAA6,FAC6,FAD6,FAB6), (Transit 09, FAC6,FAA6,FAB6,FAD6,FSB6,FSA6,FSC6,FEC6), (Transit 09, FSC6), (Transit 09, FSE6,FSF6,FSG6,FAE6,FAG6,FAF6), (Transit 09, FAA6), (Transit 09, FME6,FMF6,FNF6), (Transit 09, FME6,FMF6,FMH6,FNF6,FMG6), (Transit 09, FAC6), (Transit 09, FAD6), (Transit 09, FAB6), (Transit 09, FNB6), (Transit 09, FMA6), (Transit 09, FDA6), (Transit 09, FDB6,FDC6,FCD6,FCC6), (Transit 09, FSA6), (Transit 09, FCD6), (Transit 09, FCC6), (Transit 09, H3), (Transit 09, 2070), (Fiesta 06, JA8), (Transit 09, FSA6,FSB6,FSC6,FAA6,FAC6,FAD6,FAB6,FEC6), (Transit 09, EG/DH), (Transit 09, EG/EH), (Transit 09, EG/CH), (Transit 09, EG/F), (Transit 09, FDA6,FCC6,FDB6,FDC6), (Transit 09, H2), (Transit 09, 2060), (Transit 09, FDC6,FDB6,FCC6), (Transit 09, X1), (Transit 09, FSB6,FSC6,FAB6,FAC6,FAD6), (Transit 09, BN), (Transit 09, FAF6,FAG6,FAE6,FSE6,FSG6,FSF6), (Transit 09, FDE6,FDG6,FDF6,FZE6), (Transit 09, FEB6,FAA6,FEC6,FAB6,FED6,FAD6,FAC6), (Transit 09, FAE6,FAG6,FSE6,FSF6,FSG6,FAF6,FEF6,FEG6), (Transit 09,), (Transit 09, 2760), (Transit 09, FAA6,FEB6,FEC6,FAB6,FED6,FAD6,FAC6,FSA6,FSB6,FSC6), (Transit 09, FAF6), (Transit 09, FDA6,FDC6,FDB6), (Transit 09, FDE6), (Transit 09, FAG6), (Transit 09, FAA6,FEB6,FEC6,FAB6,FED6,FAD6,FAC6), (Transit 09, FEB6), (Transit 09, FEC6), (Transit 09, FFB6), (Transit 09, FFD6), (Transit 09, FSE6), (Transit 09, FFC6), (Transit 09, 421), (Transit 09, EG/F 002), (Transit 09, EG/DH 002), (Transit 09, EG/CH 001), (C-Max 02, DM2), (Fusion, JU2), (Mondeo 04, BA7), (Tourneo Connect 02, PT2), (Tourneo Connect 03,), (Focus 03, DYB))

Bleeding the ABS/ESC system ((Ecosport, JK8), (Fiesta 06, JR8), (Fiesta 06, JA8), (Focus 06, HN), (Focus 06, HP), (Focus 06, HM), (Focus 06, DYB), (Kuga 02, DM2), (Puma 02, J2K))

Learning the power windows ((Fiesta 05, JH1), (Ecosport, JK8), (Tourneo Connect 03, JU2), (Tourneo Connect 03, PU2), (Tourneo Connect 03, PJ2), (Transit 09, FAE6), (Transit 09, FED), (Tourneo Connect 03, JN8), (Focus 01, DFW), (Focus 01, DNW), (Focus 01, DBW), (Focus 01, DAW), (Focus 01, DWA), (Mondeo 03, B4Y), (Mondeo 03, B5Y), (Mondeo 03, BWY), (Focus 01, DB1), (Focus 01, DA1), (Fiesta 05, JBS), (Fiesta 05, JAS), (Fusion, JU2), (C-Max 01, DM2), (Fiesta 05, JD3), (Mondeo 05, BA7), (Focus 01, DN1), (Focus 01, DBY), (Focus 01,



Diagnostic devices

DBX), (Focus 01, DNX), (Focus 01, DAX), (Focus 02, DA3), (Focus 02, DBX), (Focus 02, DNX), (Focus 02, DAX), (Focus 02, DBY), (Fiesta 05, J5S), (Focus 02, DM3), (Focus 02, DB3), (C-Max 02, DM2), (Focus 03, DB3), (Focus 03, DA3), (S-Max 02, WA6), (C-Max 02, DA3), (Fiesta 05, JC3), (Fiesta 05, JA8), (Focus 01,), (Fiesta 05, BA7), (Mondeo 03,), (Mondeo 03, B4Y/B5Y/ BWY), (Focus 01, DAW/ DBW/ DFW/ DNW), (Fiesta 05, JH1/JD3/JC3), (Focus 02, DA3 / DB3), (Transit 10, FAD,FBD), (Transit 10, FCD,FDD), (Transit 10, FCD), (Transit 10, FDD), (Transit 10, FFD,FED), (Transit 10, FED,FFD), (Transit 10, FFD), (Transit 10, FED), (Transit 10, FAD), (Galaxy 04, WA6), (Transit 10, FCC), (Transit 10, 81BE), (C-Max 04, DXA), (Focus 04, DYB), (Galaxy 03, WA6), (C-Max 03, DXA), (Mondeo 04, BA7), (S-Max 01, WA6), (Transit 10, FAC), (Transit 10, SX), (Transit 10, SXS), (Transit 09, SXS), (Transit 10, 81), (Kuga 02, DM2), (Tourneo Connect 03,))

De/activating the parking brake service mode ((Kuga 02, DM2))

Resetting the intake manifold flap learning values ((Focus 04, DYB), (Galaxy 03, WA6), (S-Max 01, WA6), (C-Max 03, DXA), (Mondeo 04, BA7))

Resetting EGR valve learning values ((Transit 09, FME6,FMG6,FMH6,FNF6,FMF6,FFG6,FFF6), (Transit 09, FAE6), (Transit 09, FDF6,FDG6,FDE6,FBE6,FZE6), (Transit 09, FAE6,FAG6,FSE6,FSF6,FSG6,FAF6,FEF6,FEG6), (Transit 09, FDE6,FDF6,FDG6,FZE6), (Transit 09, H2), (Transit 09, 421), (Ranger 04, 2AB), (Transit 09, FBE6), (Transit 10, FAC), (Transit 10, FCC), (Transit 10, 81BE), (Transit 10, 81), (Transit 10, FED), (Transit 10, SX), (Transit 10, SXS), (Transit 09, SXS), (Transit 10, FAD,FBD), (Transit 10, FCD,FDD), (Transit 10, FAD), (Transit 09, FDA6,FDC6,FDB6), (Transit 09, FAC), (Transit 09, FCC), (Transit 09, FAA6,FEB6,FEC6,FAB6,FED6,FAD6,FAC6), (Transit 09, FAA6,FAB6,FAD6,FAC6,FSA6,FSB6,FSC6), (Transit 09, FNF6,FMG6,FMF6,FME6), (Transit 09, FMB6,FNB6,FMC6,FNC6,FMA6,FND6,FMD6), (Transit 09,), (Transit 10, FED,FFD), (Transit 09, FEF6,FEG6,FAG6,FAE6,FAF6,FSE6,FSF6,FSG6), (Transit 09, FEB6,FAA6,FEC6,FAB6,FED6,FAD6,FAC6), (Transit 09, FNF6,FMG6,FMH6,FMF6,FFF6,FFG6,FME6), (Transit 09, FGD6,FGC6,FGB6,FFB6,FFD6,FFC6,FMB6,FNB6,FMC6,FNC6,FMA6,FND6,FMD6), (Transit 10, FFD,FED))

Adapting the longitudinal acceleration sensor ((Focus 04, DYB), (KA+, KAF), (B-Max, JK8), (C-Max 03, DXA))

Initializing the brake-pressure sensor ((Kuga 02, DM2))

Calibrating the parking brake ((S-Max 02, WA6), (Galaxy 04, WA6))

Codings

Service resets (Fiesta 08, JHH)

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management



Diagnostic devices

Honda

Trouble codes	
Parameters	
Actuators	
Basic settings	Regenerating the soot particulate filter ((HR-V, RU)) Initializing the electronic stability control sensors ((CR-V, RW)) Calibrating the camera ECU ((Civic, FK), (Civic, FN), (Civic, FD))
Codings	
Service resets	
DolP/CAN	
Capable for diagnostics only with mega macs X	
Cyber Security Management (CSM)	
Capable for diagnostics only with Cyber Security Management	

Hyundai

Trouble codes	(Grand Santa Fe, NC), (i20, BC3), (i30 / i30cw, GD), (i30 / i30cw, PD), (Ioniq, NE), (Kona, OS), (Santa Fe, DM), (Santa Fe, TM), (Tucson, NX4), (Tucson, TL)
Parameters	(Grand Santa Fe, NC), (Ioniq, NE), (Tucson, TL)
Actuators	(Grand Santa Fe, NC), (Tucson, TL)
Basic settings	Learning the steering-angle sensor ((Santa Fe, CM), (ix20, JC), (Genesis Coupe, BK), (Grand Santa Fe, NC), (Tucson, TL), (i30 / i30cw, FD), (i20, PB), (ix35, EL), (Elantra, MD), (i40 / i40cw, VF), (i30 / i30cw, GD), (Santa Fe, DM), (i20, GB), (ix35, LM FCEV), (Genesis, BH), (Elantra, MD, UD), (Elantra, AD), (i30 / i30cw, PD), (Kona, OS), (Santa Fe, TM), (i10, AC3), (i20, BC3)) Performing the compression test ((Grand Santa Fe, NC)) Regenerating the soot particulate filter ((i30 / i30cw, PD)) Resetting engine adaptation values ((Genesis Coupe, BK), (i10, IA), (Tucson, TL), (Genesis, BH), (i30 / i30cw, PD), (Kona, OS)) Learning the lambda sensor ((Tucson, TL), (i20, PB), (ix35, EL), (i40 / i40cw, VF), (Elantra, MD), (i30 / i30cw, PD), (Kona, OS)) Adapting the swirl control valve ((i30 / i30cw, FD), (ix55 / Veracruz, EN), (ix35, EL), (i40 / i40cw, VF), (Elantra, MD), (Grandeur / Azera, IG))



Diagnostic devices

Initializing the EGR valve ((Elantra, MD), (ix20, JC), (i30 / i30cw, GD), (Grandeur / Azera, IG))

Bleeding the fuel system ((i20, GB), (i30 / i30cw, PD), (Kona, OS), (Santa Fe, TM))

Learning the throttle valve ((Tucson, TL))

Initializing the differential pressure sensor ((Tucson, TL))

Replacing the lambda probe ((ix55 / Veracruz, EN))

Adapting the longitudinal acceleration sensor ((Grand Santa Fe, NC), (Tucson, TL))

Standardizing the liftgate ((Grand Santa Fe, NC), (Tucson, NX4))

Initializing the swirl control valve ((Tucson, TL))

Initializing the mass airflow sensor ((Tucson, TL))

Adapting the longitudinal acceleration sensor ((Santa Fe, TM), (i20, BC3))

Reset learning values ((Santa Fe, SM), (i20, PB), (ix35, EL), (i30 / i30cw, GD))

Regenerating the soot particulate filter ((Tucson, JM), (Grandeur / Azera, TG), (Tucson, TL))

Resetting gearbox learning values ((ix20, JC), (Grand Santa Fe, NC), (Tucson, TL), (Veloster, FS), (ix35, EL), (i30 / i30cw, GD), (Santa Fe, DM), (ix35, LM FCEV), (Santa Fe, TM))

Initializing the torque sensor ((Grand Santa Fe, NC))

Replacing engine parts ((Grand Santa Fe, NC))

Calibrating the camera and radar system ((Grand Santa Fe, NC))

Resetting EGR valve learning values ((Tucson, TL))

Adapting the accelerator sensor ((Tucson, TL), (ix35, EL), (i40 / i40cw, VF), (i30 / i30cw, PD), (Kona, OS))

Resetting adaptation values of ABS ECU ((Tucson, TL))

Bleeding the brake system ((Grand Santa Fe, NC), (Tucson, TL), (Santa Fe, TM))

Resetting the swirl flap adaptation values ((i30 / i30cw, FD))

Configuring the lane change assist ((Grand Santa Fe, NC))

Learning the RDC sensors ((i10, AC3))

De/activating the parking brake service mode ((i30 / i30cw, PD), (Tucson, TL))

Resetting throttle valve adaptation values ((i20, PB), (Grandeur / Azera, IG))

Replacing the particle filter ((i30 / i30cw, PD), (Tucson, TL), (Kona, OS))

Calibrating the camera ECU ((Grand Santa Fe, NC))

Bleeding the ABS hydraulic unit ((Santa Fe, CM), (i30 / i30cw, GD))

Initializing ride height sensors ((Grand Santa Fe, NC))

Codings

Coding the tire pressure check ((Grand Santa Fe, NC))

Coding the power steering ECU ((Grand Santa Fe, NC))

Adapting the power steering after replacement ((Grand Santa Fe, NC))

Coding the wheel valves ((Grand Santa Fe, NC), (Tucson, TL))

Service resets

(Grand Santa Fe, NC), (Tucson, TL)



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

Jaguar

Trouble codes

Parameters

Actuators

Basic settings

Adapting the longitudinal acceleration sensor ((F-Type, X152), (XJ, X351))
Resetting throttle valve adaptation values ((XF, X250), (XJ, X351), (XE, X760), (XF, X260))
Resetting transfer case adaptation values ((F-Pace, DC))
Activating the service mode ((F-Pace, X761), (XF, X260))
De/activating the parking brake service mode ((F-Pace, X761), (F-Pace, DC))
Adapting the induction system ((XF, X260))
Adjusting the headlights ((XE, X760), (F-Pace, X761), (XF, X260), (F-Pace, DC))
Learning the throttle valve ((F-Type, X152))
Initializing the A/C flap actuators ((E-Pace, X540))
Initializing the tilt/slide sunroof ((XE, X760), (F-Pace, X761), (F-Pace, DC))
Learning the power windows ((XK, X150), (F-Type, X152), (XF, X260), (F-Pace, X761), (F-Type, QQ6))
Resetting gearbox learning values ((XJ, X351))
Bleeding the brake system ((X-Type, X400))
Calibrating the camera ECU ((E-Pace, X540))
Resetting the swirl flap adaptation values ((F-Pace, X761), (XF, X260), (E-Pace, X540), (F-Pace, DC))
Bleeding the fuel system ((F-Pace, X761))
Resetting differential pressure sensor learning values ((F-Pace, X761), (XF, X260))
Reset the learned values of the presupply pump. ((F-Pace, X761))
Resetting oxygen sensor adaptation values ((XE, X760))

Codings

Service resets



Diagnostic devices

DolP/CAN	(E-Pace, X540), (F-Pace, DC)
Capable for diagnostics only with mega macs X	
Cyber Security Management (CSM)	
Capable for diagnostics only with Cyber Security Management	
Jeep	
Trouble codes	(Renegade (BV), BV)
Parameters	(Renegade (BV), BV)
Actuators	(Renegade (BV), BV)
Basic settings	Initializing the adaptive cruise control ((Renegade (BV), BV)) De/activating the parking brake service mode ((Renegade (BV), BV)) Initializing the air distribution flaps ((Renegade (BV), BV)) Adapting the clutch biting point ((Renegade (BU), BU)) Learning the steering-angle sensor ((Renegade (BV), BV)) Initializing the crankshaft position ((Renegade (BU), BU)) Calibrating the camera ECU ((Renegade (BV), BV)) Resetting differential pressure sensor learning values ((Renegade (BU), BU)) Learning the lambda sensor ((Renegade (BU), BU)) Resetting learned values of the oxidation catalyst ((Renegade (BU), BU)) Resetting transfer case adaptation values ((Grand Cherokee, WK,WK2), (Grand Cherokee, WK), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2)) Bleeding the ABS hydraulic unit ((Wrangler, JK), (Commander, XK,XH), (Compass (MK), MK)) Resetting learned values of NOx adsorption catalyst ((Wrangler, JK)) Resetting gearbox learning values ((Compass (MK), MK), (Patriot, MK), (Grand Cherokee, WK,WK2), (Grand Cherokee, WK), (Renegade (BU), BU), (Patriot, PK), (Grand Cherokee, EK,WK2), (Grand Cherokee, Wk,WK2)) Initializing the brake-pressure sensor ((Renegade (BV), BV)) Resetting the pulse-generator ring adaptation ((Renegade (BU), BU))
Codings	Coding the trailer detection ((Renegade (BV), BV)) Deactivating the transport mode ((Renegade (BV), BV)) Coding the tire pressure sensor ID ((Renegade (BV), BV))
Service resets	(Renegade (BV), BV)



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM) (Renegade (BV), BV)

Capable for diagnostics
only with Cyber Security
Management

Kia

Trouble codes (Cee'd / Pro Cee'd, CD), (Rio, YB), (Sorento, MQ4), (Soul, SK3 EV), (Stinger, CK)

Parameters (Rio, YB)

Actuators (Rio, YB)

Basic settings Learning the steering-angle sensor ((Soul, AM), (Soul, PS EV), (Picanto, JA), (Stinger, CK), (Stonic, YB))

Resetting the tire pressure monitoring ((Rio, YB), (Stonic, YB))

Resetting engine adaptation values ((Picanto, BA/SA), (Sportage, KM), (Rio, JB), (Cee'd / Pro Cee'd, ED), (Carens, FJ), (Soul, AM), (Venga, YN), (Sportage, SL), (Rio, UB), (Cee'd / Pro Cee'd, JD), (Carens, RP), (Sportage, QL), (Cee'd / Pro Cee'd, CD), (Diverse, SL))

Learning the lambda sensor ((Carens, UN))

Adapting the swirl control valve ((Rio, UB), (Soul, PS))

Initializing the EGR valve ((Rio, UB), (Soul, PS), (Sportage, SL))

Bleeding the fuel system ((Sorento, UM), (Stonic, YB))

Initializing the fuel high-pressure sensor ((Carens, UN))

Initializing the swirl control valve ((Sorento, UM), (Sorento, XM))

Initializing the mass airflow sensor ((Cee'd / Pro Cee'd, ED), (Sportage, SL), (Optima, TF), (Carens, RP), (Soul, PS))

Initializing the ABS/ESC system ((Cee'd / Pro Cee'd, ED))

Learning the steering-angle sensor ((Stinger, CK))

Learning the throttle valve ((Carens, RP), (Sorento, UM), (Sportage, QL), (Optima, JF))

Regenerating the soot particulate filter ((Sorento, UM), (Cee'd / Pro Cee'd, CD))

Resetting gearbox learning values ((Soul, AM), (Sorento, XM), (Optima, TF), (Sorento, UM), (Sportage, QL), (Rio, YB), (Stinger, CK))

Resetting rail pressure ((Sorento, UM), (Sorento, XM))

Resetting differential pressure sensor learning values ((Sportage, KM), (Cee'd / Pro Cee'd, ED), (Carens, UN))

Bleeding the brake system ((Soul, AM), (Carens, FJ), (Carens, UN), (Rio, UB), (Carens, RP))



Diagnostic devices

Resetting the swirl flap adaptation values ((Soul, AM), (Sportage, KM), (Carens, UN), (Sorento, XM), (Venga, YN), (Sportage, SL))

De/activating the parking brake service mode ((Carens, RP), (Sorento, UM), (Soul, PS EV), (Sportage, QL))

Resetting throttle valve adaptation values ((Rio, UB), (Sportage, SL))

Calibrating the cornering light ((Sorento, UM))

Resetting mass airflow sensor adaptation values ((Carens, UN))

Replacing the particle filter ((Sportage, SL), (Rio, UB), (Cee'd / Pro Cee'd, CD))

Calibrating the camera ECU ((Cee'd / Pro Cee'd, JD))

Initializing the EGR valve ((Carens, RP), (Sportage, QL), (Optima, JF), (Stinger, CK))

Bleeding the ABS hydraulic unit ((Rio, BC), (Magentis, GD), (Carens, FJ), (Picanto, BA/SA), (Sportage, KM), (Rio, JB), (Magentis, MG), (Carens, UN), (Optima,), (Sorento, BL), (Sorento, XM))

Codings

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

Land-Rover

Trouble codes

Parameters

Actuators

Basic settings

Adapting the longitudinal acceleration sensor ((Range Rover-III (L32, L322), (Discovery-III (L319), L319), (Range Rover Sport (L, L320)))

Initializing the brake-pressure sensor ((Range Rover Evoque-I, L538), (Discovery Sport (L55, L550)))

Initializing the lateral acceleration sensor ((Range Rover Evoque-I, L538))

Learning the steering-angle sensor ((Range Rover-III (L32, L322), (Discovery-III (L319), L319), (Range Rover Sport (L, L320), (Freelander-II (L359), L359), (Discovery-IV (L319), L319), (Range Rover Evoque-I, L538), (Range Rover-IV (L405, L405), (Range Rover Sport (L, L494), (Discovery Sport (L55, L550), (Discovery-V (L462), L462), (Range Rover Evoque-I, L551))))



Diagnostic devices

Resetting oxygen sensor adaptation values ((Range Rover-III (L32, L322), (Range Rover Sport (L, L320), (Range Rover Evoque-I, L538), (Freelander-II (L359), L359), (Range Rover-IV (L405, L405), (Range Rover Sport (L, L494))

Activating the fuel pump ((Freelander-II (L359), L359), (Range Rover-IV (L405, L405), (Range Rover Evoque-I, L551))

Resetting learned values of fuel quantity ((Range Rover-IV (L405, L405))

Learning the power windows ((Range Rover-IV (L405, L405), (Range Rover Evoque-I, L551))

Reset the learned values of the presupply pump. ((Range Rover-III (L32, L322), (Range Rover Sport (L, L320), (Discovery-IV (L319), L319), (Range Rover Evoque-I, L538), (Range Rover-IV (L405, L405), (Range Rover Sport (L, L494), (Discovery Sport (L55, L550))

Filling/bleeding the cooling system ((Range Rover Velar, L560))

Resetting suspension parameters ((Range Rover-III (L32, L322))

Resetting the particulate filter learning values ((Range Rover-IV (L405, L405), (Range Rover Sport (L, L494))

Resetting learned values of the oxidation catalyst ((Range Rover-IV (L405, L405), (Range Rover Sport (L, L494))

Initializing the yaw rate sensor ((Freelander-II (L359), L359))

Adjusting the ride height ((Range Rover-IV (L405, L405), (Range Rover Evoque-I, L551))

Performing the initial run-in of the air conditioning compressor ((Defender-III, LE663))

Resetting differential pressure sensor learning values ((Range Rover-IV (L405, L405))

Initializing the A/C flap actuators ((Range Rover-IV (L405, L405), (Range Rover Sport (L, L494))

Calibrating the front camera ((Range Rover Velar, L560))

De/activating the parking brake service mode ((Freelander-II (L359), L359))

Regenerating the soot particulate filter during driving ((Range Rover-III (L32, L322), (Range Rover-IV (L405, L405), (Range Rover Sport (L, L494))

Resetting throttle valve adaptation values ((Range Rover-IV (L405, L405))

Codings

Service resets

DolP/CAN

((Range Rover-IV (L405, L405), (Range Rover Velar, L560), (Defender-III, LE663), (Range Rover Evoque-I, L551))

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management



Diagnostic devices

Lexus

Trouble codes	
Parameters	
Actuators	
Basic settings	<p>Resetting adaptation values of ABS ECU ((GS, GWL10), (RX, AGL20), (ES, ASV61), (ES, ASV), (ES, GSV40), (GS, AWL10), (GS, GRS196), (GX, GRJ150), (GX, GRJ), (IS, GSE30), (IS, GSE35), (RX, AGL25))</p> <p>Calibrating the camera ECU ((CT, ZWA10), (GS, ARL10), (RC, ASC10L), (RC, GSC16), (LC, GWZ100))</p> <p>Adjusting the headlights ((RC, USC10))</p> <p>Initializing the A/C flap actuators ((LX, UZJ100), (IS, ALE20), (RX, MHU38), (IS, GSE30), (IS, GSE20), (IS, AVE30), (GS, GRL15), (LX, URJ201), (LS, USF40), (LS, UVF45), (NX, AGZ10L), (LS, USF45), (RX, GGL15), (RX, GSU35), (RX, GYL10), (RX, GYL15), (GS, GRL11), (CT, ZWA10), (GS, GWL10), (LFA, LFA10), (LS, UVF46), (RC, GSC10), (GS, AWL10), (RC, USC10), (NX, AGZ15L), (ES, ASV60), (ES, AVV60), (RC, AVC10L), (IS, ASE30), (RC, ASC10L), (GS, ARL10), (GS, GRL12), (GS, GRL16), (HS, ANF10), (RX, GGL20), (RX, GGL25), (RX, GYL20), (RX, GYL25), (RX, AGL20), (GS, URL10), (IS, GSE35), (ES, ASV61), (ES, ASV), (ES, MCV30), (ES, MCV31), (ES, GSV60), (ES, GSV40), (GX, GRJ150), (GX, GRJ), (IS, GSE26), (LC, URZ100), (LS, GVF50), (RC, GSC15), (LS, GVF55L), (IS, GSE37), (RC, GSC16), (GX, URJ150), (IS, GSE), (LC, GWZ100), (LS, USF50), (RX, AGL25), (LS, VXFA55L), (LS, GSF50), (LX, URJ202), (LX, VDJ201), (RC, USC10L), (RX, GYL25, GYL26), (LS, USF40, USF41), (RX, AGL10), (UX, MZAA10), (UX, MZAH15), (ES, AXZH10), (RX, GYL26), (IS, GSE3), (UX, KMA10))</p>
Codings	
Service resets	
DoIP/CAN	(ES, AXZH10)
Capable for diagnostics only with mega macs X	
Cyber Security Management (CSM)	
Capable for diagnostics only with Cyber Security Management	

MAN

Trouble codes	
Parameters	
Actuators	
Basic settings	Performing maintenance work on the refrigerant circuit ((TGE, UY))



Diagnostic devices

Codings

Service resets

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

Mazda

Trouble codes (B-Series/Truck, UN), (CX-30, DM)

Parameters (B-Series/Truck, UN), (CX-30, DM)

Actuators (CX-30, DM)

Basic settings Adapting the longitudinal acceleration sensor ((Mazda 3, BM), (Mazda 3, BL), (Mazda 6, GL), (CX-5, KF), (MX-5, ND), (Mazda 3, BN), (Mazda 6, GJ,GL), (Mazda 6, GJ), (CX-30, DM))

Initializing the lateral acceleration sensor ((Mazda 2, DJ), (CX-3, DK), (Mazda 3, BM), (Mazda 3, BN), (MX-5, ND), (Mazda 6, GL), (Mazda 6, GJ,GL), (Mazda 6, GJ), (Mazda 3, BP), (CX-30, DM), (Mazda 2, DJ1), (MX-30, DR))

Initializing the brake-pressure sensor ((Mazda 3, BM), (Mazda 3, BN), (Mazda 3, BL), (Mazda 6, GL), (CX-5, KF), (MX-5, ND), (Mazda 6, GJ,GL), (Mazda 6, GJ), (MX-30, DR), (CX-30, DM))

Resetting engine adaptation values ((Mazda 3, BN))

De/activating the parking brake service mode ((CX-30, DM))

Resetting oxygen sensor adaptation values ((Mazda 3, BM), (Mazda 3, BN), (CX-5, KF))

Initializing the differential pressure sensor ((Mazda 3, BL), (CX-5, GH,KE), (Mazda 6, GL), (Mazda 6, GJ,GL))

Resetting mass airflow sensor adaptation values ((Mazda 3, BN))

Calibrating front radar sensors ((CX-30, DM))

Learning the turbocharger ((Mazda 3, BN))

Learning the throttle valve ((Mazda 3, BN), (CX-5, GH,KE), (CX-5, KF))

Learning the steering-angle sensor ((Mazda 6, GJ), (Mazda 6, GL), (Mazda 6, GJ,GL))

Resetting the particulate filter learning values ((Mazda 3, BN))

Calibrating rear radar sensors ((CX-30, DM))

Regenerating the soot particulate filter ((Mazda 3, BN))

Initializing the yaw rate sensor ((CX-7, ER))

Initializing the yaw rate sensor ((CX-5, GH,KE), (CX-30, DM))



Diagnostic devices

Resetting the soot load compensation ((Mazda 3, BN))
Reset learned values of injectors. ((Mazda 3, BM), (Mazda 3, BN), (CX-5, KF))
Initializing the adaptive cruise control ((MX-30, DR), (CX-30, DM))
Resetting EGR valve learning values ((Mazda 3, BK))
Calibrating the camera ((CX-30, DM))
Calibrating the camera ECU ((CX-30, DM))
Initializing the EGR valve ((Mazda 2, DJ), (CX-3, DK), (Mazda 3, BN), (Mazda 3, BM,BN), (Mazda 6, GJ), (Mazda 6, GL), (Mazda 6, GJ,GL))
Adapting the injection quantity ((Mazda 3, BN))
Reset fuel pump learning values ((Mazda 3, BM), (Mazda 3, BN), (CX-5, KF))
Resetting headlight leveling adaptation values ((CX-30, DM))

Codings

Coding injectors ((Mazda 3, BN))
Adjusting the engine oil monitoring function ((Mazda 3, BN))

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

Mercedes

Trouble codes (AMG GT, 190377), (AMG GT, 290659), (C-Klasse, 205477), (C-Klasse, 205009), (C-Klasse, 206245), (Citan, 420653,420753), (G-Klasse, 463277), (GLC-Klasse, 253905), (GLC-Klasse, 254651), (GLE-Klasse, 167119), (GLS-Klasse, 167921), (T-Klasse, 420853)

Parameters (AMG GT, 190377), (AMG GT, 290659), (C-Klasse, 206245), (E-Klasse, 238342), (GLC-Klasse, 254651), (GLE-Klasse, 167354), (S-Klasse, 223030,223130)

Actuators (AMG GT, 190377), (AMG GT, 290659), (GLE-Klasse, 167354)

Basic settings Learning the steering-angle sensor ((SLS-Klasse, 197377), (Sprinter, 906731,906733,906735), (Sprinter, 906611,906613), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906653,906655,906657), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906155,906253,906255), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906113,906213,906613,906713), (Sprinter, 906), (ML-Klasse, 164124,164125), (ML-Klasse, 164128), (ML-Klasse, 164177), (S-Klasse, 221179), (C-Klasse, 204200), (E-Klasse, 212072), (C-Klasse, 204077), (ML-Klasse, 164122), (E-Klasse, 212103), (E-Klasse, 212172), (E-Klasse, 212020,212021,212027), (E-Klasse, 211254), (E-Klasse, 207425), (E-Klasse,



Diagnostic devices

207472), (E-Klasse, 207348), (E-Klasse, 207301,207302), (E-Klasse, 207302), (E-Klasse, 207303,207304), (E-Klasse, 207347), (E-Klasse, 207422), (E-Klasse, 207322), (E-Klasse, 212256), (E-Klasse, 212205,212206), (E-Klasse, 212248), (E-Klasse, 212201,212202), (E-Klasse, 212202), (E-Klasse, 212203), (E-Klasse, 212247), (E-Klasse, 212254), (E-Klasse, 212225), (E-Klasse, 212224), (E-Klasse, 212257), (E-Klasse, 212272), (E-Klasse, 212289), (E-Klasse, 212221,212227), (E-Klasse, 212287), (E-Klasse, 212005,212006), (E-Klasse, 212048,212148), (E-Klasse, 212001,212002), (E-Klasse, 212047,212147), (E-Klasse, 212052), (E-Klasse, 212024), (E-Klasse, 212077), (E-Klasse, 212089), (E-Klasse, 212087), (E-Klasse, 212090), (C-Klasse, 204282), (C-Klasse, 204292), (C-Klasse, 204082), (C-Klasse, 204092), (E-Klasse, 207448), (E-Klasse, 207401,207402), (E-Klasse, 207402), (E-Klasse, 207403,207404), (E-Klasse, 207447), (E-Klasse, 212220), (C-Klasse, 204203), (C-Klasse, 204247), (C-Klasse, 204220), (C-Klasse, 204225), (C-Klasse, 204277), (C-Klasse, 204223), (C-Klasse, 204000), (C-Klasse, 204047), (C-Klasse, 204022), (S-Klasse, 221028,221128), (GLK-Klasse, 204901), (GLK-Klasse, 204984,204997), (GLK-Klasse, 204984), (GLK-Klasse, 204982,204904), (GLK-Klasse, 204981), (GLK-Klasse, 204992), (GLK-Klasse, 204983), (R-Klasse, 251121,251026,251126), (Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,906733,906735), (Sprinter, 906631,906633,906635,906637,906131,906133,906135,906231,906235,906233,906731,906735,906735), (C-Klasse, 204086), (C-Klasse, 204286), (E-Klasse, 212025), (GLK-Klasse, 204999), (E-Klasse, 207473), (E-Klasse, 212284), (C-Klasse, 204257), (C-Klasse, 204349), (C-Klasse, 204302), (E-Klasse, 207373), (SLS-Klasse, 197477), (E-Klasse, 210253), (E-Klasse, 212280), (E-Klasse, 212288), (E-Klasse, 212291), (E-Klasse, 212059), (C-Klasse, 204080), (C-Klasse, 204088), (C-Klasse, 204055), (C-Klasse, 204023), (E-Klasse, 212259), (GLK-Klasse, 204988), (Sprinter, 906633,906635), (Sprinter, 906613), (Sprinter, 906655,906657,906653), (Sprinter, 906711,906713), (E-Klasse, 212223), (Sprinter, 906111,906113,906211,906213,906611,906613), (ML-Klasse, 166074), (C-Klasse, 204020), (C-Klasse, 204388), (SLS-Klasse, 197378), (SLS-Klasse, 197478), (E-Klasse, 212234), (E-Klasse, 212236), (E-Klasse, 212276), (E-Klasse, 212204), (E-Klasse, 212275), (E-Klasse, 212273), (E-Klasse, 212098), (E-Klasse, 212255), (E-Klasse, 212226), (E-Klasse, 212294), (E-Klasse, 212026), (E-Klasse, 207336), (C-Klasse, 204284), (C-Klasse, 204084), (GLK-Klasse, 204904,204982), (E-Klasse, 212094), (E-Klasse, 212088), (E-Klasse, 212091), (E-Klasse, 212075), (E-Klasse, 212036), (E-Klasse, 212034), (GLK-Klasse, 204937), (GLK-Klasse, 204990), (GLK-Klasse, 204993), (E-Klasse, 212167), (E-Klasse, 212084), (GLK-Klasse, 204986), (GLA-Klasse, 156908), (GLA-Klasse, 156943), (GLA-Klasse, 156903), (GLA-Klasse, 156944), (GLA-Klasse, 156902), (GLA-Klasse, 156905), (GLA-Klasse, 156946), (E-Klasse, 207334), (E-Klasse, 207365), (GLK-Klasse, 204934), (GLK-Klasse, 204936), (E-Klasse, 212065), (E-Klasse, 212040), (E-Klasse, 212076), (E-Klasse, 212092), (Sprinter, 906733,906731,906735), (Sprinter, 906111,906113,906211,906213,906611,906613,906711,906613), (E-Klasse, 212165), (E-Klasse, 212003), (E-Klasse, 212067), (E-Klasse, 212199), (E-Klasse, 212299), (E-Klasse, 212261), (E-Klasse, 212265), (E-Klasse, 212099), (E-Klasse, 212061), (E-Klasse, 212001), (E-Klasse, 212104), (E-Klasse, 212173), (E-Klasse, 212292), (E-Klasse, 212267), (E-Klasse, 212161), (E-Klasse, 212027,212227), (E-Klasse, 212004), (E-Klasse, 207461), (E-Klasse, 207465), (E-Klasse, 207426), (E-Klasse, 207436), (E-Klasse, 207434), (E-Klasse, 207401), (E-Klasse, 207301), (E-Klasse, 207326), (E-Klasse, 207361), (GL-Klasse, 166874), (Sprinter, 906133,906131,906135,906231,906233,906235), (C-Klasse, 205009), (C-Klasse, 205066), (C-Klasse, 205040), (C-Klasse, 205036), (C-Klasse, 205042), (C-Klasse, 205007), (C-Klasse, 205012), (C-Klasse, 205006), (C-Klasse, 205045), (C-Klasse, 205002), (C-Klasse, 205204), (C-Klasse, 205240), (C-Klasse, 205044), (C-Klasse, 205236), (C-Klasse, 205037), (C-Klasse, 205004), (C-Klasse, 205003), (C-Klasse, 205008), (C-Klasse, 205048), (E-Klasse, 212011,212111), (GLE-Klasse, 166062), (GLE-Klasse, 166024), (GLE-Klasse, 166056), (GLE-Klasse, 166064), (GLE-Klasse, 166063), (GLE-Klasse, 292323,292324), (GLE-Klasse, 292356), (GLE-Klasse, 292364), (GLE-Klasse, 292373), (GLE-Klasse, 292374), (GLE-Klasse, 292375), (C-Klasse, 205247), (C-Klasse, 205207), (C-Klasse, 205287), (C-Klasse, 205087), (G-Klasse, 463224,463225), (G-Klasse, 463227,463228), (C-Klasse, 205208), (G-Klasse, 463204), (G-Klasse, 463207), (G-Klasse, 463300), (G-Klasse, 463320,463321), (G-Klasse, 461238,461239), (C-Klasse, 202078), (C-Klasse, 202022), (C-Klasse, 202028), (C-Klasse,



Diagnostic devices

202120), (C-Klasse, 202125), (C-Klasse, 202121,202182), (C-Klasse, 202020), (C-Klasse, 205209), (C-Klasse, 205266), (C-Klasse, 205237), (C-Klasse, 205212), (GLC-Klasse, 253905), (GLC-Klasse, 253946), (GLC-Klasse, 253909), (GLC-Klasse, 253949), (GLC-Klasse, 253954), (C-Klasse, 205342), (C-Klasse, 205304), (C-Klasse, 205345), (C-Klasse, 205308), (C-Klasse, 205348), (C-Klasse, 205043), (C-Klasse, 205005), (C-Klasse, 205064), (C-Klasse, 205264), (C-Klasse, 205205), (C-Klasse, 205243), (C-Klasse, 205448), (C-Klasse, 205464), (C-Klasse, 205466), (C-Klasse, 205405), (C-Klasse, 205443), (C-Klasse, 205408), (C-Klasse, 205445), (C-Klasse, 205404), (C-Klasse, 205440), (C-Klasse, 205442), (C-Klasse, 205340), (C-Klasse, 205343), (C-Klasse, 205305), (C-Klasse, 205309), (C-Klasse, 205366), (C-Klasse, 205364), (GLC-Klasse, 253964), (GLC-Klasse, 253303,253305), (GLC-Klasse, 253309), (GLC-Klasse, 253301), (GLC-Klasse, 253325), (GLC-Klasse, 253346), (GLC-Klasse, 253349), (GLC-Klasse, 253364), (GLC-Klasse, 253354), (GLC-Klasse, 253904), (GLC-Klasse, 253901), (GLE-Klasse, 292362), (C-Klasse, 205242), (C-Klasse, 205245), (E-Klasse, 212211), (GLA-Klasse, 156947), (V-Klasse, 448813), (V-Klasse, 448815), (V-Klasse, 448705), (Sprinter, 906735,906737), (Sprinter, 906153,906155,906253,906255,906653,906655,906657), (GLC-Klasse, 253323), (C-Klasse, 205054), (GLC-Klasse, 253923), (GLC-Klasse, 253319), (C-Klasse, 205140), (C-Klasse, 205286), (G-Klasse, 463208), (C-Klasse, 202024,202085), (E-Klasse, 210004), (Sprinter, 902011,902012,902061,902062,902071,902072), (Sprinter, 903011,903012,903013,903022,903061,903062,903063,903071,903072,903073), (Sprinter, 904062,904063,904662,904663), (Sprinter, 904012,904013,904062,904063), (E-Klasse, 210035), (E-Klasse, 210055), (V-Klasse, 638114,638014), (C-Klasse, 202128,202188), (Sprinter, 901061,901062,902061,902062), (Sprinter, 901361,901362,902361,902362), (Sprinter, 901421,901461,901462,902411,902412,902421,902422,902461,902462,902471,902472), (Sprinter, 903311,903312,903313,903321,903322,903323,903361,903362,903363,903371,903372,903373), (Sprinter, 903411,903412,903413,903421,903422,903423,903461,903462,903463,903471,903472,903473), (Sprinter, 904412,904413,904422,904423,904462,904463), (Sprinter, 904312,904313,904322,904323,904362,904363), (E-Klasse, 210010), (E-Klasse, 210020), (C-Klasse, 202182,202121), (C-Klasse, 202188), (E-Klasse, 210017), (V-Klasse, 638064,638164), (V-Klasse, 638074,638174), (E-Klasse, 210053), (E-Klasse, 210272), (E-Klasse, 210037), (E-Klasse, 210065), (E-Klasse, 210063), (E-Klasse, 210081), (E-Klasse, 210082), (E-Klasse, 210025), (C-Klasse, 202080), (C-Klasse, 202083), (C-Klasse, 202025,202082), (C-Klasse, 202085), (C-Klasse, 202089), (SLK-Klasse, 170435), (SLK-Klasse, 170447), (CLK-Klasse, 208335), (CLK-Klasse, 208445,208345), (CLK-Klasse, 208347,208447), (CLK-Klasse, 208365), (G-Klasse, 463330,463331), (E-Klasse, 210217), (V-Klasse, 638114,638194), (V-Klasse, 638214,638294), (V-Klasse, 638034,638134), (E-Klasse, 210282), (E-Klasse, 210265), (E-Klasse, 210225), (C-Klasse, 202024), (C-Klasse, 202082), (G-Klasse, 463230,463231), (Sprinter, 901311,901312,901321,901361,901362,901371,902311,902312,902321,902322,902361,902362,902371,902372), (E-Klasse, 210072), (E-Klasse, 210235), (E-Klasse, 210237), (E-Klasse, 210210), (Sprinter, 902071,902072,902073,902671,902672,902673), (Sprinter, 904462,904463), (C-Klasse, 202122), (E-Klasse, 210281), (C-Klasse, 202086), (C-Klasse, 202029), (A-Klasse, 168008), (A-Klasse, 168031), (A-Klasse, 168033), (E-Klasse, 210015), (E-Klasse, 210215), (E-Klasse, 210061), (E-Klasse, 210070), (E-Klasse, 210074), (C-Klasse, 202093), (C-Klasse, 202133,202193), (G-Klasse, 463209,463250), (G-Klasse, 463232,463233,463244,463245), (ML-Klasse, 163136), (ML-Klasse, 163154), (CLK-Klasse, 208370), (E-Klasse, 210007), (E-Klasse, 210006), (E-Klasse, 210206), (G-Klasse, 463206,463254), (G-Klasse, 463240,463241,463247,463248,463249), (V-Klasse, 638174), (Sprinter, 901061,901062,902011,902012,902061,902062,902071,902072), (E-Klasse, 210263), (E-Klasse, 210283), (A-Klasse, 168007), (E-Klasse, 210261), (E-Klasse, 210270), (E-Klasse, 210045), (E-Klasse, 210245), (E-Klasse, 210274), (S-Klasse, 220065,220165), (S-Klasse, 220070,220170), (S-Klasse, 220075,220175,220875), (ML-Klasse, 163172), (CLK-Klasse, 208447), (ML-Klasse, 166003,166004), (SLK-Klasse, 170445), (S-Klasse, 220063,220163), (ML-Klasse, 166024), (G-Klasse, 463308), (Sprinter, 903371,903372,903373), (Sprinter, 903011,903012,903013,903022), (Sprinter, 902011,902012,902071,902072,902611,902612,902711,902712), (A-Klasse, 168032), (CLK-



Diagnostic devices

Klasse, 208447,208347), (CLK-Klasse, 208345,208445), (Sprinter, 903061,903062,903063), (E-Klasse, 210216), (E-Klasse, 210226), (CLK-Klasse, 208374), (CL-Klasse, 215375), (CL-Klasse, 215378), (S-Klasse, 220026,220126), (S-Klasse, 220178,220878), (E-Klasse, 210083), (ML-Klasse, 163174), (Sprinter, 903461,903462,903463), (Sprinter, 903061,903062,903063,903661,903662,903663), (Sprinter, 904012,904013,904612,904613), (V-Klasse, 638274), (Sprinter, 903471,903472,903473), (E-Klasse, 210016), (E-Klasse, 210026), (ML-Klasse, 163113), (C-Klasse, 203004), (C-Klasse, 203008,203708), (C-Klasse, 203045,203745), (C-Klasse, 203261), (C-Klasse, 203064), (S-Klasse, 220028,220128), (Sprinter, 903), (CLK-Klasse, 208448), (CLK-Klasse, 208344), (C-Klasse, 203735), (CLK-Klasse, 208444), (CLK-Klasse, 208348), (Sprinter, 904012,904013,904662,904663), (CLK-Klasse, 208474), (ML-Klasse, 166057), (V-Klasse, 638294), (S-Klasse, 220073,220173), (SLK-Klasse, 170465), (SLK-Klasse, 170444), (SLK-Klasse, 170449), (Sprinter, 901421,902411,902412,902421,902421), (Sprinter, 901461,901462,901461,902462), (Sprinter, 903311,903312,903313,903321,903322,903323), (Sprinter, 903472), (Sprinter, 901421,901461,901462,902411,902412,902422,902461,902462,902471,902472), (Sprinter, 904412,904413,903422,903423,904462,904463), (Sprinter, 904412,904413,904422,904422,904423), (Sprinter, 903463), (Sprinter, 904412,904413,904422,904422,904423), (Sprinter, 903462), (Sprinter, 901611,901612,901671,901621,901661,901662,902621,902622,902611,902612,902662,902671,902672), (Sprinter, 902621,902622,902611,902612,902661,902662,902671,902672), (V-Klasse, 638194,638094), (V-Klasse, 638094,638194), (C-Klasse, 202194,202134), (E-Klasse, 210262), (E-Klasse, 211070), (E-Klasse, 211065), (E-Klasse, 211061), (E-Klasse, 211016), (E-Klasse, 211006), (SL-Klasse, 230474), (SL-Klasse, 230475), (VANEO, 414700), (G-Klasse, 463332,463333), (G-Klasse, 463309,463332,463333), (G-Klasse, 463322,463323), (G-Klasse, 463243,463246), (ML-Klasse, 163128), (ML-Klasse, 163175), (ML-Klasse, 166073), (Sprinter, 903621,903623,903622,903611,903612,903613,903661,903662,903663,903671,903672,903673), (C-Klasse, 202021), (C-Klasse, 202182), (Sprinter, 903411,90342,903413,903421,903422,903423,903461,903462,903463,903471,903472,903473), (CL-Klasse, 215373), (Sprinter, 904622,904623,904612,904613,904662,904663), (Sprinter, 904612), (C-Klasse, 203016), (E-Klasse, 210048), (E-Klasse, 210062), (E-Klasse, 210248), (C-Klasse, 203006,203706), (C-Klasse, 203747), (SLK-Klasse, 170466), (C-Klasse, 203065), (C-Klasse, 203265), (C-Klasse, 203264), (C-Klasse, 203245), (C-Klasse, 203216), (C-Klasse, 203206), (C-Klasse, 203204), (A-Klasse, 168006), (A-Klasse, 168009,168109), (C-Klasse, 203204,203207), (C-Klasse, 203208), (A-Klasse, 168035,168135), (CLK-Klasse, 209342), (CLK-Klasse, 209361), (CLK-Klasse, 209365), (CLK-Klasse, 209375), (C-Klasse, 203046,203746), (C-Klasse, 203042,203742), (C-Klasse, 203246), (C-Klasse, 203242), (C-Klasse, 203040,203740), (CL-Klasse, 215374), (CL-Klasse, 215376), (S-Klasse, 220067,220167), (S-Klasse, 220074,220174), (S-Klasse, 220176), (S-Klasse, 220025,220125), (S-Klasse, 220083,220183), (S-Klasse, 220084,220184), (C-Klasse, 203718,203018), (C-Klasse, 203081), (C-Klasse, 203084), (C-Klasse, 203218), (C-Klasse, 203281), (C-Klasse, 203284), (C-Klasse, 203018,203718), (CLK-Klasse, 209316), (CLK-Klasse, 209343), (CLK-Klasse, 209376), (E-Klasse, 211026), (E-Klasse, 211042), (E-Klasse, 211076), (SL-Klasse, 230467), (Sprinter, 901611,901612,901671,901621,901661,901662,901621,902622,902611,902612,902662,902671,902672), (Sprinter, 901661,901662,902661,902662), (Sprinter, 903011,903012,903013,903022,903071,903072,903073,903611,903612,903613,903622,90371,903772,903773), (Sprinter, 901671,901621,901661,901662,902621,902611,902612,902661,902662,902671,902672), (Sprinter, 902611,902612), (Sprinter, 903611,903612,903613,903621,903622,903623), (Sprinter, 903621,903623,903622,903611,903612,903612,903613,903661,903662,903663,903671,903672,903673), (Sprinter, 905612,905613,905622,905623), (V-Klasse, 638194), (S-Klasse, 220087,220187), (SL-Klasse, 230476), (E-Klasse, 211206), (E-Klasse, 211216), (E-Klasse,



Diagnostic devices

211261), (E-Klasse, 211028), (C-Klasse, 203207), (C-Klasse, 203007), (C-Klasse, 203707), (E-Klasse, 211080), (E-Klasse, 211082), (E-Klasse, 211083), (E-Klasse, 211280), (E-Klasse, 211282), (E-Klasse, 211283), (E-Klasse, 211276), (CLK-Klasse, 209442), (CLK-Klasse, 209443), (CLK-Klasse, 209465), (E-Klasse, 211226), (E-Klasse, 211270), (E-Klasse, 211265), (E-Klasse, 211242), (C-Klasse, 203043, 203743), (C-Klasse, 203243), (ML-Klasse, 163157), (C-Klasse, 203764), (V-Klasse, 639711, 639713, 639811, 639813, 639815), (Sprinter, 902471, 902472), (Sprinter, 902471, 902472, 902473), (Sprinter, 903411, 903412, 903413, 903421, 903422, 903423), (Sprinter, 901471, 901472, 901473, 902471, 902472, 902473), (E-Klasse, 210003), (E-Klasse, 211004), (C-Klasse, 203006), (A-Klasse, 168032, 168132), (A-Klasse, 168033, 168133), (A-Klasse, 168031, 168131), (C-Klasse, 202087), (C-Klasse, 202088), (C-Klasse, 202081), (Sprinter, 903611, 903612, 903613, 903622), (Sprinter, 903661, 903662, 903663), (V-Klasse, 638234), (C-Klasse, 203708), (V-Klasse, 639601, 639603, 639605), (V-Klasse, 639701), (V-Klasse, 639701, 639703, 639705), (E-Klasse, 211223), (E-Klasse, 211023), (V-Klasse, 639711, 639811), (V-Klasse, 639713, 639813, 639815), (SLK-Klasse, 171442), (C-Klasse, 203240), (C-Klasse, 203040), (C-Klasse, 203276), (SLR-Klasse, 199476), (SLK-Klasse, 171456), (SL-Klasse, 230479), (SLK-Klasse, 171473), (G-Klasse, 463270, 463271), (C-Klasse, 203007, 203707), (C-Klasse, 203018), (C-Klasse, 203718), (C-Klasse, 203740), (C-Klasse, 203742), (C-Klasse, 203043), (C-Klasse, 203743), (C-Klasse, 203046), (C-Klasse, 203746), (SLK/SLC-Klasse, 172475), (A-Klasse, 169006, 169306), (A-Klasse, 169331), (A-Klasse, 169007, 169307), (A-Klasse, 169332), (A-Klasse, 169033), (A-Klasse, 169008, 169308), (B-Klasse, 245231), (B-Klasse, 245232), (B-Klasse, 245233), (B-Klasse, 245234), (B-Klasse, 245207), (B-Klasse, 245208), (E-Klasse, 211087), (E-Klasse, 211256), (E-Klasse, 211056), (E-Klasse, 211287), (CLS-Klasse, 219322), (CLS-Klasse, 219356), (CLS-Klasse, 219375), (CLS-Klasse, 219376), (SLK-Klasse, 171454), (R-Klasse, 251125), (R-Klasse, 251022, 251122), (R-Klasse, 251065, 251165), (R-Klasse, 251175), (S-Klasse, 221022), (S-Klasse, 221022, 221122), (S-Klasse, 221056, 221156), (S-Klasse, 221070, 221170), (S-Klasse, 221071, 221171), (S-Klasse, 221076, 221176), (G-Klasse, 461331, 461302, 461332, 461342, 461345), (C-Klasse, 203008), (C-Klasse, 203020), (C-Klasse, 203220), (CLK-Klasse, 209308), (CLK-Klasse, 209320), (E-Klasse, 211022), (E-Klasse, 211020), (ML-Klasse, 164120), (E-Klasse, 211222), (E-Klasse, 211220), (E-Klasse, 211089), (E-Klasse, 211084), (E-Klasse, 211289), (E-Klasse, 211284), (E-Klasse, 211620), (V-Klasse, 639815), (V-Klasse, 639601), (C-Klasse, 203730), (C-Klasse, 203052), (C-Klasse, 203054), (C-Klasse, 203056), (C-Klasse, 203752), (C-Klasse, 203756), (C-Klasse, 203252), (C-Klasse, 203254), (C-Klasse, 203256), (CLK-Klasse, 209354), (CLK-Klasse, 209356), (CLK-Klasse, 209454), (CLK-Klasse, 209456), (E-Klasse, 211054), (E-Klasse, 211092), (ML-Klasse, 164186), (ML-Klasse, 164175), (C-Klasse, 203292), (C-Klasse, 203287), (C-Klasse, 203092), (C-Klasse, 203087), (E-Klasse, 211292), (E-Klasse, 211029), (V-Klasse, 639713), (CLK-Klasse, 209420), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639711, 639713, 639811, 639813), (ML-Klasse, 164122, 164124, 164125), (GL-Klasse, 164822), (E-Klasse, 211007), (E-Klasse, 211008), (E-Klasse, 211208), (R-Klasse, 251020), (Sprinter, 90x), (C-Klasse, 203042), (C-Klasse, 203076), (Sprinter, 903622, 903611, 903612, 903613, 903661, 903662, 903663, 903671, 903672), (V-Klasse, 639601, 639603, 639605, 639701, 639703, 639705), (SL-Klasse, 230456), (SL-Klasse, 230471), (SL-Klasse, 230472), (SL-Klasse, 230477), (E-Klasse, 211041), (E-Klasse, 211072), (E-Klasse, 211241), (E-Klasse, 211272), (CLS-Klasse, 219372), (CLK-Klasse, 209372), (CLK-Klasse, 209472), (A-Klasse, 169033, 169333), (A-Klasse, 169034, 169334), (A-Klasse, 169031, 169331), (GL-Klasse, 164886), (GL-Klasse, 164871), (E-Klasse, 211090), (S-Klasse, 221086, 221186), (S-Klasse, 221084, 221184), (SLK-Klasse, 171373), (Sprinter, 903671, 903621, 903661, 903662, 90322, 903611, 903612), (C-Klasse, 203706), (Sprinter, 906713), (Sprinter, 906733, 906735), (Sprinter, 906131, 906133, 906135, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637), (GL-Klasse, 164828), (S-Klasse, 221080, 221180), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906235), (CLS-Klasse, 218323), (CLS-Klasse, 218359), (G-Klasse, 463340, 463341, 463343), (G-Klasse, 463303), (V-Klasse, 639701, 639703), (ML-Klasse, 164195), (C-Klasse, 204008), (CL-Klasse, 215379), (S-Klasse, 220179), (E-Klasse, 211077), (E-Klasse, 211277), (CLS-Klasse, 219377), (CLS-Klasse, 219357), (CLK-Klasse, 209377), (CLK-Klasse, 209477), (R-Klasse, 251077), (CL-Klasse,



Diagnostic devices

216371), (CL-Klasse, 216376), (S-Klasse, 221054), (E-Klasse, 211052), (CLK-Klasse, 209341), (CLK-Klasse, 209441), (ML-Klasse, 164777), (SLR-Klasse, 199376), (Sprinter, 906113,906213), (CL-Klasse, 216377), (CL-Klasse, 216379), (Sprinter, 906633,906635,906637), (S-Klasse, 221077), (C-Klasse, 204041), (C-Klasse, 204054), (C-Klasse, 204241), (C-Klasse, 204046), (C-Klasse, 204246), (S-Klasse, 221087,221187), (ML-Klasse, 164172), (R-Klasse, 251056), (E-Klasse, 211252), (C-Klasse, 204052), (C-Klasse, 204081), (C-Klasse, 204087), (C-Klasse, 204252), (C-Klasse, 204254), (C-Klasse, 204256), (A-Klasse, 168133), (A-Klasse, 168132), (A-Klasse, 169032), (A-Klasse, 169032,169332), (C-Klasse, 202018), (C-Klasse, 202180), (C-Klasse, 202023), (C-Klasse, 202026), (C-Klasse, 202033), (C-Klasse, 203035), (C-Klasse, 203235), (C-Klasse, 203061), (CLC-Klasse, 203741), (C-Klasse, 204007), (C-Klasse, 204207), (C-Klasse, 204289), (C-Klasse, 204089), (C-Klasse, 204208), (C-Klasse, 204056), (CLK-Klasse, 208465), (CLK-Klasse, 208470), (CLK-Klasse, 209461), (SLR-Klasse, 199976), (ML-Klasse, 164121), (CLK-Klasse, 209475), (CLK-Klasse, 209476), (E-Klasse, 211207), (E-Klasse, 211024), (E-Klasse, 211057), (E-Klasse, 211290), (Sprinter, 906131,906133,906135,906137,906231,906233,906235,906237,906631,906633,906635,906731,906733,906735), (Sprinter, 906655,906657,906653,), (S-Klasse, 221177), (SL-Klasse, 230454), (SL-Klasse, 230458), (SL-Klasse, 230470), (R-Klasse, 251054,251154), (R-Klasse, 251156), (R-Klasse, 251075), (R-Klasse, 251072,251172), (R-Klasse, 251177), (G-Klasse, 461277), (V-Klasse, 639601,639603), (C-Klasse, 204222), (E-Klasse, 211024,211052), (C-Klasse, 203007,203207,203707), (CLC-Klasse, 203708), (C-Klasse, 203008,203208,203708), (CLS-Klasse, 218374), (C-Klasse, 204201), (C-Klasse, 204044,204045), (Sprinter, 906735,906731,906733), (V-Klasse, 639701,639705), (Sprinter, 906613,906611), (Sprinter, 906135,906235,906131,906133,906231,906233), (E-Klasse, 211257), (S-Klasse, 221054,221154), (CLS-Klasse, 219354), (SLK-Klasse, 171445), (SLK-Klasse, 171458), (CLC-Klasse, 203746), (CLC-Klasse, 203752), (CLC-Klasse, 203756), (R-Klasse, 251065,265165), (SL-Klasse, 230442), (CL-Klasse, 216386), (Sprinter, 906733), (Sprinter, 906133,906135,906233,906235), (Sprinter, 903671,903621,903661,903662,903621,903622,903611,903612,903672), (B-Klasse, 246200), (B-Klasse, 246242), (GLK-Klasse, 204902), (C-Klasse, 204044), (C-Klasse, 204006), (C-Klasse, 204245), (C-Klasse, 204065), (CLC-Klasse, 203731), (CLC-Klasse, 203707), (E-Klasse, 212002), (E-Klasse, 212056), (E-Klasse, 212057), (E-Klasse, 212055), (E-Klasse, 207357), (E-Klasse, 207356), (E-Klasse, 207372), (G-Klasse, 463340), (G-Klasse, 463341), (G-Klasse, 463202), (GL-Klasse, 164824,164825), (GLK-Klasse, 204987), (R-Klasse, 251124,251125), (S-Klasse, 221095,221195), (Sprinter, 906635,906637,906631,906633), (B-Klasse, 246201), (V-Klasse, 639705,639815), (C-Klasse, 204249), (C-Klasse, 204248), (C-Klasse, 204025), (E-Klasse, 207457), (E-Klasse, 207456), (E-Klasse, 212277), (C-Klasse, 204049), (C-Klasse, 204001), (C-Klasse, 204048), (C-Klasse, 204002), (R-Klasse, 251021,251121,251026,251126), (G-Klasse, 463041), (S-Klasse, 221080,221081), (S-Klasse, None), (B-Klasse, 246243), (C-Klasse, 204045), (CL-Klasse, 216373), (CL-Klasse, 216374), (CL-Klasse, 216394), (E-Klasse, 212282), (E-Klasse, 212293), (E-Klasse, 212023), (E-Klasse, 212082), (E-Klasse, 212093), (G-Klasse, 463306), (G-Klasse, 463346), (S-Klasse, 221026,221126), (E-Klasse, 212057,212157), (R-Klasse, 251023,251123), (GL-Klasse, 164823), (S-Klasse, 221057,221157), (S-Klasse, 221074,221174), (S-Klasse, 221082,221182), (S-Klasse, 221094,221194), (CLS-Klasse, 218303,218304), (SLK/SLC-Klasse, 172447), (SLK/SLC-Klasse, 172457), (E-Klasse, 207455), (E-Klasse, 207423), (E-Klasse, 207459), (C-Klasse, 204303), (C-Klasse, 204347), (C-Klasse, 204357), (E-Klasse, 207355), (E-Klasse, 207323), (E-Klasse, 207359), (C-Klasse, 204377), (CLS-Klasse, 218373), (CLS-Klasse, 218391), (SLK/SLC-Klasse, 172448), (C-Klasse, 204078), (E-Klasse, 212056,212156), (E-Klasse, 212041), (C-Klasse, 204003), (C-Klasse, 204057), (E-Klasse, 212074), (S-Klasse, 221003,221103), (CLC-Klasse, 203743), (CLS-Klasse, 218393), (Sprinter, 906611,906613,906731,906733,906735), (Sprinter, 906153,906155,906255), (Sprinter, 906113,906213,906111,906211), (SLK/SLC-Klasse, 172403), (SL-Klasse, 231457), (SL-Klasse, 231473), (SL-Klasse, 231474), (E-Klasse, 212054), (R-Klasse, 251057,251157), (V-Klasse, 639811,639813,639815,639711,639713), (A-Klasse, 176012), (A-Klasse, 176042), (A-Klasse, 176001), (A-Klasse, 176043), (A-Klasse, 176044), (C-Klasse, 204202), (C-Klasse, 204031), (C-Klasse, 204231), (C-Klasse, 204285), (C-Klasse, 204331), (C-Klasse, 204348), (E-Klasse, 207388), (A-Klasse, 176000), (A-Klasse,



Diagnostic devices

176003), (A-Klasse, 176046), (A-Klasse, 176052), (B-Klasse, 246212), (B-Klasse, 246203), (B-Klasse, 246244), (B-Klasse, 242848), (CLS-Klasse, 218993), (CLS-Klasse, 218991), (GL-Klasse, 166823, 166824), (GL-Klasse, 166873), (CLS-Klasse, 218326), (CLA-Klasse, 117342), (CLA-Klasse, 117343), (CLA-Klasse, 117303), (CLA-Klasse, 117344), (Citan, 415703), (Citan, 415703, 415705), (Citan, 415601), (CLS-Klasse, 218974), (CLS-Klasse, 218973), (CLS-Klasse, 218959), (CLS-Klasse, 218923), (CLS-Klasse, 218903, 218904), (E-Klasse, 212298), (E-Klasse, 212073), (Citan, 415603), (Citan, 415605), (A-Klasse, 176011), (A-Klasse, 176005), (A-Klasse, 176002), (B-Klasse, 246211), (A-Klasse, 176008), (CLS-Klasse, 218375), (CLS-Klasse, 218376), (CLS-Klasse, 218392), (CLS-Klasse, 218394), (B-Klasse, 246247), (ML-Klasse, 166055), (E-Klasse, 207362), (E-Klasse, 212080), (E-Klasse, 212035), (SL-Klasse, 231479), (A-Klasse, 169), (A-Klasse, 176047), (CLS-Klasse, 218397), (CLS-Klasse, 218367), (CLS-Klasse, 218368), (CLS-Klasse, 218301), (CLS-Klasse, 218361), (CLS-Klasse, 218365), (CLA-Klasse, 117302), (CLA-Klasse, 117305), (CLA-Klasse, 117346), (CLA-Klasse, 117352), (CLA-Klasse, 117308), (CLA-Klasse, 117312), (CLA-Klasse, 117301), (E-Klasse, 212201), (E-Klasse, 212080, 212180), (E-Klasse, 212182), (E-Klasse, 212105, 212106), (E-Klasse, 212059, 212159), (E-Klasse, 212055, 212155), (E-Klasse, 212136), (E-Klasse, 212297), (E-Klasse, 207462), (ML-Klasse, 166056), (SL-Klasse, 231465), (V-Klasse, 447601, 447603, 447605), (V-Klasse, 447701, 447703, 447705), (V-Klasse, 447703), (V-Klasse, 447811, 447813, 447815), (V-Klasse, 447813, 447811, 447815), (V-Klasse, 447703, 447813), (CLA-Klasse, 117952), (B-Klasse, 246208), (E-Klasse,), (Sprinter, 901461, 901462, 902461, 902462), (G-Klasse, 463222, 463236, 463237, 463242), (C-Klasse,), (R-Klasse,), (Sprinter, 906731, 906735, 906737), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906731, 906733, 906735), (Sprinter, 906111, 906113, 906211, 906713, 906611, 906613, 906711, 906713), (Sprinter, 906111, 906113, 906211, 906213, 906611, 906613, 906711, 906713), (Sprinter, 906611, 906613, 906711, 906713), (GL-Klasse,), (S-Klasse, 221073, 221173), (A-Klasse, 176041), (GLS-Klasse, 166824), (S-Klasse, 221083, 221183), (ML-Klasse, 166), (ML-Klasse, 166058), (C-Klasse, 204240), (CLS-Klasse, 218992), (CLS-Klasse, 218975), (CLS-Klasse, 218976), (E-Klasse, 212274), (E-Klasse, 212095), (GL-Klasse, 166856), (ML-Klasse, 166062), (CLS-Klasse, 218355), (ML-Klasse, 164182), (GLA-Klasse, 156952), (GLA-Klasse, 156912), (GLA-Klasse, 156942), (B-Klasse, 246246), (B-Klasse, 246205), (B-Klasse, 246202), (CLS-Klasse, 218926), (GLS-Klasse, 166856), (GLS-Klasse, 166873), (GLS-Klasse, 166875), (SLK/SLC-Klasse, 172404), (C-Klasse, 205086), (CLS-Klasse, 218965), (C-Klasse, 205387), (A-Klasse, 176051), (B-Klasse, 246241), (C-Klasse, 205047), (CLA-Klasse, 117951), (CLA-Klasse, 117946), (CLA-Klasse, 117944), (CLA-Klasse, 117905), (CLA-Klasse, 117902), (CLA-Klasse, 117903), (CLA-Klasse, 117943), (CLA-Klasse, 117912), (CLA-Klasse, 117942), (SLK/SLC-Klasse, 172434), (V-Klasse, 447811, 447813, 447815, 447801, 447803), (V-Klasse, 447705, 447701, 447703), (V-Klasse, 447811, 447813, 447801, 447803), (V-Klasse, 447815, 447813, 447811), (V-Klasse, 447811, 447813, 447801, 447803), (CLS-Klasse, 218967), (CLS-Klasse, 218997), (Sprinter, 906111, 906113, 906211, 906213, 906711, 906713, 906611, 906613), (GLK-Klasse, 204956), (ML-Klasse, None), (V-Klasse, None), (Sprinter, 906111, 906113, 906211, 906213, 906611, 711, 906713), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637), (Sprinter, 906655, 906657), (CLA-Klasse, 117350), (A-Klasse, 176050), (CLS-Klasse, 218961), (CLS-Klasse, 218968), (C-Klasse, 205386), (SLK/SLC-Klasse, 172431), (SLK/SLC-Klasse, 172466), (CLS-Klasse, 218901), (E-Klasse, 212097), (E-Klasse, 212197), (V-Klasse, 447701, 447702, 447703, 447704, 447705), (V-Klasse, 447811, 447812, 447813, 447814, 447815), (SL-Klasse, 231466), (V-Klasse, 447703, 477813), (GLE-Klasse, 166057), (SLK/SLC-Klasse, 172438), (C-Klasse, 205244), (C-Klasse, 205248), (CLA-Klasse, 117351), (Citan, 415705), (V-Klasse, 447711, 447713, 447701, 447703), (V-Klasse, 447815, 447811, 447813), (V-Klasse, 447711, 447713), (C-Klasse, 205486), (C-Klasse, 205487), (CLA-Klasse, 117347), (CLA-Klasse, 117947), (CLS-Klasse, 218994), (C-Klasse, 205203), (V-Klasse, 447701, 447703), (Sprinter, 906635, 906637), (V-Klasse, 447813, 447815), (CLA-Klasse, 117908), (GLC-Klasse, 253925), (V-Klasse, 447), (Sprinter, 906133, 906135, 906233, 906235, 906733, 906735), (GLC-Klasse, 253388), (GLC-Klasse, 253988), (GLC-Klasse, 253989), (GLC-Klasse, 253389), (GLC-Klasse, 253943), (V-Klasse, 447701, 447703, 447705), (GLC-Klasse, 253380), (V-Klasse, 447603, 447605), (V-Klasse,



Diagnostic devices

447703, 447705), (V-Klasse, 447811, 447813), (GLC-Klasse, 253981), (GLC-Klasse, 253980), (GLC-Klasse, 253315), (GLC-Klasse, 253915), (GLC-Klasse, 253353), (B-Klasse, 246207), (B-Klasse, 246245), (C-Klasse, 205049), (C-Klasse, 205053), (C-Klasse, 205449), (C-Klasse, 204), (C-Klasse, 205349), (C-Klasse, 203765), (C-Klasse, 205253), (CLA-Klasse,), (CLA-Klasse, 117345), (CLK-Klasse, 2094_), (CLS-Klasse, 218362), (E-Klasse, 207367), (E-Klasse, 211606), (E-Klasse, 211616), (GL-Klasse, 166824), (GL-Klasse, 166864), (GL-Klasse, 166872), (GL-Klasse, None), (GLC-Klasse, 253942), (GLC-Klasse, 253913), (GLC-Klasse, 253916), (GLC-Klasse, 253914), (GLC-Klasse, 253948), (GLC-Klasse, 253953), (GLC-Klasse, 253984), (GLC-Klasse, 253342), (GLC-Klasse, 253343), (GLC-Klasse, 253313), (GLC-Klasse, 253316), (GLC-Klasse, 253381), (GLC-Klasse, 253384), (GLE-Klasse, 166058), (GLE-Klasse, 292062), (GLK-Klasse, 204957), (S-Klasse,), (SLK/SLC-Klasse, 172435), (Sprinter, 904), (CLK-Klasse, 2093_), (CLS-Klasse, 2183_), (CLS-Klasse, 2193_), (GLE-Klasse, 292324), (GLC-Klasse, 253903), (GLC-Klasse, 253911), (GLC-Klasse, 253311))

Resetting learned values of the power window ((AMG GT, 190377), (AMG GT, 190378), (AMG GT, 190379), (AMG GT, 190477), (AMG GT, 190480), (AMG GT, 190380), (AMG GT, 190478), (AMG GT, 190479), (AMG GT, 190381), (AMG GT, 190382))

Learning the power windows ((AMG GT, 190377), (AMG GT, 190378), (AMG GT, 190379), (AMG GT, 190477), (AMG GT, 190480), (AMG GT, 190380), (AMG GT, 190478), (C-Klasse, 204277), (ML-Klasse, 163175), (AMG GT, 190479), (AMG GT, 190381), (AMG GT, 190382), (GLE-Klasse, 167354))

Initializing lateral/longitudinal/rotation acceleration sensor ((GLA-Klasse, 156943), (GLA-Klasse, 156944), (GLA-Klasse, 156946), (GLA-Klasse, 156947), (GLA-Klasse, 156952), (GLA-Klasse, 156942))

Changing the SBC brake fluid/bleeding the brake system ((CLS-Klasse, 219322), (CLS-Klasse, 219356), (CLS-Klasse, 219375), (CLS-Klasse, 219376), (E-Klasse, 211222), (E-Klasse, 211220))

Changing and checking DCT fluid ((GLA-Klasse, 156947))

Activating the SBC after brake disc change ((CLS-Klasse, 219322), (CLS-Klasse, 219356), (CLS-Klasse, 219375), (CLS-Klasse, 219376))

Activating SBC system ((CLS-Klasse, 219322), (CLS-Klasse, 219356), (CLS-Klasse, 219375), (CLS-Klasse, 219376))

Initializing the soot particulate filter ((Sprinter, 906731, 906733, 906735), (Sprinter, 906611, 906613), (Sprinter, 906631, 906633, 906635, 906637), (Sprinter, 906653, 906655, 906657), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (Sprinter, 906153, 906155, 906253, 906255), (Sprinter, 906111, 906113, 906211, 906213), (Sprinter, 906), (ML-Klasse, 164122), (R-Klasse, 251121, 251026, 251126), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637, 906731, 906733, 906735), (C-Klasse, 203004), (C-Klasse, 203008, 203708), (E-Klasse, 211006), (E-Klasse, 211206), (C-Klasse, 203207), (C-Klasse, 203007), (C-Klasse, 203707), (E-Klasse, 211004), (C-Klasse, 203006), (C-Klasse, 203708), (C-Klasse, 203208), (C-Klasse, 203007, 203707), (C-Klasse, 203206), (CLS-Klasse, 219322), (R-Klasse, 251125), (R-Klasse, 251022, 251122), (S-Klasse, 221022), (S-Klasse, 221022, 221122), (C-Klasse, 203008), (C-Klasse, 203020), (C-Klasse, 203220), (CLK-Klasse, 209308), (CLK-Klasse, 209320), (E-Klasse, 211022), (E-Klasse, 211020), (ML-Klasse, 164120), (E-Klasse, 211222), (E-Klasse, 211220), (E-Klasse, 211089), (E-Klasse, 211084), (E-Klasse, 211289), (E-Klasse, 211284), (E-Klasse, 211620), (C-Klasse, 203204), (CLK-Klasse, 209420), (C-Klasse, 203204, 203207), (ML-Klasse, 164122, 164124, 164125), (GL-Klasse, 164822), (R-Klasse, 251020), (Sprinter, 906711, 906713), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906631, 906633, 906635, 906637), (S-Klasse, 221080, 221180), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235), (G-Klasse, 463340, 463341, 463343), (G-Klasse, 463303), (E-Klasse, 211024), (Sprinter, 906155, 906253, 906255), (E-Klasse, 211024, 211052), (C-Klasse, 203007, 203207, 203707), (CLC-Klasse, 203708), (C-Klasse, 203008, 203208, 203708), (Sprinter, 906655, 906657, 906653), (Sprinter, 906735, 906731, 906733), (Sprinter, 906613, 906611))



Diagnostic devices

(Sprinter, 906135, 906235, 906131, 906133, 906231, 906233), (CLC-Klasse, 203707), (G-Klasse, 463340), (G-Klasse, 463341), (ML-Klasse, 164124, 164125), (R-Klasse, 251124, 251125), (R-Klasse, 251021, 251121, 251026, 251126), (G-Klasse, 463041), (S-Klasse, 221080, 221081), (S-Klasse, None), (Sprinter, 906111, 906113, 906211, 906213, 906711, 906713, 906611, 906613), (Sprinter, 906111, 906113, 906211, 906213, 906611, 906613, 906711, 906713), (Sprinter, 906111, 906113, 906211, 906213, 906611, 711, 906713), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906235, 906631, 906633, 906635, 906637), (C-Klasse, 203706), (Sprinter, 906111, 906113, 906211, 906213, 906611, 906613), (Sprinter, 906131, 906133, 906135, 906231, 906233, 906235, 906731, 906733, 906735), (E-Klasse, 211606), (CLS-Klasse, 2193_))

Adapting the pressure-regulating valve ((Sprinter, 906), (Sprinter, 906111, 906113, 906211, 906213, 906611, 906613))

Resetting the counter for headlight operating hours ((GLA-Klasse, 156908), (GLA-Klasse, 156943), (GLA-Klasse, 156903), (GLA-Klasse, 156944), (GLA-Klasse, 156902), (GLA-Klasse, 156905), (GLA-Klasse, 156946), (GLA-Klasse, 156947), (A-Klasse, 176012), (A-Klasse, 176042), (A-Klasse, 176001), (A-Klasse, 176043), (A-Klasse, 176044), (A-Klasse, 176000), (A-Klasse, 176003), (A-Klasse, 176046), (A-Klasse, 176052), (A-Klasse, 176011), (A-Klasse, 176005), (A-Klasse, 176002), (A-Klasse, 176008), (A-Klasse, 176047), (A-Klasse, 176041), (GLA-Klasse, 156952), (GLA-Klasse, 156912), (GLA-Klasse, 156942), (A-Klasse, 176051), (A-Klasse, 176050))

Initializing the manual transmission position sensor ((C-Klasse, 204200), (E-Klasse, 212103), (E-Klasse, 212020, 212021, 212027), (E-Klasse, 207425), (E-Klasse, 207301, 207302), (E-Klasse, 207302), (E-Klasse, 207303, 207304), (E-Klasse, 207422), (E-Klasse, 207322), (E-Klasse, 212205, 212206), (E-Klasse, 212201, 212202), (E-Klasse, 212202), (E-Klasse, 212203), (E-Klasse, 212225), (E-Klasse, 212224), (E-Klasse, 212289), (E-Klasse, 212221, 212227), (E-Klasse, 212005, 212006), (E-Klasse, 212001, 212002), (E-Klasse, 212024), (E-Klasse, 212089), (C-Klasse, 204282), (C-Klasse, 204292), (C-Klasse, 204082), (C-Klasse, 204092), (E-Klasse, 207401, 207402), (E-Klasse, 207402), (E-Klasse, 207403, 207404), (E-Klasse, 212220), (C-Klasse, 204203), (C-Klasse, 204220), (C-Klasse, 204225), (C-Klasse, 204223), (C-Klasse, 204000), (C-Klasse, 204022), (GLK-Klasse, 204901), (GLK-Klasse, 204984, 204997), (GLK-Klasse, 204984), (GLK-Klasse, 204982, 204904), (GLK-Klasse, 204992), (GLK-Klasse, 204983), (C-Klasse, 204086), (C-Klasse, 204286), (E-Klasse, 212025), (GLK-Klasse, 204999), (E-Klasse, 212284), (C-Klasse, 204302), (C-Klasse, 204023), (E-Klasse, 212223), (C-Klasse, 204020), (E-Klasse, 212204), (E-Klasse, 212098), (E-Klasse, 212226), (E-Klasse, 212294), (E-Klasse, 212026), (C-Klasse, 204284), (C-Klasse, 204084), (GLK-Klasse, 204904, 204982), (E-Klasse, 212094), (GLK-Klasse, 204993), (E-Klasse, 212084), (GLK-Klasse, 204986), (GLA-Klasse, 156908), (GLA-Klasse, 156903), (GLA-Klasse, 156902), (GLA-Klasse, 156905), (E-Klasse, 212003), (E-Klasse, 212001), (E-Klasse, 212104), (E-Klasse, 212027, 212227), (E-Klasse, 212004), (E-Klasse, 207426), (E-Klasse, 207401), (E-Klasse, 207301), (E-Klasse, 207326), (C-Klasse, 205009), (C-Klasse, 205007), (C-Klasse, 205012), (C-Klasse, 205006), (C-Klasse, 205002), (C-Klasse, 205204), (C-Klasse, 205004), (C-Klasse, 205003), (C-Klasse, 205008), (E-Klasse, 212011, 212111), (GLE-Klasse, 166004), (GLE-Klasse, 166024), (GLE-Klasse, 166006), (GLE-Klasse, 292323, 292324), (C-Klasse, 205207), (C-Klasse, 205208), (C-Klasse, 205209), (C-Klasse, 205212), (GLC-Klasse, 253905), (GLC-Klasse, 253909), (C-Klasse, 205304), (C-Klasse, 205308), (C-Klasse, 205005), (C-Klasse, 205205), (C-Klasse, 205037), (C-Klasse, 205405), (C-Klasse, 205408), (C-Klasse, 205404), (C-Klasse, 205305), (C-Klasse, 205309), (GLC-Klasse, 253303, 253305), (GLC-Klasse, 253309), (GLC-Klasse, 253301), (GLC-Klasse, 253325), (GLC-Klasse, 253904), (GLC-Klasse, 253901), (E-Klasse, 212211), (E-Klasse, 238314), (E-Klasse, 238334), (E-Klasse, 238315), (E-Klasse, 238414), (C-Klasse, 205314), (E-Klasse, 238318), (E-Klasse, 213023), (E-Klasse, 238418), (GLE-Klasse, 167119), (GLE-Klasse, 167121), (GLE-Klasse, 167123), (GLS-Klasse, 167921), (GLS-Klasse, 167923), (C-Klasse, 205418), (C-Klasse, 205318), (C-Klasse, 205213), (C-Klasse, 205019), (C-Klasse, 205018), (C-Klasse, 205013), (GLC-Klasse, 253323), (GLC-Klasse, 253923), (GLB-Klasse, 247610), (GLB-Klasse, 247612), (GLB-Klasse, 247613), (GLB-Klasse, 247615), (GLA-Klasse, 247712), (GLA-Klasse, 247713), (GLA-Klasse,



Diagnostic devices

247715), (GLA-Klasse, 247714), (GLA-Klasse, 247710), (GLC-Klasse, 253349), (GLC-Klasse, 253319), (ML-Klasse, 166003,166004), (ML-Klasse, 166024), (CLS-Klasse, 218323), (C-Klasse, 204289), (C-Klasse, 204089), (C-Klasse, 204222), (B-Klasse, 246200), (GLK-Klasse, 204902), (E-Klasse, 212002), (B-Klasse, 246201), (C-Klasse, 204208), (C-Klasse, 204201), (C-Klasse, 204025), (C-Klasse, 204001), (C-Klasse, 204002), (E-Klasse, 212282), (E-Klasse, 212293), (E-Klasse, 212023), (E-Klasse, 212082), (E-Klasse, 212093), (G-Klasse, 463306), (G-Klasse, 463346), (CLS-Klasse, 218303,218304), (E-Klasse, 207423), (C-Klasse, 204303), (E-Klasse, 207323), (C-Klasse, 204008), (C-Klasse, 204003), (CLS-Klasse, 218393), (SLK/SLC-Klasse, 172403), (A-Klasse, 176012), (A-Klasse, 176001), (C-Klasse, 204202), (A-Klasse, 176000), (A-Klasse, 176003), (B-Klasse, 246212), (B-Klasse, 246203), (CLS-Klasse, 218993), (GL-Klasse, 166823,166824), (CLS-Klasse, 218326), (CLA-Klasse, 117303), (CLS-Klasse, 218923), (CLS-Klasse, 218903,218904), (E-Klasse, 212298), (A-Klasse, 176011), (A-Klasse, 176005), (A-Klasse, 176002), (B-Klasse, 246211), (A-Klasse, 176008), (S-Klasse, 222004,222104), (S-Klasse, 222033,222133), (S-Klasse, 222032,222123,222132), (S-Klasse, 222133), (CLS-Klasse, 218394), (CLS-Klasse, 218397), (CLS-Klasse, 218301), (CLA-Klasse, 117302), (CLA-Klasse, 117305), (CLA-Klasse, 117308), (CLA-Klasse, 117312), (CLA-Klasse, 117301), (E-Klasse, 212201), (E-Klasse, 212182), (E-Klasse, 212105,212106), (E-Klasse, 212297), (B-Klasse, 246208), (C-Klasse,), (GLS-Klasse, 166824), (ML-Klasse, 166), (S-Klasse, 222032,222132), (GLA-Klasse, 156912), (B-Klasse, 246205), (B-Klasse, 246202), (CLS-Klasse, 218926), (SLK/SLC-Klasse, 172404), (CLA-Klasse, 117905), (CLA-Klasse, 117902), (CLA-Klasse, 117903), (CLA-Klasse, 117912), (CLS-Klasse, 218997), (E-Klasse, 213004), (CLS-Klasse, 218901), (E-Klasse, 212097), (E-Klasse, 212197), (G-Klasse, 463348), (V-Klasse, 447711,447713,447701,447703), (V-Klasse, 447811,447812,447813,447814,447815), (E-Klasse, 213204), (E-Klasse, 213031), (E-Klasse, 213033), (CLS-Klasse, 218994), (E-Klasse, 213005), (C-Klasse, 205203), (E-Klasse, 213013), (E-Klasse, 213217), (E-Klasse, 213237), (E-Klasse, 213234), (E-Klasse, 213213), (E-Klasse, 213205), (E-Klasse, 213233), (E-Klasse, 213034), (E-Klasse, 213104), (CLA-Klasse, 117908), (GLC-Klasse, 253925), (E-Klasse, 238434), (S-Klasse, 222035,222135), (C-Klasse, 205014), (C-Klasse, 205214), (C-Klasse, 205414), (E-Klasse, 213008), (E-Klasse, 213208), (S-Klasse, 222021,222121), (S-Klasse, 222020,222120), (S-Klasse, 222034,222134), (E-Klasse, 238415), (CLS-Klasse, 257321), (CLS-Klasse, 257323), (C-Klasse, 205000), (C-Klasse, 205001), (C-Klasse, 205011), (C-Klasse, 205015), (C-Klasse, 205200), (C-Klasse, 205201), (C-Klasse, 205211), (C-Klasse, 205215), (X-Klasse, 470252), (A-Klasse, 177012), (A-Klasse, 177014), (C-Klasse, 205401), (C-Klasse, 205411), (C-Klasse, 205415), (C-Klasse, 205301), (C-Klasse, 205311), (C-Klasse, 205218), (C-Klasse, 205219), (E-Klasse, 213012), (E-Klasse, 213016), (E-Klasse, 213022), (E-Klasse, 213220), (CLS-Klasse, 257320), (E-Klasse, 238420), (E-Klasse, 238423), (B-Klasse, 247012), (B-Klasse, 247014), (CLA-Klasse, 118312), (CLA-Klasse, 118314), (X-Klasse, 471210), (X-Klasse, 471230), (X-Klasse, 471231), (X-Klasse, 471252), (B-Klasse, 247015), (B-Klasse, 247013), (CLS-Klasse, 257318), (CLA-Klasse, 118612), (CLA-Klasse, 118614), (C-Klasse, 205319), (C-Klasse, 205315), (E-Klasse, 213222), (A-Klasse, 177013), (A-Klasse, 177015), (CLA-Klasse, 118613), (CLA-Klasse, 118615), (E-Klasse, 213212), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (GLC-Klasse, 253315), (GLC-Klasse, 253915), (A-Klasse, 177112), (A-Klasse, 177113), (A-Klasse, 177114), (A-Klasse, 177115), (B-Klasse, 246207), (CLS-Klasse, 257314), (E-Klasse, 238320), (E-Klasse, 238323), (E-Klasse, 213216), (G-Klasse, 463349), (G-Klasse, 463350), (GL-Klasse, 166824), (GLB-Klasse, 247614), (GLC-Klasse, 253913), (GLC-Klasse, 253916), (GLC-Klasse, 253914), (GLC-Klasse, 253313), (GLC-Klasse, 253316), (GLE-Klasse, 167321), (GLE-Klasse, 167323), (GLE-Klasse, 292324), (A-Klasse, 177010), (A-Klasse, 177110), (CLA-Klasse, 118310), (CLA-Klasse, 118610), (GLC-Klasse, 253903), (GLC-Klasse, 253911), (GLC-Klasse, 253311), (B-Klasse, 247010))

Regenerating the soot particulate filter ((Sprinter, 906731,906733,906735), (Sprinter, 906611,906613), (Sprinter, 906631,906633,906635,906637), (Sprinter, 906653,906655,906657), (Sprinter, 906131,906133,906135,906231,906233,906235), (Sprinter, 906153,906155,906253,906255), (Sprinter, 906111,906113,906211,906213), (Sprinter, 906), (ML-Klasse, 164124,164125), (Sprinter, 906131,906133,906135,906231,906233,906235,906631,906633,906635,906637,906731,9067



Diagnostic devices

33,906735), (C-Klasse, 203004), (C-Klasse, 203008,203708), (C-Klasse, 203207), (C-Klasse, 203007), (C-Klasse, 203707), (C-Klasse, 203006), (C-Klasse, 203708), (C-Klasse, 203208), (C-Klasse, 203007,203707), (C-Klasse, 203206), (C-Klasse, 203008), (C-Klasse, 203204), (V-Klasse, 639811,639813,639815), (C-Klasse, 203204,203207), (Sprinter, 906131,906133,906135,906231,906233,906233,906235), (V-Klasse, 639701,639703,639705), (V-Klasse, 639601,639603,639605), (ML-Klasse, 164121), (C-Klasse, 203007,203207,203707), (CLC-Klasse, 203708), (C-Klasse, 203008,203208,203708), (CLC-Klasse, 203707), (GL-Klasse, 164824,164825), (R-Klasse, 251124,251125), (R-Klasse, 251023,251123), (GL-Klasse, 164823), (R-Klasse, 251021,251121,251026,251126), (R-Klasse,), (GL-Klasse,), (ML-Klasse, None), (GL-Klasse, 164822), (C-Klasse, 203706), (Sprinter, 906111,906113,906211,906213,906611,906613))

Initializing the intelligent cruise control/emergency brake assistant ((AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (AMG GT, 290658), (GLE-Klasse, 167354), (AMG GT, 290679))

Deactivating SBC system ((CLS-Klasse, 219322), (CLS-Klasse, 219356), (CLS-Klasse, 219375), (CLS-Klasse, 219376))

Learning throttle valve stop ((ML-Klasse, 164124,164125), (Sprinter, 906), (E-Klasse, 211072), (E-Klasse, 211272), (CLK-Klasse, 209372), (CLK-Klasse, 209472), (E-Klasse, 211090), (G-Klasse, 463340,463341,463343), (G-Klasse, 463303), (CLK-Klasse, 209377), (CLK-Klasse, 209477), (ML-Klasse, 164121), (E-Klasse, 211290), (G-Klasse, 463340), (G-Klasse, 463341), (GL-Klasse, 164824,164825), (R-Klasse, 251124,251125), (CLC-Klasse, 203752), (G-Klasse, 463041), (R-Klasse, 251023,251123), (GL-Klasse, 164823), (R-Klasse, 251021,251121,251026,251126), (R-Klasse,), (GL-Klasse,), (ML-Klasse, None), (GL-Klasse, 164822), (Sprinter, 906111,906113,906211,906213,906611,906613))

Adjusting the xenon headlight ((CLK-Klasse, 209342), (CLK-Klasse, 209361), (CLK-Klasse, 209365), (CLK-Klasse, 209375), (CLK-Klasse, 209316), (CLK-Klasse, 209343), (CLK-Klasse, 209376), (CLK-Klasse, 209442), (CLK-Klasse, 209443), (CLK-Klasse, 209465), (CLK-Klasse, 209308), (CLK-Klasse, 209320), (CLK-Klasse, 209354), (CLK-Klasse, 209356), (CLK-Klasse, 209454), (CLK-Klasse, 209456), (CLK-Klasse, 209420), (CLK-Klasse, 209372), (CLK-Klasse, 209472), (CLK-Klasse, 209377), (CLK-Klasse, 209477), (CLK-Klasse, 209341), (CLK-Klasse, 209441), (CLK-Klasse, 203741), (CLK-Klasse, 209461), (CLK-Klasse, 209475), (CLK-Klasse, 209476), (CLK-Klasse, 2094_), (CLK-Klasse, 2093_))

Initializing the parking brake ECU ((B-Klasse, 242848))

Adapting the emergency brake assistant ((AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (AMG GT, 290658), (GLE-Klasse, 167354), (AMG GT, 290679))

Initializing the adaptive cruise control ((ML-Klasse, 164124,164125), (ML-Klasse, 164128), (ML-Klasse, 164177), (ML-Klasse, 164122), (CLK-Klasse, 209342), (CLK-Klasse, 209361), (CLK-Klasse, 209365), (CLK-Klasse, 209375), (CLK-Klasse, 209316), (CLK-Klasse, 209343), (CLK-Klasse, 209376), (CLK-Klasse, 209442), (CLK-Klasse, 209443), (CLK-Klasse, 209465), (CLS-Klasse, 219322), (CLS-Klasse, 219356), (CLS-Klasse, 219375), (CLS-Klasse, 219376), (CLK-Klasse, 209308), (CLK-Klasse, 209320), (ML-Klasse, 164120), (CLK-Klasse, 209354), (CLK-Klasse, 209356), (CLK-Klasse, 209454), (CLK-Klasse, 209456), (ML-Klasse, 164186), (ML-Klasse, 164175), (CLK-Klasse, 209420), (ML-Klasse, 164122,164124,164125), (GL-Klasse, 164822), (CLS-Klasse, 219372), (CLK-Klasse, 209372), (CLK-Klasse, 209472), (GL-Klasse, 164886), (GL-Klasse, 164871), (GL-Klasse, 164828), (ML-Klasse, 164195), (CLS-Klasse, 219377), (CLS-Klasse, 219357), (CLK-Klasse, 209377), (CLK-Klasse, 209477), (CLK-Klasse, 209341), (CLK-Klasse, 209441), (ML-Klasse, 164777), (ML-Klasse, 164172), (CLK-Klasse, 209461), (ML-Klasse, 164121), (CLK-Klasse, 209475), (CLK-Klasse, 209476), (CLS-Klasse, 219354), (GL-Klasse, 164824,164825), (GL-Klasse, 164823), (GL-Klasse,), (ML-Klasse, 164182), (ML-Klasse, None), (CLK-Klasse, 2094_), (CLK-Klasse, 2093_), (CLS-Klasse, 2193_))

Adapting the exhaust gas flap actuator ((GLA-Klasse, 156947))

Learning the throttle valve ((GLA-Klasse, 156947))



Diagnostic devices

Calibrating the front camera ((C-Klasse, 206245), (GLC-Klasse, 254651), (GLC-Klasse, 254605), (GLC-Klasse, 254647), (GLC-Klasse, 254))

Resetting learned values of steering angle sensor ((S-Klasse, 221179), (C-Klasse, 204200), (C-Klasse, 204282), (C-Klasse, 204292), (C-Klasse, 204082), (C-Klasse, 204092), (C-Klasse, 204203), (C-Klasse, 204247), (C-Klasse, 204220), (C-Klasse, 204225), (C-Klasse, 204000), (C-Klasse, 204047), (C-Klasse, 204022), (S-Klasse, 221028, 221128), (GLK-Klasse, 204901), (GLK-Klasse, 204984, 204997), (GLK-Klasse, 204984), (GLK-Klasse, 204982, 204904), (GLK-Klasse, 204981), (GLK-Klasse, 204992), (GLK-Klasse, 204983), (C-Klasse, 204086), (C-Klasse, 204286), (GLK-Klasse, 204999), (C-Klasse, 204349), (C-Klasse, 204302), (C-Klasse, 204080), (C-Klasse, 204088), (C-Klasse, 204055), (GLK-Klasse, 204988), (C-Klasse, 204277), (ML-Klasse, 166074), (GL-Klasse, 166874), (GLE-Klasse, 166004), (GLE-Klasse, 166024), (GLE-Klasse, 166073), (GLE-Klasse, 166074), (GLE-Klasse, 166075, 166875), (GLE-Klasse, 166006), (ML-Klasse, 166003, 166004), (ML-Klasse, 166024), (C-Klasse, 203004), (C-Klasse, 203008, 203708), (ML-Klasse, 166057), (ML-Klasse, 166073), (C-Klasse, 203207), (C-Klasse, 203707), (C-Klasse, 203276), (C-Klasse, 203007), (C-Klasse, 203007, 203707), (C-Klasse, 203006), (C-Klasse, 203708), (C-Klasse, 203206), (C-Klasse, 203208), (C-Klasse, 203016), (C-Klasse, 203216), (C-Klasse, 203018), (C-Klasse, 203218), (C-Klasse, 203718), (C-Klasse, 203740), (C-Klasse, 203240), (C-Klasse, 203040), (C-Klasse, 203242), (C-Klasse, 203742), (C-Klasse, 203043), (C-Klasse, 203243), (C-Klasse, 203743), (C-Klasse, 203046), (C-Klasse, 203246), (C-Klasse, 203746), (C-Klasse, 203261), (C-Klasse, 203064), (C-Klasse, 203264), (C-Klasse, 203764), (C-Klasse, 203065), (C-Klasse, 203265), (C-Klasse, 203081), (C-Klasse, 203084), (C-Klasse, 203284), (S-Klasse, 221022), (S-Klasse, 221022, 221122), (S-Klasse, 221056, 221156), (S-Klasse, 221070, 221170), (S-Klasse, 221071, 221171), (S-Klasse, 221076, 221176), (C-Klasse, 203008), (C-Klasse, 203020), (C-Klasse, 203220), (C-Klasse, 203730), (C-Klasse, 203052), (C-Klasse, 203054), (C-Klasse, 203056), (C-Klasse, 203752), (C-Klasse, 203756), (C-Klasse, 203252), (C-Klasse, 203254), (C-Klasse, 203256), (C-Klasse, 203292), (C-Klasse, 203287), (C-Klasse, 203092), (C-Klasse, 203087), (C-Klasse, 203204), (C-Klasse, 203204, 203207), (C-Klasse, 203042), (C-Klasse, 203076), (S-Klasse, 221086, 221186), (S-Klasse, 221084, 221184), (S-Klasse, 221080, 221180), (C-Klasse, 204008), (S-Klasse, 221054), (S-Klasse, 221077), (C-Klasse, 204041), (C-Klasse, 204054), (C-Klasse, 204241), (C-Klasse, 204046), (C-Klasse, 204246), (S-Klasse, 221087, 221187), (C-Klasse, 204052), (C-Klasse, 204081), (C-Klasse, 204087), (C-Klasse, 204252), (C-Klasse, 204254), (C-Klasse, 204256), (C-Klasse, 204007), (C-Klasse, 204207), (C-Klasse, 204289), (C-Klasse, 204089), (C-Klasse, 204208), (C-Klasse, 204056), (S-Klasse, 221177), (C-Klasse, 204222), (C-Klasse, 203007, 203207, 203707), (C-Klasse, 203008, 203208, 203708), (C-Klasse, 204201), (C-Klasse, 204044, 204045), (C-Klasse, 204077), (S-Klasse, 221054, 221154), (GLK-Klasse, 204902), (C-Klasse, 204044), (C-Klasse, 204006), (C-Klasse, 204245), (C-Klasse, 204065), (GLK-Klasse, 204987), (S-Klasse, 221095, 221195), (C-Klasse, 204249), (C-Klasse, 204248), (C-Klasse, 204025), (C-Klasse, 204049), (C-Klasse, 204001), (C-Klasse, 204048), (C-Klasse, 204002), (S-Klasse, 221080, 221081), (S-Klasse, None), (C-Klasse, 204045), (S-Klasse, 221026, 221126), (S-Klasse, 221057, 221157), (S-Klasse, 221074, 221174), (S-Klasse, 221082, 221182), (S-Klasse, 221094, 221194), (C-Klasse, 204303), (C-Klasse, 204347), (C-Klasse, 204377), (C-Klasse, 204078), (C-Klasse, 204003), (C-Klasse, 204057), (S-Klasse, 221003, 221103), (C-Klasse, 204202), (C-Klasse, 204285), (C-Klasse, 204231), (C-Klasse, 204357), (GL-Klasse, 166823, 166824), (GL-Klasse, 166873), (CLK-Klasse, 209316), (C-Klasse,), (S-Klasse, 221073, 221173), (GLS-Klasse, 166824), (S-Klasse, 221083, 221183), (ML-Klasse, 166), (GLS-Klasse, 166873), (GLS-Klasse, 166875), (CLC-Klasse, 203707), (GLK-Klasse, 204956), (C-Klasse, 203706), (ML-Klasse, 163175), (C-Klasse, 204031), (GL-Klasse, 166824), (GL-Klasse, 166872), (GL-Klasse, None), (GLK-Klasse, 204990), (S-Klasse,))

Adjusting the headlights ((E-Klasse, 211254), (E-Klasse, 211070), (E-Klasse, 211065), (E-Klasse, 211061), (E-Klasse, 211016), (E-Klasse, 211006), (E-Klasse, 211026), (E-Klasse, 211042), (E-Klasse, 211076), (E-Klasse, 211206), (E-Klasse, 211216), (E-Klasse, 211261), (E-Klasse, 211028), (E-Klasse, 211080), (E-Klasse, 211082), (E-Klasse, 211083), (E-Klasse, 211280), (E-Klasse, 211282), (E-Klasse, 211283), (E-Klasse, 211276), (E-Klasse, 211226), (E-Klasse, 211270), (E-Klasse, 211265), (E-Klasse, 211242), (E-Klasse, 211004), (E-Klasse,



Diagnostic devices

211223), (E-Klasse, 211023), (E-Klasse, 211087), (E-Klasse, 211256), (E-Klasse, 211056), (E-Klasse, 211287), (CLS-Klasse, 219322), (CLS-Klasse, 219356), (CLS-Klasse, 219375), (CLS-Klasse, 219376), (E-Klasse, 211022), (E-Klasse, 211020), (E-Klasse, 211089), (E-Klasse, 211084), (E-Klasse, 211289), (E-Klasse, 211284), (E-Klasse, 211620), (E-Klasse, 211054), (E-Klasse, 211092), (E-Klasse, 211292), (E-Klasse, 211029), (E-Klasse, 211222), (E-Klasse, 211220), (E-Klasse, 211007), (E-Klasse, 211008), (E-Klasse, 211208), (E-Klasse, 211041), (E-Klasse, 211072), (E-Klasse, 211241), (E-Klasse, 211272), (CLS-Klasse, 219372), (E-Klasse, 211090), (E-Klasse, 211077), (E-Klasse, 211277), (CLS-Klasse, 219377), (CLS-Klasse, 219357), (E-Klasse, 211052), (E-Klasse, 211252), (E-Klasse, 211207), (E-Klasse, 211024), (E-Klasse, 211057), (E-Klasse, 211290), (E-Klasse, 211024, 211052), (E-Klasse, 211257), (CLS-Klasse, 219354), (E-Klasse,), (AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (AMG GT, 290658), (AMG GT, 290679))

Learning the power windows ((AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (AMG GT, 290658), (AMG GT, 290679))

Resetting adaptation values of front radar sensor ((AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (S-Klasse, 223030, 223130), (AMG GT, 290658), (GLE-Klasse, 167354), (S-Klasse, 223031, 223131), (S-Klasse, 223033, 223133), (S-Klasse, 223061, 223161), (S-Klasse, 223063, 223163), (S-Klasse, 223068, 223168), (S-Klasse, 223076, 223176), (S-Klasse, 223060, 223160), (S-Klasse, 223976), (AMG GT, 290679), (C-Klasse, 206245), (S-Klasse, 223069), (GLC-Klasse, 254651), (GLC-Klasse, 254605), (GLC-Klasse, 254647), (GLC-Klasse, 254))

Learning the recirculation air flap stop ((SLK-Klasse, 170444), (SLK-Klasse, 170449))

Resetting mass airflow sensor adaptation values ((Sprinter, 906), (V-Klasse, 639811, 639813, 639815), (V-Klasse, 639701, 639703, 639705), (V-Klasse, 639601, 639603, 639605), (G-Klasse, 463340, 463341, 463343), (G-Klasse, 463303), (G-Klasse, 463340), (G-Klasse, 463341), (G-Klasse, 463041), (Sprinter, 906111, 906113, 906211, 906213, 906611, 906613))

Resetting the quantity mean value adaptation ((ML-Klasse, 164124, 164125), (Sprinter, 906), (C-Klasse, 203004), (C-Klasse, 203008, 203708), (E-Klasse, 211006), (E-Klasse, 211206), (C-Klasse, 203207), (C-Klasse, 203007), (C-Klasse, 203707), (E-Klasse, 211004), (C-Klasse, 203006), (C-Klasse, 203708), (C-Klasse, 203208), (C-Klasse, 203007, 203707), (C-Klasse, 203206), (C-Klasse, 203008), (CLK-Klasse, 209308), (C-Klasse, 203204), (C-Klasse, 203204, 203207), (G-Klasse, 463340, 463341, 463343), (G-Klasse, 463303), (ML-Klasse, 164121), (C-Klasse, 203007, 203207, 203707), (CLC-Klasse, 203708), (C-Klasse, 203008, 203208, 203708), (CLC-Klasse, 203707), (G-Klasse, 463340), (G-Klasse, 463341), (GL-Klasse, 164824, 164825), (R-Klasse, 251124, 251125), (G-Klasse, 463041), (R-Klasse, 251023, 251123), (GL-Klasse, 164823), (R-Klasse, 251021, 251121, 251026, 251126), (R-Klasse,), (GL-Klasse,), (ML-Klasse, None), (GL-Klasse, 164822), (C-Klasse, 203706), (Sprinter, 906111, 906113, 906211, 906213, 906611, 906613), (E-Klasse, 211606))

Calibrating the camera ECU ((ML-Klasse, 166074), (GL-Klasse, 166874), (GLE-Klasse, 166004), (GLE-Klasse, 166062), (GLE-Klasse, 166024), (GLE-Klasse, 166056), (GLE-Klasse, 166064), (GLE-Klasse, 166073), (GLE-Klasse, 166063), (GLE-Klasse, 166074), (GLE-Klasse, 166075, 166875), (GLE-Klasse, 166006), (AMG GT, 190377), (AMG GT, 190378), (E-Klasse, 213066), (E-Klasse, 213043), (E-Klasse, 213045), (E-Klasse, 238342), (E-Klasse, 238314), (E-Klasse, 238348), (E-Klasse, 238334), (E-Klasse, 238343), (E-Klasse, 238365), (E-Klasse, 238366), (E-Klasse, 213143), (E-Klasse, 213142), (E-Klasse, 213148), (AMG GT, 190379), (AMG GT, 190477), (AMG GT, 190480), (AMG GT, 190380), (E-Klasse, 238443), (E-Klasse, 238315), (E-Klasse, 238442), (E-Klasse, 238414), (E-Klasse, 238466), (E-Klasse, 238448), (AMG GT, 190478), (C-Klasse, 205477), (C-Klasse, 205377), (C-Klasse, 205314), (C-Klasse, 205378), (E-Klasse, 238318), (C-Klasse, 205064), (C-Klasse, 205464), (C-Klasse, 205364), (C-Klasse, 205264), (E-Klasse, 213023), (C-Klasse, 205448), (C-Klasse, 205383), (E-Klasse, 238418), (E-Klasse, 238361), (C-Klasse, 205483), (C-Klasse, 205418), (C-Klasse, 205340), (C-Klasse, 205440), (C-Klasse, 205283), (C-Klasse, 205318), (C-Klasse, 205466), (C-Klasse, 205066), (C-Klasse, 205240), (C-Klasse, 205044), (C-Klasse, 205213), (C-Klasse, 205019),



Diagnostic devices

(C-Klasse, 205266), (C-Klasse, 205040), (C-Klasse, 205018), (C-Klasse, 205013), (C-Klasse, 205075), (C-Klasse, 205076), (C-Klasse, 205476), (C-Klasse, 205376), (C-Klasse, 205276), (E-Klasse, 213068), (ML-Klasse, 166003,166004), (ML-Klasse, 166024), (ML-Klasse, 166057), (ML-Klasse, 166073), (GL-Klasse, 166823,166824), (GL-Klasse, 166873), (GLS-Klasse, 166824), (ML-Klasse, 166), (B-Klasse, 242848), (GLS-Klasse, 166873), (GLS-Klasse, 166875), (E-Klasse, 213042), (E-Klasse, 213004), (GLE-Klasse, 166057), (E-Klasse, 213242), (E-Klasse, 213204), (E-Klasse, 213245), (E-Klasse, 213031), (E-Klasse, 213033), (E-Klasse, 213264), (E-Klasse, 213271), (E-Klasse, 213266), (E-Klasse, 213064), (E-Klasse, 213071), (E-Klasse, 213005), (E-Klasse, 213040), (E-Klasse, 213013), (E-Klasse, 213050), (E-Klasse, 213048), (E-Klasse, 213217), (E-Klasse, 213237), (E-Klasse, 213234), (E-Klasse, 213213), (E-Klasse, 213205), (E-Klasse, 213233), (E-Klasse, 213243), (E-Klasse, 213034), (E-Klasse, 213049), (E-Klasse, 213089), (E-Klasse, 213088), (E-Klasse, 213104), (E-Klasse, 213140), (E-Klasse, 213288), (E-Klasse, 213289), (E-Klasse, 238434), (C-Klasse, 205078), (C-Klasse, 205077), (C-Klasse, 205014), (C-Klasse, 205214), (C-Klasse, 205278), (C-Klasse, 205414), (C-Klasse, 205478), (C-Klasse, 205277), (E-Klasse, 213008), (E-Klasse, 213208), (E-Klasse, 238415), (E-Klasse, 238385), (CLS-Klasse, 257321), (CLS-Klasse, 257323), (CLS-Klasse, 257359), (E-Klasse, 238485), (E-Klasse, 213061), (C-Klasse, 205000), (C-Klasse, 205001), (C-Klasse, 205011), (C-Klasse, 205015), (C-Klasse, 205083), (C-Klasse, 205200), (C-Klasse, 205201), (C-Klasse, 205211), (C-Klasse, 205215), (CLS-Klasse, 257361), (C-Klasse, 205401), (C-Klasse, 205411), (C-Klasse, 205487), (C-Klasse, 205486), (C-Klasse, 205415), (C-Klasse, 205301), (C-Klasse, 205311), (C-Klasse, 205386), (C-Klasse, 205387), (C-Klasse, 205244), (C-Klasse, 205287), (C-Klasse, 205286), (C-Klasse, 205218), (C-Klasse, 205219), (C-Klasse, 205086), (C-Klasse, 205087), (E-Klasse, 213012), (E-Klasse, 213016), (E-Klasse, 213053), (E-Klasse, 213022), (E-Klasse, 213220), (E-Klasse, 213085), (CLS-Klasse, 257350), (CLS-Klasse, 257320), (E-Klasse, 238420), (E-Klasse, 238423), (E-Klasse, 238461), (AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (CLS-Klasse, 257318), (CLS-Klasse, 257351), (C-Klasse, 205084), (C-Klasse, 205284), (E-Klasse, 213080), (E-Klasse, 213087), (E-Klasse, 213083), (E-Klasse, 238480), (E-Klasse, 238487), (E-Klasse, 238483), (E-Klasse, 238380), (E-Klasse, 238387), (E-Klasse, 238383), (E-Klasse, 213280), (E-Klasse, 213287), (E-Klasse, 213283), (C-Klasse, 205319), (C-Klasse, 205315), (C-Klasse, 205275), (C-Klasse, 205384), (C-Klasse, 205484), (E-Klasse, 213222), (E-Klasse, 213077), (E-Klasse, 213078), (E-Klasse, 213054), (E-Klasse, 213011), (E-Klasse, 213), (E-Klasse, 213206), (E-Klasse, 213253), (E-Klasse, 238468), (E-Klasse, 213212), (E-Klasse, 213020), (E-Klasse, 213223), (E-Klasse, 213227), (E-Klasse, 213268), (E-Klasse, 213261), (AMG GT, 190479), (E-Klasse, 213211), (E-Klasse, 238368), (AMG GT, 290658), (C-Klasse, 205080), (C-Klasse, 205480), (C-Klasse, 205380), (C-Klasse, 205280), (CLS-Klasse, 257314), (CLS-Klasse, 257348), (CLS-Klasse, 257358), (E-Klasse, 238465), (E-Klasse, 238467), (E-Klasse, 238386), (E-Klasse, 238320), (E-Klasse, 238323), (E-Klasse, 238367), (E-Klasse, 213216), (GL-Klasse, 166824), (GL-Klasse, 166872), (GL-Klasse, None), (GLE-Klasse, 166058), (E-Klasse, 213053,213050), (E-Klasse, 213086), (AMG GT, 190381), (AMG GT, 190382), (C-Klasse, 205079), (E-Klasse, 213279), (E-Klasse, 238458), (E-Klasse, 238459), (E-Klasse, 238358), (E-Klasse, 238359), (GLE-Klasse, 167354), (AMG GT, 290679))

Resetting adaptation values of radar sensor rear ((AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (AMG GT, 290658), (GLE-Klasse, 167354), (AMG GT, 290679), (C-Klasse, 206245), (GLC-Klasse, 254651), (GLC-Klasse, 254605), (GLC-Klasse, 254647), (GLC-Klasse, 254))

Initializing the adaptive cruise control ((AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (AMG GT, 290658), (GLE-Klasse, 167354), (AMG GT, 290679), (C-Klasse, 206245), (GLC-Klasse, 254651), (GLC-Klasse, 254605), (GLC-Klasse, 254647), (GLC-Klasse, 254))

Calibrating the camera ((GLE-Klasse, 292323,292324), (GLE-Klasse, 292356), (GLE-Klasse, 292364), (GLE-Klasse, 292373), (GLE-Klasse, 292374), (GLE-Klasse, 292375), (GLE-Klasse, 292362), (GLE-Klasse, 292062), (GLE-Klasse, 292324))

Checking the transmission fluid level ((C-Klasse, 205009), (C-Klasse, 205066), (C-Klasse, 205040), (C-Klasse, 205036), (C-Klasse, 205042), (C-Klasse, 205007), (C-Klasse, 205012), (C-Klasse, 205006), (C-Klasse, 205045), (C-Klasse, 205002), (C-Klasse, 205204), (C-Klasse,



Diagnostic devices

205240), (C-Klasse, 205044), (C-Klasse, 205236), (C-Klasse, 205037), (C-Klasse, 205004), (C-Klasse, 205003), (C-Klasse, 205008), (C-Klasse, 205048), (GLA-Klasse, 156902), (GLA-Klasse, 156908), (GLA-Klasse, 156903), (GLA-Klasse, 156905), (C-Klasse, 205247), (C-Klasse, 205207), (C-Klasse, 205287), (C-Klasse, 205087), (C-Klasse, 205208), (C-Klasse, 205209), (C-Klasse, 205266), (C-Klasse, 205237), (C-Klasse, 205212), (C-Klasse, 205342), (C-Klasse, 205304), (C-Klasse, 205345), (C-Klasse, 205308), (C-Klasse, 205348), (C-Klasse, 205043), (C-Klasse, 205005), (C-Klasse, 205064), (C-Klasse, 205264), (C-Klasse, 205205), (C-Klasse, 205243), (C-Klasse, 205448), (C-Klasse, 205464), (C-Klasse, 205466), (C-Klasse, 205405), (C-Klasse, 205443), (C-Klasse, 205408), (C-Klasse, 205445), (C-Klasse, 205404), (C-Klasse, 205440), (C-Klasse, 205442), (C-Klasse, 205340), (C-Klasse, 205343), (C-Klasse, 205305), (C-Klasse, 205309), (C-Klasse, 205366), (C-Klasse, 205364), (C-Klasse, 205242), (C-Klasse, 205245), (GLA-Klasse, 156947), (C-Klasse, 205054), (C-Klasse, 205213), (C-Klasse, 205140), (C-Klasse, 205286), (SL-Klasse, 231457), (SL-Klasse, 231473), (SL-Klasse, 231474), (A-Klasse, 176012), (A-Klasse, 176042), (A-Klasse, 176001), (A-Klasse, 176043), (A-Klasse, 176044), (A-Klasse, 176000), (A-Klasse, 176003), (A-Klasse, 176046), (A-Klasse, 176052), (CLA-Klasse, 117342), (CLA-Klasse, 117343), (CLA-Klasse, 117303), (CLA-Klasse, 117344), (A-Klasse, 176011), (A-Klasse, 176005), (A-Klasse, 176002), (A-Klasse, 176008), (S-Klasse, 222004,222104), (S-Klasse, 222033,222133), (S-Klasse, 222032,222123,222132), (S-Klasse, 222165), (S-Klasse, 222057,222157), (S-Klasse, 222082), (S-Klasse, 222176), (S-Klasse, 222179), (S-Klasse, 222077,222177), (S-Klasse, 222133), (S-Klasse, 222085), (S-Klasse, 222178), (SL-Klasse, 231479), (A-Klasse, 176047), (CLA-Klasse, 117302), (CLA-Klasse, 117305), (CLA-Klasse, 117346), (CLA-Klasse, 117352), (CLA-Klasse, 117308), (CLA-Klasse, 117312), (CLA-Klasse, 117301), (S-Klasse, 222067,222167), (S-Klasse, 222063,222163), (SL-Klasse, 231465), (CLA-Klasse, 117952), (A-Klasse, 176041), (S-Klasse, 222185), (S-Klasse, 222032,222132), (C-Klasse, 205086), (C-Klasse, 205387), (A-Klasse, 176051), (C-Klasse, 205047), (CLA-Klasse, 117951), (CLA-Klasse, 117946), (CLA-Klasse, 117944), (CLA-Klasse, 117905), (CLA-Klasse, 117902), (CLA-Klasse, 117903), (CLA-Klasse, 117943), (CLA-Klasse, 117912), (CLA-Klasse, 117942), (GLA-Klasse, 156952), (GLA-Klasse, 156912), (S-Klasse, 222967), (S-Klasse, 222982), (CLA-Klasse, 117350), (A-Klasse, 176050), (C-Klasse, 205386), (S-Klasse, 222976), (S-Klasse, 222162), (SL-Klasse, 231466), (C-Klasse, 205244), (C-Klasse, 205248), (CLA-Klasse, 117351), (C-Klasse, 205486), (C-Klasse, 205487), (CLA-Klasse, 117347), (CLA-Klasse, 117947), (C-Klasse, 205203), (CLA-Klasse, 117908), (S-Klasse, 222985), (S-Klasse, 222983), (S-Klasse, 222980), (S-Klasse, 222964), (S-Klasse, 222986), (S-Klasse, 222035,222135), (S-Klasse, 222021,222121), (S-Klasse, 222059), (S-Klasse, 222064), (S-Klasse, 222086,222186), (S-Klasse, 222188), (S-Klasse, 222020,222120), (S-Klasse, 222058), (S-Klasse, 222066), (S-Klasse, 222060,222160), (S-Klasse, 222083,222183), (S-Klasse, 222073), (S-Klasse, 222187), (S-Klasse, 222034,222134), (S-Klasse, 221179), (GLA-Klasse, 156946), (C-Klasse, 205049), (C-Klasse, 205053), (C-Klasse, 205449), (C-Klasse, 205349), (C-Klasse, 205253), (CLA-Klasse,), (CLA-Klasse, 117345), (G-Klasse, 463350), (GLA-Klasse, 156944), (S-Klasse, 222082,222182), (GLE-Klasse, 167354))

Codings

Registering the battery ((AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (AMG GT, 290658), (GLE-Klasse, 167354), (AMG GT, 290679))

Coding the rain/light sensor ((AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (AMG GT, 290658), (GLE-Klasse, 167354), (AMG GT, 290679))

Service resets



Diagnostic devices

DolP/CAN	(S-Klasse, 223030,223130), (S-Klasse, 223031,223131), (S-Klasse, 223033,223133), (S-Klasse, 223061,223161), (S-Klasse, 223063,223163), (S-Klasse, 223068,223168), (S-Klasse, 223076,223176), (S-Klasse, 223060,223160), (S-Klasse, 223976), (C-Klasse, 206245), (S-Klasse, 223069), (GLC-Klasse, 254651), (GLC-Klasse, 254605), (GLC-Klasse, 254647), (GLC-Klasse, 254)
Cyber Security Management (CSM)	(AMG GT, 190377), (AMG GT, 190378), (AMG GT, 190379), (AMG GT, 190477), (AMG GT, 190480), (AMG GT, 190380), (AMG GT, 190478), (AMG GT, 290659), (AMG GT, 290661), (AMG GT, 290688), (AMG GT, 290689), (E-Klasse, 213054), (E-Klasse, 213011), (E-Klasse, 213023), (E-Klasse, 213), (E-Klasse, 213206), (E-Klasse, 213008), (E-Klasse, 213253), (AMG GT, 190479), (E-Klasse, 213016), (E-Klasse, 213211), (S-Klasse, 223030,223130), (AMG GT, 290658), (AMG GT, 190381), (AMG GT, 190382), (E-Klasse, 213227), (E-Klasse, 213216), (E-Klasse, 213223), (S-Klasse, 223031,223131), (S-Klasse, 223033,223133), (S-Klasse, 223061,223161), (S-Klasse, 223063,223163), (S-Klasse, 223068,223168), (S-Klasse, 223076,223176), (S-Klasse, 223060,223160), (Citan, 420653,420753), (Citan, 420663,420763), (Citan, 420613,420713), (Citan, 420623,420723), (Citan, 420633), (S-Klasse, 223976), (AMG GT, 290679), (C-Klasse, 206245), (S-Klasse, 223069), (T-Klasse, 420853), (T-Klasse, 420823), (T-Klasse, 420863), (T-Klasse, 420833), (GLC-Klasse, 254651), (GLC-Klasse, 254605), (GLC-Klasse, 254647), (GLC-Klasse, 254)
Capable for diagnostics only with mega macs X	

Mini

Trouble codes	
Parameters	
Actuators	
Basic settings	<p>Initializing the overhead control panel ((F54 Clubman, F54), (F57 Cabrio, F57), (F60 Countryman, F60), (F54 Clubman, FMK), (F56 One/Cooper, F56), (F55 One/Cooper, F55))</p> <p>Learning the steering-angle sensor ((R60 Countryman, R60), (R56 One/Cooper, R56), (R55 Clubman, R55), (R57 Cabrio, R57), (R58 Coupe, R58), (R59 Roadster, R59), (R61 Paceman, R61))</p> <p>Resetting mass airflow sensor adaptation values ((F56 One/Cooper, F56), (F55 One/Cooper, F55), (F54 Clubman, F54), (F57 Cabrio, F57), (F60 Countryman, F60))</p> <p>Adapting the A/C compressor ((F60 Countryman, F60), (F54 Clubman, F54), (F56 One/Cooper, F56), (F54 Clubman, FMK))</p> <p>Calibrating the front camera ((F54 Clubman, F54), (F60 Countryman, F60), (F54 Clubman, FMK), (F56 One/Cooper, F56), (F55 One/Cooper, F55))</p> <p>Initializing the rain/light sensor ((F54 Clubman, F54), (F57 Cabrio, F57), (F60 Countryman, F60), (F54 Clubman, FMK), (F56 One/Cooper, F56), (F55 One/Cooper, F55))</p> <p>Initializing the ride height sensor ((F54 Clubman, F54), (F56 One/Cooper, F56), (F55 One/Cooper, F55), (F54 Clubman, FMK))</p> <p>Initializing the A/C flap actuators ((F56 One/Cooper, F56), (F55 One/Cooper, F55), (F57 Cabrio, F57), (F60 Countryman, F60))</p> <p>Bleeding the electronic stability control ((F56 One/Cooper, F56), (F55 One/Cooper, F55), (F54 Clubman, F54), (F57 Cabrio, F57), (F60 Countryman, F60), (F54 Clubman, FMK))</p> <p>Resetting gearbox learning values ((F54 Clubman, F54), (R60 Countryman, R60), (R59 Roadster, R59), (F56 One/Cooper, F56), (F55 One/Cooper, F55), (F54 Clubman, FMK))</p>



Diagnostic devices

Unlocking aux. heater/independent car heater ((F56 One/Cooper, F56), (F55 One/Cooper, F55), (F57 Cabrio, F57), (F54 Clubman, F54), (F60 Countryman, F60), (F54 Clubman, FMK))

Codings

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

Mitsubishi

Trouble codes (Outlander, CW)

Parameters (Outlander, CW)

Actuators

Basic settings

Learning the steering-angle sensor ((Lancer, CX), (Lancer, CY), (Outlander, CB), (Outlander, CW), (Lancer, CZ), (Pajero, V80), (ASX, GA), (Lancer, CS), (Space Star, A00), (Colt, Z30), (L200, KB), (L200, KA), (Lancer, CT), (L200, NA), (Pajero, V85), (L200, KJ), (Pajero, V86), (Eclipse Cross, GK), (Outlander,), (Diverse, GK), (ASX,))

Initializing the high-pressure fuel pump ((Pajero, V80), (L200, KB), (L200, KA), (ASX, GA), (L200, NA), (Lancer, CY), (Outlander, CB), (Outlander, CW), (Pajero, V85), (L200, KJ), (Pajero, V86), (Eclipse Cross, GK), (Diverse, GK))

Initializing the yaw rate sensor ((Space Star, A00), (Eclipse Cross, GK))

Initialising adaptive functions ((Lancer, CX), (Outlander, CB), (Outlander, CW), (Lancer, CY), (Lancer, CZ), (ASX, GA), (Space Star, A00), (Eclipse Cross, GK), (ASX,))

Changing brake linings ((Outlander, CW), (Eclipse Cross, GK))

Calibrating the camera ECU ((L200, KJ))

Resetting learned values of the battery monitoring ECU ((L200, KJ), (Eclipse Cross, GK), (Diverse, GK))

Codings

Service resets



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

Nissan

Trouble codes

Parameters

Actuators

Basic settings

Learning the steering-angle sensor ((Juke, F15), (Pathfinder, R51), (Murano, Z51), (370 Z, Z34), (NV 200 / Evalia, M20), (Qashqai, J10), (X-Trail, T31), (Micra, K13), (Navara, D40), (Leaf, ZE0), (NV 400, X62), (Qashqai, J11), (Note, E12), (Pulsar, C13), (X-Trail, T32), (Navara, D23), (Micra, K14), (Leaf, ZE1), (Patrol, Y62), (Altima, L34), (Altima, L33), (Maxima, A36))

Initializing the EGR valve ((Pathfinder, R51))

Initializing the yaw rate sensor ((Qashqai, J11), (Leaf, ZE1))

Initializing the rain/light sensor ((Pulsar, C13))

Learning the flywheel ((Micra, K14))

Initializing the ride height sensor ((Leaf, ZE0))

Learning the throttle valve ((Navara, D40), (Pathfinder, R51), (Micra, K14))

Resetting learned values of fuel injector of soot particulate filter ((Navara, D40))

Resetting the mixture adjustment ((Micra, K14))

Initialize acceleration sensor ((Pulsar, C13))

Codings

Service resets

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM)

Capable for diagnostics
only with Cyber Security
Management



Diagnostic devices

Opel/Vauxhall

Trouble codes	(Vectra-C, J96)
Parameters	(Vectra-C, J96)
Actuators	(Vectra-C, J96)
Basic settings	<p>Learning the steering-angle sensor ((Combo-E, X19))</p> <p>Resetting the mixture adjustment ((Insignia-B, Z18))</p> <p>Resetting engine adaptation values ((Movano-A, X70), (Movano-A, U9))</p> <p>Adjusting the xenon headlight ((Meriva-A, X 01), (Astra-G, T98))</p> <p>Resetting the diesel exhaust fluid level ((Mokka, J13), (Insignia-B, Z18), (Insignia-B, Z-B))</p> <p>Learning the lambda sensor ((Astra-H, A04))</p> <p>Resetting learned values of idle speed stabilizer ((Insignia-B, Z18))</p> <p>MTA EasyTronic transmission ((Zafira-B, A05), (Zafira-B, A-H/Monocab))</p> <p>Replacing/filling the regeneration additive container ((Grandland X, A18))</p> <p>Initializing the fuel pressure sensor or the fuel rail ((Astra-J, P10), (Mokka, J13), (Zafira-C, P12))</p> <p>Resetting the fluid level of the regeneration additive system ((Grandland X, A18))</p> <p>Resetting oxygen sensor adaptation values ((Astra-G, T98), (Corsa-D, S07))</p> <p>Learning the turbocharger ((Astra-J, P10))</p> <p>Resetting learned values of NOx adsorption catalyst ((Astra-K, B16), (Insignia-A, G09), (Astra-K, B-K))</p> <p>Reset the adaptation values of NOx sensor 1. ((Astra-K, B16), (Astra-K, B-K))</p> <p>Resetting learned values of the oxidation catalyst ((Insignia-B, Z18), (Insignia-B, Z-B))</p> <p>Regenerating the soot particulate filter ((Insignia-B, Z18), (Insignia-B, Z-B))</p> <p>Resetting gen. ECU learning values ((Astra-G, T98), (Meriva-A, X 01))</p> <p>Initializing the crankshaft position sensor ((Insignia-A, G09))</p> <p>Reset learned values of glow plugs. ((Zafira-C, P12))</p> <p>Initializing the rotation rate/acceleration sensor ((Crossland X, P17), (Grandland X, A18))</p> <p>Initializing the crankshaft position ((Insignia-B, Z18), (Insignia-B, Z-B))</p> <p>Resetting mass airflow sensor adaptation values ((Astra-H, A04))</p> <p>Initializing the clutch pedal position ((Zafira-C, P12), (Corsa-D, S07), (Insignia-B, Z18), (Insignia-B, Z-B))</p> <p>Replace the battery. ((Combo-E, X19), (Crossland X, P17), (Grandland X, A18))</p> <p>Resetting learned values of throttle valve actuator ((Astra-J, P10), (Zafira-C, P12), (Astra-J, P-J/SW))</p> <p>Reset the adaptation values of NOx sensor 2. ((Astra-K, B16), (Astra-K, B-K))</p> <p>Initializing the soot particulate filter pressure sensor ((Combo-E, X19))</p> <p>Resetting oxygen sensor adaptation values ((Astra-H, A04), (Antara, L07))</p>



Diagnostic devices

Resetting differential pressure sensor learning values ((Astra-H, A04), (Astra-J, P10), (Insignia-A, G09))

Initializing the exhaust temperature sensor ((Astra-J, P10), (Zafira-C, P12), (Mokka, J13))

Initializing the air distribution flap actuator ((Corsa-F, X20), (Mokka-B, U))

Resetting learned values of idle speed stabilizer ((Mokka, J13), (Meriva-B, S-D), (Corsa-D, S07))

Initializing the diesel exhaust fluid pump module ((Combo-E, X19))

Resetting the learned values for DEF injector ((Grandland X, A18), (Crossland X, P17))

Resetting catalyst adaptation values ((Astra-H, A04), (Corsa-F, X20))

Resetting the mixture adjustment ((Astra-J, P10), (Zafira-C, P12), (Astra-J, P-J/SW))

Regenerating the soot particulate filter ((Astra-J, P10), (Astra-H, A04), (Zafira-C, P12), (Insignia-A, G09), (Mokka, J13), (Corsa-D, S07))

Calibrate steering-angle sensor/sensor group ((Vectra-C, Vectra/Lim), (Vectra-C, J96), (Signum, Z03))

Bleeding the ABS hydraulic unit ((Zafira-Life, K0), (Vivaro-C, K0), (Vivaro-C, EK0), (Zafira-Life, EK0), (Vivaro-C, V))

Reset fuel pump learning values ((Meriva-A, X 01))

Resetting adaptation values of the longitudinal acceleration sensor ((Corsa-F, X20))

Calibrating the tire pressure monitoring system ((Karl/Viva, C16))

Resetting the soot particulate filter ((Zafira-C, P12), (Insignia-A, G09), (Mokka, J13), (Corsa-D, S07), (Astra-J, P10))

Initializing the neutral position sensor ((Corsa-D, S07), (Insignia-B, Z18), (Insignia-B, Z-B))

Calibrating the battery current sensor ((Meriva-B, S-D))

Codings

Coding injectors ((Astra-K, B16), (Astra-K, B-K))

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

Peugeot

Trouble codes

(308, F)

Parameters

(308, F)



Diagnostic devices

Actuators	(308, F)
Basic settings	<p>Learning the steering-angle sensor ((Partner-III, 7), (208, C), (4008, B), (301, DD), (406, 8), (406, 8 (Nouvelle)), (607, 9), (1007, K), (207, W), (4007, V), (2008, CU), (5008, 0A), (Expert-IV, V), (Traveller, V), (3008, M), (5008, M), (308, 4), (308, L), (2008, C), (207, W*****), (3008, 0U), (Rifter, E), (508, F), (Partner-IV, E), (208, U), (2008, U), (308,), (308, F))</p> <p>Learning the flywheel ((308, F))</p> <p>Adjusting the headlights ((308, 4), (308, 4 ok), (5008, 0A), (508, 8), (3008, 0U), (3008, HU), (208, C), (301, DD), (RCZ, 4), (2008, CU), (3008, M), (5008, M), (308, L), (RCZ, 4J), (2008, C), (308, 4****), (508, F), (308,), (Partner-IV, E))</p> <p>Adapting the accelerator sensor ((307, 3), (807, E), (Expert-I, 222), (Expert-II, B), (206, 2), (807, V), (407, 6), (308, L), (2008, U))</p> <p>Adjusting the xenon headlight ((307, 3))</p> <p>Learning the lambda sensor ((208, C), (2008, CU))</p> <p>Self-adaptation of A/C system ((Expert-III, XX))</p> <p>Initializing the crankshaft sensor ((308, F))</p> <p>Initializing the fuel pressure sensor or the fuel rail ((308, F))</p> <p>Initialize starter ((308, F))</p> <p>Initialising the boost pressure regulator ((308, F))</p> <p>Adapting the longitudinal acceleration sensor ((Partner-III, 7), (308, 4), (308, L), (308,), (308, F))</p> <p>Initializing the mass airflow sensor ((308, F))</p> <p>Learning the turbocharger ((208, C), (301, DD), (Expert-III, XX), (2008, CU), (308, F))</p> <p>Replacing the lean NOx catalyst ((5008, 0A))</p> <p>Initializing the fuel level ((308, F))</p> <p>Fill the DEF tank ((308, F))</p> <p>Adapting the clutch assembly ((308, F))</p> <p>Regenerating the soot particulate filter ((Boxer-III, Y (EU6)))</p> <p>Resetting gearbox learning values ((307, 3))</p> <p>Replace brake parts ((Rifter, E), (508, F), (Partner-IV, E), (208, U), (2008, U), (308, F))</p> <p>Replacing engine parts ((Partner-I, 5), (Partner-II, G), (308, F))</p> <p>Initializing the high-pressure fuel pump ((308, F))</p> <p>Initializing the air metering system ((308, F))</p> <p>Initialising adaptive functions ((207, W))</p> <p>Resetting all engine adaptation values ((308, F))</p> <p>Reset the adaptation values of NOx sensor 2. ((308, F))</p> <p>Initializing the soot particulate filter/lean NOx catalyst ((308, F))</p> <p>Reset the adaptation values of NOx sensor 1. ((308, F))</p> <p>Initializing the alternator ((308, F))</p> <p>Adapting the EGR flap ((1007, K))</p>



Diagnostic devices

Bleeding the ABS/ESC system ((Partner-III, 7), (308, 4), (308, L), (3008, 0U), (308,), (308, F))
Leaving the ECO mode ((308, F))
Initialising high-pressure pump ((308, 4 ok), (407, 6), (508, 8), (308, 4), (407, 6*****))
Replacing the particle filter ((208, C), (308, L), (5008, M), (3008, M), (2008, C), (301, DD), (5008, 0A), (Traveller, V), (308,), (308, F))
Calibrating the camera ECU ((Boxer-III, Y (EU6)), (208, U), (2008, U), (308, F))
Initializing the EGR valve ((1007, K), (308, F))
Initializing the diesel exhaust fluid injector ((308, F))
MM G6 / 8P ((405, 4 B))
Replacing the differential pressure sensor ((308, F))
Learning the turbocharger ((208, C), (308, L), (5008, M), (3008, M), (2008, C), (Rifter, E), (508, F), (Partner-IV, E), (301, DD), (Traveller, V), (208, U), (2008, U), (308,))

Codings Coding injectors ((208, C), (308, F))

Service resets (308, F)

DoIP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

Porsche

Trouble codes (Cayenne (9Yx), 9YA), (Panamera (971), 971)

Parameters (911 (992), 992), (Cayenne (9Yx), 9YA), (Panamera (971), 971), (Taycan (Y1A), Y1A)

Actuators (Cayenne (9Yx), 9YA), (Panamera (971), 971)

Basic settings
Initializing electric seats ((Cayenne (9Yx), 9YA))
Bleeding the cooling system ((Macan (95B), 95B))
Adapting the radiator shutter 1 ((Cayenne (92A), 92A), (Macan (95B), 95B))
Initializing the adaptive cruise control ((Cayenne (9Yx), 9YA))
Resetting engine adaptation values ((Panamera (971), 971), (Macan (95B), 95B))
Learning the steering-angle sensor ((Cayenne (9Yx), 9YA))
Initializing the sunroof actuator ((Cayenne (9Yx), 9YA))



Diagnostic devices

Calibrating the camera ECU ((Panamera (970), 970), (911 (991), 991), (Boxster (981), 981), (Cayman (981), 981), (Boxster 718 (982), 982), (Cayman 718 (982), 982), (Cayenne (9Yx), 9YA))

Adapting the fuel burning heater remote control ((Cayenne (9Yx), 9YA))

Parking brake maintenance work ((Cayenne (9Yx), 9YA))

Unlocking aux. heater/independent car heater ((Cayenne (9Yx), 9YA))

Burning off aux. heater/independent car heater ((Cayenne (9Yx), 9YA))

Standardizing the liftgate ((Cayenne (9Yx), 9YA))

Codings

Coding the trailer detection ((Cayenne (9Yx), 9YA))

Registering the battery ((Cayenne (9Yx), 9YA))

Coding the rain/light sensor ((Cayenne (9Yx), 9YA))

Deactivating/activating the transport mode ((Cayenne (9Yx), 9YA))

Service resets

(Cayenne (9Yx), 9YA)

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

Renault

Trouble codes

(Arkana,), (Espace-V, JRM1), (Kadjar, HAxx, HLxx), (Megane-IV, B9NC), (Scenic-IV, J9A9, J9N9), (Talisman, KPAM), (Trafic-II, FL0L), (Zoe, FFFMF)

Parameters

(Arkana,), (Espace-V, JRM1), (Kadjar, HAxx, HLxx), (Megane-IV, B9NC), (Scenic-IV, J9A9, J9N9), (Talisman, KPAM), (Trafic-II, FL0L), (Zoe, FFFMF)

Actuators

(Arkana,), (Espace-V, JRM1), (Kadjar, HAxx, HLxx), (Megane-IV, B9NC), (Scenic-IV, J9A9, J9N9), (Talisman, KPAM), (Trafic-II, FL0L), (Zoe, FFFMF)

Basic settings

Learning the steering-angle sensor ((Vel Satis, BJ0G), (Espace-IV, JK00), (Espace-IV, JK0G), (Espace-IV, JK09), (Megane-III, DZ0F), (Megane-III, DZ0A), (Megane-III, DZ0B), (Megane-III, DZ0C), (Megane-III, DZ1M), (Megane-III, DZ0D, DZ09, DZ1F, DZ1G), (Megane-III, DZ03), (Megane-III, DZ0J), (Megane-III, DZ1P), (Megane-III, DZ0L), (Megane-III, DZ0Y), (Megane-III, DZ0G, DZ1E), (Megane-III, DZ0K), (Megane-III, DZ1N), (Megane-III, KZ0F), (Megane-III, KZ1V), (Megane-III, KZ0A), (Megane-III, KZAA), (Megane-III, KZ0B), (Megane-III, KZ1M), (Megane-III, KZ1W), (Megane-III, KZ0Y), (Megane-III, KZ0G), (Megane-III, KZ0K), (Megane-III, KZ0C), (Megane-III, KZ1A), (Megane-III, KZ0D), (Megane-III, KZ1G), (Megane-III, KZ03), (Megane-III, KZG3), (Megane-III, KZ0H), (Megane-III, KZ0U), (Megane-III, KZ0V), (Megane-III, KZ0J), (Megane-III, KZ0N), (Megane-III, KZ1S), (Megane-III, KZ0L), (Megane-III, BZ0F), (Megane-III, BZ1V), (Megane-III, BZ0B), (Megane-III, BZ1M), (Megane-III, BZ1W), (Megane-III, BZ0C),



Diagnostic devices

(Megane-III, BZ1A), (Megane-III, BZ0D), (Megane-III, BZ10), (Megane-III, BZAR), (Megane-III, BZ0H), (Megane-III, BZ03,BZM4,BZ24,BZ0U,BZ0V), (Megane-III, BZ0U), (Megane-III, BZAF), (Megane-III, BZ03), (Megane-III, BZ0N), (Megane-III, BZ1S), (Megane-III, BZ0L), (Megane-III, BZ0G), (Megane-III, BZ0K), (Megane-III, BZ1U), (Espace-IV, JK0K), (Espace-IV, JK0L), (Espace-IV, JK0Y), (Megane-II, KM01), (Megane-III, DZ0N), (Megane-III, DZ1S), (Megane-III, DZ1V), (Megane-III, DZ1W), (Megane-III, DZ1A), (Megane-III, DZ1G), (Megane-III, DZ0U), (Megane-III, KZ1P), (Megane-III, BZ1P), (Scenic-III, JZ07,JZ0B), (Scenic-III, JZ0L), (Scenic-III, JZ1S), (Megane-III, BZ01), (Laguna-II, BG0F), (Laguna-II, BG0G,BG10,BG1G,BGCG,BGRG), (Laguna-II, BG0G), (Laguna-II, BG0E), (Laguna-II, BG01), (Laguna-II, BG02), (Laguna-II, BG0N), (Laguna-II, BG04), (Vel Satis, BJ0J), (Vel Satis, BJ0E), (Vel Satis, BJ0P), (Laguna-II, BG0L), (Laguna-II, KG04), (Clio-II, BB0T), (Clio-II, CB1D), (Espace-IV, JK0U,JK0G), (Espace-IV, JK0H), (Espace-IV, JK0J,JK0V,JK0Y), (Espace-IV, JK0B), (Espace-IV, JK0J), (Espace-IV, JK0F), (Espace-IV, JK0U), (Megane-II, BM0T), (Megane-II, BM02), (Megane-II, BM0C), (Megane-II, BM0G), (Megane-II, BM05), (Scenic-II, JM0F), (Scenic-II, JM0B), (Scenic-II, JM0J), (Scenic-II, JM0L), (Scenic-II, JM0G), (Scenic-II, JM0U), (Laguna-II, BG0R), (Clio-II, BB1D), (Laguna-I, K56G), (Clio-II, CB2L), (Clio-II, CB1N,CB0M,), (Megane-III, BZ09), (Megane-III, DZ09), (Scenic-II, JM1D), (Scenic-II, JM1R), (Scenic-II, JM1Y), (Scenic-II, JM0Y), (Scenic-II, JM0W), (Laguna-II, BG14), (Clio-III, BR06), (Clio-III, BR1J), (Clio-III, BR1J, BR1B, BR26, BRA6, BRCB, CR1B, CR26, CRA6, CRCB), (Clio-III, BR1J, BR1J, BR1B, BR26, BRA6, BRCB, CR1B, CR26, CRA6, CRCB), (Vel Satis, BJ03), (Vel Satis, BJ0B), (Scenic-II, JM15), (Scenic-II, JM16), (Scenic-II, JM17), (Scenic-II, JM2A), (Scenic-II, JM2B), (Scenic-II, JM2C), (Megane-II, BM2A), (Megane-II, BM2B), (Megane-II, BM2C), (Megane-II, CM0T), (Megane-II, CM13), (Megane-II, CM16), (Megane-II, CM17), (Megane-II, CM2C), (Megane-II, CM2H), (Megane-II, EM16), (Megane-II, EM17), (Megane-II, EM1B), (Megane-II, EM1E), (Megane-II, EM2C), (Megane-II, KM13), (Megane-II, KM16), (Megane-II, KM17), (Megane-II, KM2B), (Megane-II, KM2C), (Megane-II, KM2E), (Megane-II, KM2F), (Megane-II, KM2G), (Megane-II, KM2M), (Megane-II, KM2N), (Megane-II, LM0S), (Megane-II, LM16), (Megane-II, LM17), (Megane-II, LM2A), (Megane-II, LM2B), (Megane-II, LM2C), (Megane-II, LM2E), (Megane-II, LM2F), (Megane-II, LM2G), (Megane-II, LM2M), (Megane-II, LM2N), (Laguna-I, K568), (Clio-II, CB2D), (Clio-II, CB21), (Clio-II, CB22), (Clio-III, BR0B), (Clio-III, BR0C), (Clio-III, BR0E), (Clio-III, BR0F), (Clio-III, BR0S), (Clio-III, CR07), (Clio-III, CR09,KRC9), (Clio-III, CR0B), (Clio-III, CR0C), (Clio-III, CR0E), (Clio-III, CR0F), (Clio-III, CR0G), (Clio-III, CR0H), (Clio-III, CR0J), (Clio-III, CR0S), (Clio-III, CR1M), (Scenic-II, JM1T), (Scenic-II, JM1M), (Scenic-II, JM1N), (Scenic-II, JM1U), (Clio-II, BB2T,BB05,BB0W,BB2L,BBCT,BBCU,BBCL), (Clio-II, BB2U), (Clio-II, BB05,BB2L,BB2T,BB2U,BBCT,BBCU,BBCL), (Megane-II, CM0G), (Megane-II, BM1G), (Megane-II, CM1G), (Megane-II, CM0F), (Clio-III, BR1L), (Vel Satis, BJ0F), (Clio-III, CR1L), (Scenic-II, JM12), (Scenic-II, JM1G), (Scenic-II, JM14), (Scenic-II, JM0C), (Scenic-II, JM1B), (Clio-III, SR1U), (Clio-III, CR1U), (Clio-III, KR1U), (Clio-III, BR1U), (Scenic-II, JM0H), (Scenic-II, JM1S), (Scenic-II, JM0T), (Megane-II, BM0U), (Megane-II, CM02), (Megane-II, BM0F), (Espace-IV, JK0P), (Espace-IV, JK0S), (Clio-III, BR0K), (Clio-III, BR15), (Clio-III, BR1W), (Clio-III, BR1Y, BR0B, BR1B, BR1J, BR1M, BRCB, BR0Y), (Clio-III, BR1Y), (Clio-III, CR0P), (Clio-III, CR15), (Clio-III, CR1F), (Clio-III, CR1Y), (Clio-III, KR1A), (Clio-III, SR0P), (Megane-III, BZ0Y), (Megane-III, BZ1B), (Megane-III, BZ1F), (Megane-III, BZ1H), (Megane-III, BZ1J), (Megane-III, BZ1K), (Megane-III, DZ0G), (Megane-III, BZ1E), (Megane-III, DZ0H), (Megane-III, DZ1B), (Megane-III, DZ1E), (Megane-III, DZ1F), (Megane-III, DZ1H), (Megane-III, DZ1J), (Megane-III, DZ1K), (Megane-III, EZ03), (Megane-III, EZ09), (Megane-III, EZ0B), (Megane-III, EZ0D), (Megane-III, EZ0F), (Megane-III, EZ0G), (Megane-III, EZ0J), (Megane-III, EZ0K), (Megane-III, EZ0L), (Megane-III, EZ0U), (Megane-III, EZ1E), (Megane-III, EZ1G), (Megane-III, EZ1P), (Megane-III, EZ1T), (Megane-III, EZ1U), (Megane-III, EZ1V), (Megane-III, KZ09), (Megane-III, KZ1B), (Megane-III, KZ1F), (Clio-III, JP0Y), (Scenic-III, JZ1K), (Scenic-III, JZ1J), (Clio-III, BREU), (Clio-III, BRFU), (Clio-III, CRFU), (Clio-III, CREU), (Clio-III, KREU), (Clio-III, KRFU), (Laguna-II, KG0N), (Laguna-II, KG0L), (Laguna-II, BG0U), (Laguna-II, KG0U), (Laguna-II, BG0A), (Laguna-II, KG0A), (Laguna-II, BG06), (Laguna-II, KG06), (Laguna-II, BG0B), (Laguna-II, KG0B), (Laguna-II, BG0C), (Laguna-II, KG0C), (Laguna-II, BG0J), (Laguna-II, KG0J), (Laguna-II, BG0V), (Laguna-II, KG0V), (Laguna-II, KG0R), (Laguna-II, KG0F), (Laguna-II, KG0G), (Laguna-II, KG0E), (Laguna-II, BG0D), (Laguna-II, BG0Y), (Laguna-II, KG01),



Diagnostic devices

(Laguna-II, KG0D), (Laguna-II, KG0Y), (Laguna-II, KG02), (Laguna-II, BG0M), (Laguna-II, KG0M), (Megane-III, EZ1W), (Megane-III, EZ1Y), (Megane-III, EZ1S), (Clio-III, CR04, CRCP, CR1P, CR14), (Clio-III, BR0R, BR1R, BRCR), (Clio-III, CR0R, CR1R, CR1R), (Clio-III, BR1D), (Clio-III, KR0E), (Clio-III, SR0S), (Clio-III, BR03), (Clio-III, CR03), (Clio-III, BR0P), (Clio-III, BR02), (Clio-III, CR02), (Clio-III, CR02, KR1J, KR1S, KRCJ, KRCS, KREU, KRFU,), (Clio-III, BR0R), (Clio-III, CR0R), (Clio-III, KR0E, BR02, BR0J, BR11, CR02), (Clio-III, BR01), (Clio-III, BR1P, BRC4), (Clio-III, CR14, CRCP), (Clio-III, CR02, CR03, CR0J, CR1D, CR1J, CR1L, CR1U, CR23, CRCJ, CREU, CRFU, CRP3), (Clio-III, BR04, BR14, BR1P), (Clio-III, BR0Y), (Clio-III, BR0Y, BR1Y, BR0B, BR1B, BR1J, BR1M, BRCB), (Clio-III, CR0Y, CR1Y, CR0B, CR1B, CR1J, CR1M, CRCB), (Clio-III, CR0Y, CR1Y, CR0B, CR1B, CR1J, CR1M, CRCB), (Clio-III, KR0B, KR1B, KR26, KRA6, KRCB, KR26), (Clio-III, KR0B, KR1B, KR26, KR26, KRA6, KRCB), (Clio-III, BR00), (Clio-III, BR0A, BR1A, BRCA), (Clio-III, BR1E), (Clio-III, CR00, CR1A, CRCA), (Clio-III, CR0A), (Clio-III, CR1E), (Clio-III, KR0A, KRCA), (Clio-III, SR0A), (Clio-III, BR05), (Clio-III, BR09), (Clio-III, BR0T), (Clio-III, BR0U), (Clio-III, CR05), (Clio-III, CR09), (Clio-III, CR0T), (Clio-III, CR0U), (Clio-III, KR09), (Clio-III, CR06), (Clio-III, CR0K), (Clio-III, None), (Clio-III, KR00), (Clio-III, KR02), (Clio-III, BR14, BRCP), (Clio-III, CR04, CR14, CRC4), (Clio-III, BR0G), (Clio-III, BR0G, BR1G, BR27, BRA7, BRCG), (Clio-III, BR0H), (Clio-III, KR1S, KRAS, KRCH), (Clio-III, BR0V), (Clio-III, BR0W), (Clio-III, BR1A), (Clio-III, BR1B), (Clio-III, BR1C), (Clio-III, BR1C, BR2C, BRAC), (Clio-III, BR1F), (Clio-III, BR1G), (Clio-III, BR1N), (Clio-III, BR1T), (Clio-III, CR0G, CR1G, CR27, CRA7, CRCG), (Clio-III, CR0V), (Clio-III, CR0W), (Clio-III, CR1A), (Clio-III, CR1C), (Clio-III, CR1C, CR2C, CR2C), (Clio-III, CR1G), (Clio-III, CR1N), (Clio-III, CR1T), (Clio-III, KR0F), (Clio-III, CR11), (Clio-III, KR0F, KR2N, KRAN, KRCF), (Clio-III, KR0G), (Clio-III, KR0H), (Clio-III, KR0H, KR1H, KR2S,), (Clio-III, SR0H), (Clio-III, KR1C), (Clio-III, KR1C, KRAC, KR2C), (Clio-III, KR1N), (Clio-III, KR1N, KR1F, KR2N, KRAN, KRCF), (Clio-III, SR0F), (Clio-III, SR0G, KR2T, KRAT), (Clio-III, SR0G), (Clio-III, SR1B), (Clio-III, CR0N), (Clio-III, CR1B), (Espace-IV, JK0K, JK09), (Megane-II, BM0J), (Megane-II, BM1B), (Megane-II, CM0C), (Megane-II, CM0J), (Megane-II, CM1B), (Megane-II, EM0C), (Megane-II, EM0E), (Megane-II, KM0C), (Megane-II, KM0J), (Megane-II, KM1B), (Megane-II, LM0C), (Megane-II, LM0J), (Megane-II, LM1B), (Clio-III, KR1B), (Clio-III, KR1V), (Clio-III, KRAV), (Clio-III, BR2V, BRAV, CR2V, CRAV), (Clio-III, BRAV), (Clio-III, CR1V), (Clio-III, BR1V), (Scenic-II, JM05, JM1U, JM1N, JM2V), (Scenic-II, JM0G, JM1G, JM12, JM2C), (Vel Satis, BJ0V), (Scenic-III, JZ14), (Clio-III, CR1P), (Clio-III, KR0P, KR14, KR1P, KRC4, KRCP), (Clio-III, SR0J), (Espace-IV, JK0D), (Espace-IV, JK0E), (Espace-IV, JK0N), (Espace-IV, JK0V), (Espace-IV, JK0W), (Espace-IV, JK1B), (Espace-IV, JK1D), (Laguna-II, BG00), (Laguna-II, BG03), (Laguna-II, BG05), (Laguna-II, BG07), (Laguna-II, BG08), (Laguna-II, BG09), (Laguna-II, BG0K), (Laguna-II, BG0P, BG1P, BGCP), (Laguna-II, BG0PB, BG1P, BGCP), (Laguna-II, BG0S), (Laguna-II, BG0T), (Laguna-II, BG0W), (Laguna-II, BG0Z), (Laguna-II, BG10), (Laguna-II, BG12, BG42, BGE2), (Laguna-II, BG12), (Laguna-II, BG13), (Laguna-II, BG1A), (Laguna-II, BG1G), (Laguna-II, BG1H), (Laguna-II, BG1K), (Laguna-II, BG1L), (Laguna-II, BG1M), (Laguna-II, BG1P), (Laguna-II, BG1S), (Laguna-II, BG44), (Laguna-II, BG1V), (Laguna-II, BG1Y), (Laguna-II, KG00), (Laguna-II, KG03), (Laguna-II, KG05), (Laguna-II, KG08), (Laguna-II, KG09), (Laguna-II, KG0K), (Laguna-II, KG0P), (Laguna-II, KG0S), (Laguna-II, KG0T), (Laguna-II, KG0W), (Laguna-II, KG0Z), (Laguna-II, KG10), (Laguna-II, KG12), (Laguna-II, KG13), (Laguna-II, KG1A), (Laguna-II, KG1G), (Laguna-II, KG1H), (Laguna-II, KG1K), (Laguna-II, KG1L), (Laguna-II, KG1N), (Laguna-II, KG1P), (Laguna-II, KG44), (Laguna-II, KG1V), (Laguna-II, KG1W), (Laguna-II, KG1Y), (Clio-III, BR0T, BR09, BR19, BRC9), (Megane-II, KM00), (Megane-II, KM02), (Megane-II, KM05), (Megane-II, KM0B), (Megane-II, KM0F), (Megane-II, KM0G), (Megane-II, KM0H), (Megane-II, KM0L), (Megane-II, KM0U), (Megane-II, KM0Y), (Megane-II, KM14), (Megane-II, KM1A), (Megane-II, KM1D), (Megane-II, KM1E), (Megane-II, KM1F), (Megane-II, KM1G), (Megane-II, KM1K), (Megane-II, KM1M), (Megane-II, KM1N), (Megane-II, KM1R), (Megane-II, KM1S), (Megane-II, KM1U), (Megane-II, LM02), (Megane-II, LM00), (Megane-II, LM05), (Megane-II, BM00), (Megane-II, BM08), (Megane-II, BM0B), (Megane-II, BM0H), (Megane-II, BM0L), (Megane-II, BM0M), (Megane-II, BM0W), (Megane-II, BM0Y), (Megane-II, BM11), (Megane-II, BM13), (Megane-II, BM14), (Megane-II, BM16), (Megane-II, BM17), (Megane-II, BM1A), (Megane-II, BM1C), (Megane-II, BM1D), (Megane-II, BM1E), (Megane-II, BM1F), (Megane-II, BM1K), (Megane-II, BM1M), (Megane-II, BM1N), (Megane-II, BM1R), (Megane-II, BM1S), (Megane-II, BM1T), (Megane-II, BM1U), (Megane-II, BM1V),



Diagnostic devices

(Megane-II, BM1Y), (Megane-II, CM00), (Megane-II, CM05), (Megane-II, CM08), (Megane-II, CM0B), (Megane-II, CM0H), (Megane-II, CM0L), (Megane-II, CM0M), (Megane-II, CM0U), (Megane-II, CM0W), (Megane-II, CM0Y), (Megane-II, CM11), (Megane-II, CM14), (Megane-II, CM1D), (Megane-II, CM1E), (Megane-II, CM1F), (Megane-II, CM1K), (Megane-II, CM1L), (Megane-II, CM1M), (Megane-II, CM1N), (Megane-II, CM1R), (Megane-II, CM1S), (Megane-II, CM1T), (Megane-II, CM1U), (Megane-II, CM1V), (Megane-II, CM1Y), (Megane-II, EM05), (Megane-II, EM0G), (Megane-II, EM0J), (Megane-II, EM0U), (Megane-II, EM0W), (Megane-II, EM14), (Megane-II, EM1D), (Megane-II, EM1G), (Megane-II, EM1K), (Megane-II, EM1M), (Megane-II, EM1N), (Megane-II, EM1R), (Megane-II, EM1T), (Megane-II, EM1U), (Megane-II, GM02), (Megane-II, GM0F), (Megane-II, GM1E), (Megane-II, GM1F), (Megane-II, LM0G), (Megane-II, LM0H), (Megane-II, LM0L), (Megane-II, LM0P), (Megane-II, LM0T), (Megane-II, LM0U), (Megane-II, LM0Y), (Megane-II, LM13), (Megane-II, LM14), (Megane-II, LM1A), (Megane-II, LM1D), (Megane-II, LM1E), (Megane-II, LM1F), (Megane-II, LM1G), (Megane-II, LM1K), (Megane-II, LM1M), (Megane-II, LM1N), (Megane-II, LM1R), (Megane-II, LM1S), (Megane-II, LM1U), (Megane-II, SM02), (Megane-II, SM0F), (Megane-II, SM1E), (Megane-II, SM1F), (Scenic-II, JM02), (Scenic-II, JM05), (Scenic-II, JM13), (Scenic-II, JM1A), (Scenic-II, JM1E), (Scenic-II, JM1F), (Scenic-II, JM1K), (Clio-III, CR0T, CR09, CR19, CRC9), (Vel Satis, BJ00), (Vel Satis, BJ01), (Vel Satis, BJ05), (Vel Satis, BJ0H), (Vel Satis, BJ0K), (Vel Satis, BJ0M), (Vel Satis, BJ0R), (Vel Satis, BJ0S), (Vel Satis, BJ0U), (Vel Satis, BJ0W), (Clio-III, CR1H, CR2S, CRAS, CRCH), (Clio-III, BR1H, BR2S, BRAS, BRCH), (Clio-III, CROH), (Clio-III, BROH), (Clio-III, BR01, BR1E, BRCE), (Clio-III, BR0E, KR1E, KRCE), (Clio-III, KR0G, KR1G, KR27, KRA7, KRCG), (Espace-IV, JK08), (Espace-IV, JR0S), (Espace-IV, JK01, JK1F, JKJF, JK04, JK1J), (Espace-IV, JK02, JK1H, JKFH), (Espace-IV, JK1H, JK02, JKFH), (Clio-III, KR0J), (Clio-III, BR11), (Clio-III, BR10, BR20, BRA0), (Clio-III, BR07), (Megane-IV, B9A1), (Espace-IV, JK0A), (Espace-IV, JK03), (Espace-IV, JK04), (Espace-IV, JK07, JK0T), (Espace-IV, JK00), (Vel Satis, BJ0N), (Vel Satis, BJRS), (Scenic-II, JMS6, JMG6), (Scenic-III, JM16), (Laguna-II, KG4T), (Laguna-II, KG43), (Scenic-II, JM1GJM0G, JM1G, JM12, JM2C), (Scenic-II, JM17, JM14), (Scenic-III, JZ0D), (Scenic-III, JZ03), (Scenic-III, JZ0U), (Scenic-III, JZ0B, JZ07), (Scenic-III, JZ1M), (Scenic-III, JZ0F, JZ1V, JZDV), (Scenic-III, JZ0G), (Scenic-III, JZ1P), (Scenic-III, JZ0J), (Scenic-III, JZ0N), (Scenic-III, JZ0A), (Scenic-III, JZ0Y), (Clio-III, CR00), (Clio-II, CB0H), (Clio-II, CB1N, CB0M), (Clio-III, CB3N), (Clio-III, KR20, KRA0), (Scenic-III, JZ1Y), (Espace-IV, JK0B, JK0D), (Megane-II, BMSF), (Megane-II, BMSD), (Megane-II, BMPK), (Megane-II, BMSK), (Megane-II, BMR0), (Megane-II, KMR0), (Megane-II, KMSE), (Megane-II, LMR0), (Megane-II, LMRG), (Megane-II, LMRF), (Megane-II, LMR2), (Megane-II, LMKD), (Megane-II, LMSE), (Megane-II, LMSF), (Megane-II, LMPK), (Megane-II, LM0B), (Megane-II, LM08), (Megane-II, LM2S), (Megane-II, BMS7), (Megane-II, BM2K), (Megane-II, BM1W), (Megane-II, CM1W), (Megane-II, KM2K), (Megane-III, BZ0J), (Megane-III, BZAB), (Megane-II, LM0F), (Megane-III, BZ0A), (Espace-IV, JK1C), (Espace-IV, JK1G), (Espace-IV, JK1J, JK1F, JKJF, JK01, JK04), (Clio-IV, BHMA), (Clio-IV, KHMA), (Espace-IV, JK04, JK1F, JKJF, JK01, JK1J), (Scenic-III, JZ1V, JZDV, JZ0F), (Scenic-III, JZ1W), (Scenic-III, JZ1G), (Clio-III, CR10, CR20, CRA0), (Clio-III, KR10), (Scenic-III, JZ1E), (Scenic-III, JZ1U), (Scenic-III, JZ42), (Laguna-II, BG4T), (Laguna-II, BGE4), (Laguna-II, BGET), (Laguna-II, KGET), (Megane-II, KM0T), (Megane-II, KM0S), (Scenic-III, JZ00, JZ12), (Espace-IV, JK1L), (Espace-IV, JK09, JK0K, JK0L), (Clio-III, KR1H), (Clio-III, KR1S, KRAS, KRCH, KR1H, KR2S,), (Clio-III, BR02BR03, BR0J, BR1D, BR1J, BR1L, BR1U, BR23, BRCJ, BREU, BRFU, BRP3), (Clio-III, BR0J), (Clio-III, BR1U, BR02, BR03, BR0J, BR1D, BR1J, BR1L, BR1U, BR23, BRCJ, BREU, BRFU, BRP3), (Clio-III, CR1U, CR02, CR03, CR0J, CR1D, CR1J, CR1L, CR23, CRCJ, CREU, CRFU, CRP3), (Clio-III, BR04, BR14, BRC4), (Clio-III, CR1H, CRAH, CRAH), (Clio-III, BR1H, BR2H, BRAH), (Fluence, L30Z, LZBZ, LZL6), (Clio-III, KR1F, KR2N, KRN, KRCF), (Clio-III, KR0P), (Clio-III, KR04, KR14, KR1P, KRC4, KRCP), (Clio-III, KR04, KR14, KRC4), (Megane-III, DZ15), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, KZ01), (Megane-III, DZ00), (Megane-III, DZ02), (Megane-III, DZ11, DZ2B), (Megane-III, DZ01), (Megane-III, DZ08), (Clio-III, KR0S), (Scenic-III, JZ11, JZ0Z, JZ1Z, JZD1), (Scenic-III, JZ09), (Clio-II, CB05, CB2L, CB2T, CB2U, CBCT, CBCU, CBCL), (Clio-II, CB0W), (Clio-II, BB0W), (Clio-II, CB2T, CB05, CB0W, CB2L, CBCT, CBCU, CBCL), (Clio-II, BB2L), (Clio-II, CB2U), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Clio-IV, BHMG), (Clio-IV, BHMK), (Clio-IV, KHMG, KHAK), (Clio-IV, KHMG), (Clio-IV, BHML), (Clio-IV, KHML), (Clio-IV, BHMH), (Clio-IV,



Diagnostic devices

BHMM), (Scenic-III, JZ16,JZ0Y,JZ1Y,JZD6), (Megane-III, BZ16), (Megane-III, KZ16), (Megane-III, DZ16,DZ28), (Megane-III, EZ16), (Megane-III, BZ11), (Megane-III, BZ1Y), (Megane-III, EZ00), (Megane-III, DZ12), (Megane-III, KZ1Y), (Megane-III, KZ1T), (Megane-III, DZ0_), (Megane-III, BZ1T), (Megane-III, BZ0K), (Megane-III, DZ17), (Megane-III, DZ18), (Megane-III, EZ12), (Megane-III, L331), (Megane-III, L332), (Megane-III, BZL2), (Captur-I, J5M0), (Captur-I, J5AL), (Captur-I, J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Scenic-III, JZ00,JZ02,JZ12,JZ13,JZD2,JZH0,JZNA,JZPA,JZV0,JZYA), (Scenic-II, JM02,JM13), (Scenic-II, JM13,JM02), (Captur-I, BHM0), (Captur-I, KHM0), (Captur-I, 5R40), (Captur-I, 5RU0), (Scenic-III, JZ09,JZ11,JZ0Z,JZ1Z,JZD1), (Scenic-III, JZ00), (Scenic-III, JZ12,JZ00), (Laguna-II,), (Megane-III, BZ23), (Megane-III, BZ1G), (Megane-III, DZ21), (Megane-III, DZ23), (Trafic-III, FGMD,FGME,JGMD,JGME), (Trafic-III, FGMA,FGMB,JGMA,JGMB,JRA5), (Clio-IV, KHM0), (Trafic-III, FGMA,FGMB,JGMA,JGMB,JRA5,EGMA), (Megane-III, BZ14), (Captur-I, J5MA,J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Captur-I, J5MH,J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Zoe, BFMA), (Twingo-III, BCM1), (Laguna-II, BG10,BG1A,BG1W,BG4A,BG4W,BGEA,BGEW), (Laguna-II, KG10,KG1A,KG1W,KG4A,KG4W,KGEA,KGEW), (Megane-II, CM0W,CM1T), (Scenic-II, JM0W,JM1T,JMAW), (Clio-III, BR0F,BR1B,BR1F,BR1N,BR2N,BRAN,BRCF), (Clio-III, BR0H,BR1H,BRCH,CR0H,CR1H,CRCH,SR0H,SR1H,SRCH), (Laguna-II, BG09,BG19,BG1N,BG4N,BGEN), (Laguna-II, KG09,KG19,KG1N,KG4N,KGEN), (Laguna-II, BG14,BG1T,BG44,BG4T,BGE4,BGET), (Laguna-II, KG14,KG1T,KG44,KG4T,KGE4,KGET), (Megane-II, BM1K,BMSK), (Megane-II, LM1K,LMSK), (Megane-II, KM1K,KMSK), (Megane-II, EM1K,EMSK), (Scenic-II, JM14,JMG4,JMJ4,JMK4,JMS4,JMT4), (Scenic-II, JM1K,JMGK,JMKJ,JMSK), (Clio-III, BR00,BR0A,BR1A,BR1E,BRCA,CR00,CR0A,CR1A,CR1E,CRCA,SR00,SR0A,SR1A,SR1E,SRCA), (Scenic-II, JM0C,JM1B,JM1R,JMJR), (Scenic-II, JM1Y,JM3Y,JM4Y), (Laguna-II, KG12,KG42,KGE2), (Laguna-II, KG42,KGE2), (Laguna-II, BG13,BG43,BGE3), (Laguna-II, KG13,KG43,KGE3), (Laguna-II, BG05,BG15), (Laguna-II, KG05,KG15), (Megane-II, KM1D,KM1G,KM2C,KMKD,KMSD,KMSG), (Megane-II, BMKD,BMSD,BMSG,CMKD,CMSD,CMSG), (Megane-II, EM14,EMK4,EMS4), (Laguna-II, BG1V,BG4V,BGEV), (Laguna-II, KG1V,KG4V,KGEV), (Megane-II, CM1F,CMSF,GM1F,GMSF), (Megane-II, CM02,CM13,CMR2,GM02,GM13,GMR2), (Megane-II, KM00,KMR0), (Scenic-II, JM1F,JMSF), (Scenic-II, JM1E,JMGE,JMJE,JMSE), (Laguna-II, KG00,KG0K,KG0P,KG0W,KG1P,KGCP), (Laguna-II, BG00,BG0K,BG0P,BG0W,BG1P,BGCP), (Laguna-II, BG1G,BG1H,BG4H,BGEH), (Laguna-II, KG1G,KG1H,KG4H,KGEH), (Laguna-II, KG0S,KG1L,KG1M), (Laguna-II, BG0T,BG1T,BGCT), (Laguna-II, KG0T,KG1T,KGCT), (Laguna-II, BG03,BG0Z,BG1Y,BG1Z,BGCZ), (Laguna-II, KG03,KG0Z,KG1Y,KG1Z,KGCZ), (Megane-II, LM0C,LM1B,LM1R), (Megane-II, KM0C,KM1B,KM1R), (Clio-III, CR0F,CR1B,CR1F,CR1N,CR2N,CRAN,CRCF), (Clio-III, SR0F,SR1B,SR1F,SR1N,SR2N,SRAN,SRCF), (Espace-IV, JK1K), (Clio-III, CR1J,CR1S,CR23,CR9S,CRCJ,CRC5,CREU,CR FU,CRP3,BR03,BR1J,BR1S,BR23,BR9S,BRCJ,BRCS,BREU,BRFU,BRP3), (Kadjar, HLA4), (Kadjar, HLMR), (Kadjar, HLA3), (Captur-I, 2RAU,2RBU), (Captur-I, 2RAL,2RBL,2REL,2RFL), (Captur-I, 2RAJ,2RBJ2RAJ,2RBJ,5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 2RAJ,2RBJ,2RAJ,2RBJ,5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 2RA1,2RB1,2RD1,2RE1), (Captur-I, 2RA1,2RB1,2RD1,2RE1), (Captur-I, 2RAR,2RBR), (Clio-IV, 5RB2,5RD2,5RD3), (Clio-IV, 5RBF,5RDF,5REF), (Clio-IV, 5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Clio-IV, 7R0J,7RBJ,7RDJ,7R,JJ,7RKJ,KHAJ), (Megane-IV, B9MS), (Megane-IV, B9MR), (Megane-IV, B9A3), (Megane-IV, B9A4), (Clio-IV, 5R22,BHM1), (Clio-IV, 6RBF,6RDF), (Clio-IV, 7R22,KHM1), (Clio-IV, 7R22,7R24,7R2R,7R32,7RB2,7RD2,7RE2,KHM1), (Clio-IV, 7RBF,7RDF,7REF), (Captur-I, 7RBU), (Clio-IV, 5R93), (Talisman, L2A3,LPA3), (Talisman, L2A5,LPA5), (Talisman, L2A4,LPA4), (Talisman, L2MJ,LPMJ), (Talisman, L2MV,LPMV), (Talisman, K2A3,KPA3), (Talisman, K2A5, KPA5), (Talisman, K2A4, KPA4), (Talisman, K2MJ), (Talisman, K2MV, KPMV), (Fluence, LZVJ), (Clio-IV, 2RAU,2RBU), (Megane-IV, K9MS), (Megane-IV, K9MR), (Megane-IV, K9A1), (Megane-IV, K9A3), (Megane-IV, K9A4), (Megane-IV, K9M0), (Megane-IV, K9MV), (Megane-IV, B9MV), (Megane-IV, B9M0), (Clio-IV, 7R01,KHMR), (Clio-IV, 6RRN,6RSN), (Clio-IV, 5RBU), (Clio-IV, 5R01), (Clio-IV, 7RBU,KHAU), (Scenic-IV, J9MR,R9MR), (Scenic-IV, J9A4), (Scenic-IV, J9A5), (Scenic-IV, J9A3), (Scenic-IV, J9A2), (Clio-



Diagnostic devices

IV, 7RBU, KHAU), (Scenic-IV, J9MB,J9MB,R9MB), (Scenic-IV, JZ), (Megane-IV, B9A5), (Megane-IV, K9A5), (Captur-I, 2R04,2R05), (Captur-I, 2R02,2R03), (Captur-I, 2R06,2R07), (Captur-I, 2R00,2R01,J5AJ), (Espace-V, JRM1), (Koleos-II, HCAK), (Koleos-II, HCA4), (Scenic-III, JZ0Y,JZ16,JZ1Y,JZD6,JZ0Z,JZ11,JZ1Z,JZ1D), (Scenic-IV, J9AE), (Twingo-III, BCM8), (Fluence, LZLL,LZVV), (Captur-I, 5R33,5R24,5R2R,5R32,5RB2,5RD2,5RE2), (Captur-I, 2R5A,2RDA,2REA,2RFA,2RGA,2RHA), (Captur-I, 5RBU), (Kadjar, HLMH), (Scenic-III, JZ0Y,JZ16,JZ1Y,JZD6,JZ0Z,JZ11,JZ1Z,JZ1D,JZ16,JZ0Y,JZ1Y,JZD6), (Trafic-III, JGML,FGML), (Trafic-III, JGMH,EGMH), (Trafic-III, JGMJ,FGMR), (Scenic-III,), (Twingo-II, CN0K,CN04,CN0A,CN0B), (Captur-I, J5M1,J5NF), (Captur-I, J5AU), (Captur-I, J5NJ), (Captur-I, J5NK), (Captur-I, J5N4), (Clio-IV, BHA1), (Clio-IV, BHAK), (Clio-IV, BHN4), (Clio-IV, BHN3), (Clio-IV, KHNF), (Clio-IV, KHN4), (Clio-IV, KHN3), (Espace-V, JRAL), (Espace-V, JRAM), (Kadjar, HLNB), (Kadjar, HLNC), (Kadjar, HLA6), (Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, K9A2), (Megane-IV, K9A6), (Megane-IV, K9MF), (Megane-IV, B9NC), (Megane-IV, B9A2), (Megane-IV, B9A6), (Megane-IV, B9MF), (Megane-IV, B9M6), (Megane-III, DZ16), (Scenic-IV, J9A9,J9N9), (Zoe, BFMF), (Twingo-III, BCMD), (Trafic-III, JGMK,JGMS,FGMK), (Talisman, LPA7), (Talisman, LPA8), (Talisman, LPM1), (Talisman, KPA7), (Talisman, KPM1), (Scenic-IV, J9NB,R9NB), (Scenic-IV, J9NC), (Scenic-IV, J9A7,R9A7), (Scenic-IV, J9A8,R9A8), (Megane-IV, B9), (Espace-IV, JK02,JK03), (Laguna-II, BG0G,BG08), (Laguna-II, BG1Y,BG03,BG0Z,BG0T), (Clio-IV, BHMM,BHJ4,BHJ6), (Talisman, LPAL), (Talisman, LPAM), (Talisman, LPNC), (Kadjar, HLA7), (Talisman, KPAM), (Talisman, KPAL), (Megane-IV, B9M8), (Megane-IV, B9A7), (Zoe, FFMA), (Zoe, FFMB), (Twingo-III, BCME), (Twingo-III, BCM4), (Twingo-III, BCMJ), (Megane-III, DZ0Z), (Megane-III,), (Megane-III, RFB), (Clio-IV, R), (Clio-IV, BHN), (Clio-IV, BHF), (Clio-IV, BHM1,BHF), (Clio-IV, KHN), (Trafic-III, JGMN), (Trafic-III, JGML,FGML,EGML), (Talisman,), (Talisman, None), (Captur-I, J5NE), (Koleos-II, HCA7), (Koleos-II, HCAN), (Koleos-II, None), (Megane-IV, K9A7), (Talisman, L2M), (Talisman, KP_), (Trafic-III, JGMM), (Clio-IV, BHM0), (Koleos-II, HCA), (Megane-IV,), (Twingo-III, BCA1), (Express, F6MA), (Kadjar, HAxx,HLxx), (Megane-IV, RFB), (Espace-V, JRFC), (Scenic-IV, R9NC), (Talisman, RFD))

Initializing the soot particulate filter upon replacement ((Kangoo-II, FW06,KW06), (Kangoo-II, FW06,KW06,FW16,FW56,KW16,KW56,KW66,KW96), (Kangoo-II, KW32,FW42,KW42), (Kangoo-II, KWS8,KWE8,KWR8,FWG8), (Kangoo-II, FW17), (Kangoo-II, None), (Kangoo-II, FW0G), (Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Kangoo-II, KW06,KW12,FW06,FW12), (Talisman, L2M), (Talisman, KP_), (Kangoo-II, KW16), (Kangoo-II, FW17,KW17), (Kangoo-II, FW15,KW15), (Megane-IV, B9NC), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL), (Kadjar, HAxx,HLxx))

Replacing the fuel pressure sensor ((Fluence, L30A,LZBA), (Fluence, B306,LZB6,BBB6,BLB6), (Megane-III, DZ0A), (Megane-III, DZ0B), (Megane-III, DZ0C), (Megane-III, DZ1M), (Megane-III, DZ0D,DZ09,DZ1F,DZ1G), (Megane-III, DZ0L), (Megane-III, DZ0Y), (Megane-III, KZ0A), (Megane-III, KZAA), (Megane-III, KZ0B), (Megane-III, KZ1M), (Megane-III, KZ1W), (Megane-III, KZ0Y), (Megane-III, KZ0C), (Megane-III, KZ1A), (Megane-III, KZ0D), (Megane-III, KZ1G), (Megane-III, KZ0L), (Megane-III, BZ0B), (Megane-III, BZ1M), (Megane-III, BZ1W), (Megane-III, BZ0C), (Megane-III, BZ1A), (Megane-III, BZ0D), (Megane-III, BZ10), (Megane-III, BZ0L), (Megane-III, DZ1W), (Megane-III, DZ1A), (Megane-III, DZ1G), (Scenic-III, JZ07,JZ0B), (Scenic-III, JZ0L), (Fluence, LZBS), (Megane-III, BZ09), (Megane-III, DZ09), (Fluence, B30A), (Megane-III, BZ0Y), (Megane-III, BZ1F), (Megane-III, DZ1F), (Megane-III, EZ09), (Megane-III, EZ0B), (Megane-III, EZ0D), (Megane-III, EZ0L), (Megane-III, EZ1G), (Megane-III, KZ09), (Megane-III, KZ1F), (Megane-III, EZ1W), (Fluence, LZBD), (Fluence, LZBL), (Laguna-III, BT00), (Laguna-III, KT0A), (Scenic-III, JZ14), (Laguna-III, BT0R), (Laguna-III, KT03), (Scenic-III, JZ0D), (Scenic-III, JZ0B,JZ07), (Scenic-III, JZ1M), (Scenic-III, JZ0A), (Scenic-III, JZ0Y), (Megane-III, BZAB), (Megane-III, BZ0A), (Scenic-III, JZ1W), (Scenic-III, JZ1G), (Scenic-III, JZ42), (Scenic-III, JZ00,JZ12), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, DZ00), (Megane-III, DZ02), (Laguna-III, DT1R,DT1R,DTE2,DTER,DT0_), (Scenic-III, JZ09), (Megane-III, EZ00), (Megane-III, DZ12), (Fluence, LZ00), (Megane-III, EZ12), (Scenic-III, JZ00,JZ02,JZ12,JZ13,JZD2,JZH0,JZNA,JZPA,JZV0,JZYA), (Scenic-III, JZ00), (Scenic-III, JZ12,JZ00), (Laguna-III, KT0R), (Megane-III, BZ1G), (Megane-III, BZ14), (Kangoo-II,



Diagnostic devices

FW06,KW06), (Kangoo-II, FW06,KW06,FW16,FW56,KW16,KW56,KW66,KW96), (Fluence, LZLL,LZVV), (Laguna-III, KT0A,KT12,KT1A,KT1R,KTE2,KTER), (Laguna-III, DT1R,DT1R,DTE2,DTER), (Laguna-III, BT0A,BT12,BT1A,BT1R,BTE2,BTER), (Scenic-III,))

Resetting throttle valve adaptation values ((Trafic-II, FL0L), (Trafic-II, JL0L), (Trafic-II, EL0L))

Resetting oxygen sensor adaptation values ((Twingo-III, BCMD), (Twingo-III, BCME), (Twingo-III, BCM4), (Twingo-III, BCMJ), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman,), (Espace-V, JRFC))

Learning the flywheel ((Fluence, L30A,LZBA), (Megane-III, DZ0A), (Megane-III, DZ0C), (Megane-III, DZ0Y), (Megane-III, KZ0A), (Megane-III, KZAA), (Megane-III, KZ0Y), (Megane-III, KZ0C), (Megane-III, KZ1A), (Megane-III, BZ0C), (Megane-III, BZ1A), (Megane-III, DZ1A), (Kangoo-II, KW05), (Fluence, LZBS), (Kangoo-II, FW05), (Fluence, B30A), (Megane-III, BZ0Y), (Kangoo-II, FW0F), (Clio-III, KR1V), (Clio-III, KRAV), (Clio-III, BR2V,BRAV,CR2V,CRAV), (Clio-III, BRAV), (Clio-III, CR1V), (Clio-III, BR1V), (Scenic-III, JZ0Y), (Kangoo-II, KW0G), (Megane-III, BZ0A), (Kangoo-II, KW04,KW14,KW17,KW54,KW57), (Kangoo-II, KW24), (Kangoo-II, FW05,FW15,FW18,FW55,FW58,), (Kangoo-II, KW05,FW15,FW18,FW55,FW58,), (Modus, JP04), (Twingo-II, CN00), (Twingo-II, CN03), (Kangoo-II, FW04,FW07,FW14,FW17,FW54,FW57), (Scenic-III, JZ00,JZ12), (Clio-III, KR1H), (Clio-III, CR1H,CRAH,CRAH), (Clio-III, BR1H,BR2H,BRAH), (Kangoo-II, FW0G), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, DZ00), (Megane-III, DZ02), (Clio-IV, BHAL), (Clio-IV, KHAL), (Megane-III, EZ00), (Megane-III, DZ12), (Fluence, LZ00), (Megane-III, EZ12), (Captur-I, J5AL), (Scenic-III, JZ00,JZ02,JZ12,JZ13,JZD2,JZH0,JZNA,JZPA,JZV0,JZYA), (Scenic-III, JZ00), (Scenic-III, JZ12,JZ00), (Kangoo-II, KW08), (Kangoo-II, KW25), (Kangoo-II, KW28), (Kangoo-II, KW55), (Kangoo-II, KW58), (Kangoo-II, KW45), (Kangoo-II, KW48), (Kangoo-II, KW25,FW15,FW18,FW55,FW58,), (Kangoo-II, KW28,FW15,FW18,FW55,FW58,), (Kangoo-II, KW65,FW15,FW18,FW55,FW58,), (Kangoo-II, KW68,FW15,FW18,FW55,FW58,), (Kangoo-II, KW95,FW15,FW18,FW55,FW58,), (Kangoo-II, KW98,FW15,FW18,FW55,FW58,), (Laguna-III, KT0S,KT09,KT0F,KT0M,KT0S), (Kangoo-II, FW15,FW18,FW55,FW58,FWG5,FWG8,FWK5,FWK8,KW25,KW28,KW65,KW68,KW95,KW98), (Captur-I, 2RAU,2RBU), (Captur-I, 2RAL,2RBL,2REL,2RFL), (Kangoo-II,), (Megane-IV, B9A4), (Captur-I, 7RBU), (Talisman, L2A5,LPA5), (Talisman, K2A5, KPA5), (Clio-IV, 2RAU,2RBU), (Megane-IV, K9A4), (Clio-IV, 5RBU), (Clio-IV, 7RBU,KHAU), (Scenic-IV, J9A4), (Clio-IV, 7RBU, KHAU), (Captur-I, 2R02,2R03), (Megane-III, BZ16), (Megane-III, KZ16), (Captur-I, 5RBU), (Scenic-III, JZ0Y,JZ16,JZ1Y,JZD6,JZ0Z,JZ11,JZ1Z,JZ1D,JZ16,JZ0Y,JZ1Y,JZD6), (Captur-I, J5AU), (Talisman, L2M), (Talisman, KP__))

Initializing the fuel high-pressure sensor ((Kangoo-II, KW05), (Kangoo-II, FW05), (Master-III, EV0F,EV0J,FV0F,FV0J,HV0F,HV0J,JV0F,JV0J,UV0F,UV0J), (Master-III, FV0F,FV0J,HV0F,HV0J,UV0F,UV0J), (Master-III, EV0F), (Master-III, FV0F), (Master-III, HV0B), (Kangoo-II, FW0F), (Clio-III, KR1V), (Clio-III, KRAV), (Clio-III, BR2V,BRAV,CR2V,CRAV), (Clio-III, BRAV), (Clio-III, CR1V), (Clio-III, BR1V), (Master-III, HV0F), (Kangoo-II, KW0G), (Kangoo-II, KW04,KW14,KW17,KW54,KW57), (Kangoo-II, KW24), (Kangoo-II, FW05,FW15,FW18,FW55,FW58,), (Kangoo-II, KW05,FW15,FW18,FW55,FW58,), (Modus, JP04), (Master-III, UV0J), (Twingo-II, CN00), (Twingo-II, CN03), (Kangoo-II, FW04,FW07,FW14,FW17,FW54,FW57), (Master-III, HV0D), (Master-III, HV0J), (Master-III, UV0B), (Master-III, UV0D), (Master-III, UV0F), (Clio-III, KR1H), (Clio-III, CR1H,CRAH,CRAH), (Clio-III, BR1H,BR2H,BRAH), (Kangoo-II, FW0G), (Master-III, FV0D), (Master-III, FV0J), (Master-III, FV0J,FV0J,FV0D,FV0H), (Master-III, JV0B), (Master-III, JV0D), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Master-III, UV0J,EV0F,EV0J,FV0F,FV0J,HV0F,HV0J,JV0F,JV0J,UV0F,UV0J), (Master-III, EV0J), (Master-III, JV0F), (Master-III, JV0J), (Captur-I, J5AL), (Kangoo-II, KW08), (Kangoo-II, KW25), (Kangoo-II, KW28), (Kangoo-II, KW55), (Kangoo-II, KW58), (Kangoo-II, KW45), (Kangoo-II, KW48), (Kangoo-II, KW25,FW15,FW18,FW55,FW58,), (Kangoo-II, KW28,FW15,FW18,FW55,FW58,), (Kangoo-II, KW65,FW15,FW18,FW55,FW58,), (Kangoo-II, KW68,FW15,FW18,FW55,FW58,), (Kangoo-II, KW95,FW15,FW18,FW55,FW58,), (Kangoo-II, KW98,FW15,FW18,FW55,FW58,), (Master-III,



Diagnostic devices

UV0B,EV0B,EV0D,FV0B,FV0D,HV0B,HV0D,JV0B,JV0D,UV0B,UV0D), (Master-III,
FV0F,FV0J,HV0F,HV0J,UV0F,UV0J), (Master-III,
EV0B,EV0D,FV0B,FV0D,HV0B,HV0D,JV0B,JV0D,UV0B,UV0D), (Master-III,
FV0N,FV0P,HV0N,UVOP), (Master-III, FV0N,FV0P,HV0N,JVOP,JV0N), (Master-III,
EV0F,EV0J,FV0F,HV0F,HV0J,JV0F,JV0J,UV0F,UV0J), (Kangoo-II,
FW15,FW18,FW55,FW58,FWG5,FWG8,FWK5,FWK8,KW25,KW28,KW65,KW68,KW95,KW98),
(Master-III, FV0A,FV0B,FV0C,FV0D,FV0G,FV0K), (Master-III, FV0E,FV0F,FV0H,FV0J),
(Captur-I, 2RAU,2RBU), (Captur-I, 2RAL,2RBL,2REL,2RFL), (Clio-IV, 5RBF,5RDF,5REF),
(Kangoo-II,), (Clio-IV, 6RBF,6RDF), (Clio-IV, 7RBF,7RDF,7REF), (Captur-I, 7RBU), (Clio-IV,
2RAU,2RBU), (Clio-IV, 5RBU), (Clio-IV, 7RBU,KHAU), (Clio-IV, 7RBU, KHAU), (Captur-I,
2R02,2R03), (Megane-III, BZ16), (Megane-III, KZ16), (Master-III, MB), (Captur-I, 5RBU),
(Scenic-III, JZ0Y,JZ16,JZ1Y,JZD6,JZ0Z,JZ11,JZ1Z,JZ1D,JZ16,JZ0Y,JZ1Y,JZD6), (Captur-I,
J5AU), (Captur-I, J5NJ), (Captur-I, J5NK), (Kadjar, HLNB), (Kadjar, HLNC), (Megane-IV,
B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9),
(Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, B9NC), (Scenic-IV, J9A9,J9N9),
(Scenic-IV, J9NB,R9NB), (Scenic-IV, J9NC), (Talisman, LPNC), (Clio-V, B7MF), (Captur-II,
RJB), (Master-III, JV0A,JV0B), (Captur-I, J5NE), (Koleos-II, HCA), (Clio-V, RJA), (Express,
F6MA), (Kadjar, HAxx,HLxx), (Scenic-IV, R9NC), (Talisman, RFD), (Arkana, RJL))

Learning the lambda sensor ((Megane-III, DZ0L), (Megane-III, DZ0Y), (Megane-III, KZ0Y),
(Megane-III, KZ0L), (Megane-III, BZ0L), (Scenic-III, JZ0L), (Megane-III, BZ0Y), (Megane-III,
EZ0L), (Scenic-III, JZ14), (Scenic-III, JZ0Y), (Scenic-III, JZ00,JZ12), (Megane-III, BZ00),
(Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, DZ00), (Megane-III,
DZ02), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Megane-III, EZ00),
(Megane-III, DZ12), (Fluence, LZ00), (Megane-III, EZ12), (Captur-I, J5AL), (Scenic-III,
JZ00,JZ02,JZ12,JZ13,JZD2,JZH0,JZNA,JZPA,JZV0,JZYA), (Scenic-III, JZ00), (Scenic-III,
JZ12,JZ00), (Kangoo-II, KW05), (Kangoo-II, KW08), (Kangoo-II, KW25), (Kangoo-II, KW28),
(Kangoo-II, KW55), (Kangoo-II, KW58), (Kangoo-II, KW45), (Kangoo-II, KW48), (Kangoo-II,
KW25,FW15,FW18,FW55,FW58,), (Kangoo-II, KW28,FW15,FW18,FW55,FW58,), (Kangoo-II,
KW65,FW15,FW18,FW55,FW58,), (Kangoo-II, KW68,FW15,FW18,FW55,FW58,), (Kangoo-II,
KW95,FW15,FW18,FW55,FW58,), (Kangoo-II, KW98,FW15,FW18,FW55,FW58,), (Megane-III,
BZ14), (Kangoo-II, FW06,KW06), (Kangoo-II,
FW06,KW06,FW16,FW56,KW16,KW56,KW66,KW96), (Laguna-III,
KT0S,KT09,KT0F,KT0M,KT0S), (Kangoo-II,
FW15,FW18,FW55,FW58,FWG5,FWG8,FWK5,FWK8,KW25,KW28,KW65,KW68,KW95,KW98),
(Captur-I, 2RAL,2RBL,2REL,2RFL), (Clio-IV, 5RBF,5RDF,5REF), (Clio-IV, 6RBF,6RDF), (Clio-
IV, 7RBF,7RDF,7REF), (Laguna-III, KT08,KT04,KT07,KT0A,KT0B,KT0J,KT0S,), (Laguna-III,
KT18,KT32,KTB8,KTD2,KTE8,KTF2), (Laguna-III,
BT01,DT01,DT02,DT08,DT09,DT0C,DT0D,DT0K,DT0N,DT0W), (Laguna-III,
BT09,BT0F,BT0M,BT0S), (Laguna-III, BT1S,BT18,BT32,BTB8,BTD2,BTE8,BTF2), (Laguna-III,
BT04,BT07,BT0A,BT0B,BT0J,BT0S), (Laguna-III, DT09,DT0F,DT0M,DT0S), (Espace-IV,
JK1J,JK1F,JKFJ,JK01,JK04), (Talisman, L2M), (Talisman, KP__))

Initializing the mass airflow sensor ((Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM),
(Talisman,), (Espace-V, JRFC))

Reset learned values of intake-air flap. ((Fluence, L30A,LZBA), (Fluence,
B306,LZB6,BBB6,BLB6), (Megane-III, DZ0A), (Megane-III, DZ0B), (Megane-III, DZ0C),
(Megane-III, DZ1M), (Megane-III, DZ0D,DZ09,DZ1F,DZ1G), (Megane-III, DZ0J), (Megane-III,
DZ0L), (Megane-III, DZ0Y), (Megane-III, KZ0A), (Megane-III, KZAA), (Megane-III, KZ0B),
(Megane-III, KZ1M), (Megane-III, KZ1W), (Megane-III, KZ0Y), (Megane-III, KZ0C), (Megane-III,
KZ1A), (Megane-III, KZ0D), (Megane-III, KZ1G), (Megane-III, KZ0J), (Megane-III, KZ0N),
(Megane-III, KZ1S), (Megane-III, KZ0L), (Megane-III, BZ0B), (Megane-III, BZ1M), (Megane-III,
BZ1W), (Megane-III, BZ0C), (Megane-III, BZ1A), (Megane-III, BZ0D), (Megane-III, BZ10),
(Megane-III, BZ0N), (Megane-III, BZ1S), (Megane-III, BZ0L), (Megane-III, DZ0N), (Megane-III,
DZ1S), (Megane-III, DZ1W), (Megane-III, DZ1A), (Megane-III, DZ1G), (Scenic-III, JZ07,JZ0B),
(Scenic-III, JZ0L), (Scenic-III, JZ1S), (Fluence, LZBS), (Megane-III, BZ09), (Megane-III, DZ09),
(Fluence, B30A), (Megane-III, BZ0Y), (Megane-III, BZ1F), (Megane-III, BZ1J), (Megane-III,
BZ1K), (Megane-III, DZ1F), (Megane-III, DZ1J), (Megane-III, DZ1K), (Megane-III, EZ09),



Diagnostic devices

(Megane-III, EZ0B), (Megane-III, EZ0D), (Megane-III, EZ0J), (Megane-III, EZ0L), (Megane-III, EZ1G), (Megane-III, KZ09), (Megane-III, KZ1F), (Scenic-III, JZ1K), (Scenic-III, JZ1J), (Megane-III, EZ1W), (Megane-III, EZ1S), (Fluence, LZBD), (Fluence, LZBL), (Laguna-III, BT00), (Laguna-III, KT0A), (Laguna-III, KT19), (Scenic-III, JZ14), (Laguna-III, BT1S,BT18,BT32,BTB8,BTD2,BTE8,BTF2), (Laguna-III, BT12), (Laguna-III, DT12), (Laguna-III, KT12), (Laguna-III, KT1S), (Laguna-III, DT19), (Laguna-III, BT19), (Laguna-III, BT0R), (Laguna-III, KT03), (Scenic-III, JZ0D), (Scenic-III, JZ0B,JZ07), (Scenic-III, JZ1M), (Scenic-III, JZ0J), (Scenic-III, JZ0N), (Scenic-III, JZ0A), (Scenic-III, JZ0Y), (Megane-III, BZ0J), (Megane-III, BZAB), (Megane-III, BZ0A), (Scenic-III, JZ1W), (Scenic-III, JZ1G), (Scenic-III, JZ42), (Scenic-III, JZ00,JZ12), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, DZ00), (Megane-III, DZ02), (Scenic-III, JZ09), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Megane-III, EZ00), (Megane-III, DZ12), (Fluence, LZ00), (Megane-III, EZ12), (Laguna-III, BT11), (Captur-I, J5AL), (Laguna-III, DT11), (Laguna-III, KT11), (Scenic-III, JZ00,JZ02,JZ12,JZ13,JZD2,JZHO,JZNA,JZPA,JZV0,JZYA), (Scenic-III, JZ00), (Scenic-III, JZ12,JZ00), (Kangoo-II, KW05), (Kangoo-II, KW08), (Kangoo-II, KW25), (Kangoo-II, KW28), (Kangoo-II, KW55), (Kangoo-II, KW58), (Kangoo-II, KW45), (Kangoo-II, KW48), (Kangoo-II, KW25,FW15,FW18,FW55,FW58,), (Kangoo-II, KW28,FW15,FW18,FW55,FW58,), (Kangoo-II, KW68,FW15,FW18,FW55,FW58,), (Kangoo-II, KW95,FW15,FW18,FW55,FW58,), (Kangoo-II, KW98,FW15,FW18,FW55,FW58,), (Megane-III, BZ1G), (Megane-III, BZ14), (Fluence, LZLL,LZVV), (Kangoo-II, FW15,FW18,FW55,FW58,FWG5,FWK8,FWK5,KW25,KW28,KW65,KW68,KW95,KW98), (Captur-I, 2RAL,2RBL,2REL,2RFL), (Clio-IV, 5RBF,5RDF,5REF), (Clio-IV, 6RBF,6RDF), (Clio-IV, 7RBF,7RDF,7REF), (Laguna-III, KT1E,KT11,KT1E,KT1N), (Laguna-III, KT0S,KT09,KT0F,KT0M,KT0S), (Laguna-III, KT06,KT2D,KT2W,KT3D,KT3D,KTDD,KTDW,KTFD,KTFW,), (Laguna-III, KT18,KT32,KTB8,KTD2,KTE8,KTF2), (Laguna-III, KT0K,KT1K,KT2B,KT2C,KT3C,KTEK,KTFC), (Laguna-III, KT0A,KT12,KT1A,KT1R,KTE2,KTER), (Laguna-III, DT11,DT1E,DT1N), (Laguna-III, DT1N), (Laguna-III, DT1E), (Laguna-III, BT01,DT01,DT02,DT08,DT09,DT0C,DT0D,DT0K,DT0N,DT0W), (Laguna-III, DT1R,DT1R,DTE2,DTER), (Laguna-III, BT0A,BT12,BT1A,BT1R,BTE2,BTER), (Laguna-III, BT01,BT09,BT11,BT19,BTB1,BTE1,BTE9), (Laguna-III, KT01,KT09,KT11,KT19,KTB1,KTE1,KTE9), (Laguna-III, KT0N,KT1N,KTBN,KTEN), (Laguna-III, BT0K,BT1K,BT2C,BT3C,BTEK,BTFB,BTFC), (Laguna-III, BT0N,BT1N,BTBN,BTEN), (Laguna-III, BT2D,BT2W,BT3D,BT3W,BTFD,BTFW), (Laguna-III, BT09,BT0F,BT0M,BT0S), (Laguna-III, BT01,BT0E,BT0N), (Laguna-III, BT04,BT07,BT0A,BT0B,BT0J,BT0S), (Laguna-III, DT09,DT0F,DT0M,DT0S), (Espace-IV, JK1J,JK1F,JKFJ,JK01,JK04), (Scenic-III,), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman,), (Espace-V, JRFC))

Reset learned values of injectors. ((Laguna-III, KT1E,KT11,KT1E,KT1N), (Laguna-III, KT0S,KT09,KT0F,KT0M,KT0S), (Laguna-III, KT08,KT04,KT07,KT0A,KT0B,KT0J,KT0S), (Laguna-III, KT18,KT32,KTB8,KTD2,KTE8,KTF2), (Laguna-III, DT11,DT1E,DT1N), (Laguna-III, DT1N), (Laguna-III, DT1E), (Laguna-III, BT01,DT01,DT02,DT08,DT09,DT0C,DT0D,DT0K,DT0N,DT0W), (Laguna-III, BT01,BT09,BT11,BT19,BTB1,BTE1,BTE9), (Laguna-III, KT01,KT09,KT11,KT19,KTB1,KTE1,KTE9), (Laguna-III, BT09,BT0F,BT0M,BT0S), (Laguna-III, BT01,BT0E,BT0N), (Espace-IV, JK04,JK1F,JKFJ,JK01,JK1J), (Scenic-II, JM1K), (Scenic-III, JZ0N), (Scenic-III, JZ1S))

Adapting the clutch assembly ((Kadjar, HAxx,HLxx))

Initializing the fuel pressure sensor or the fuel rail ((Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC))

Resetting learned values of fuel pressure regulator ((Kangoo-II, KW02), (Kangoo-II, FW02,KW02), (Kangoo-II, KW02,FW02))

Initializing the differential pressure sensor ((Laguna-III, DT1R,DT1R,DTE2,DTER,DT0_), (Laguna-III, KT0R), (Laguna-III, KT0S,KT09,KT0F,KT0M,KT0S), (Laguna-III, KT08,KT04,KT07,KT0A,KT0B,KT0J,KT0S), (Laguna-III, KT18,KT32,KTB8,KTD2,KTE8,KTF2),



Diagnostic devices

(Laguna-III, KT0A, KT12, KT1A, KT1R, KTE2, KTER), (Laguna-III, BT01, DT01, DT02, DT08, DT09, DT0C, DT0D, DT0K, DT0N, DT0W), (Laguna-III, DT1R, DT1R, DTE2, DTER), (Laguna-III, BT0A, BT12, BT1A, BT1R, BTE2, BTER), (Laguna-III, BT09, BT0F, BT0M, BT0S), (Laguna-III, BT1S, BT18, BT32, BTB8, BTD2, BTE8, BTF2), (Laguna-III, BT04, BT07, BT0A, BT0B, BT0J, BT0S), (Laguna-III, DT09, DT0F, DT0M, DT0S), (Espace-IV, JK1J, JK1F, JKFJ, JK01, JK04), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC))

Initialising the boost pressure regulator ((Captur-I, J5NJ), (Captur-I, J5NK), (Kadjar, HLNB), (Kadjar, HLNC), (Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, B9NC), (Scenic-IV, J9A9, J9N9), (Scenic-IV, J9NB, R9NB), (Scenic-IV, J9NC), (Talisman, LPNC), (Clio-V, B7MF), (Captur-II, RJB), (Captur-I, J5NE), (Koleos-II, HCA), (Clio-V, RJA), (Express, F6MA), (Kadjar, HAxx, HLxx), (Scenic-IV, R9NC), (Talisman, RFD), (Arkana, RJL))

Initializing the starter ring gear ((Scenic-IV, J9A9, J9N9), (Megane-IV, B9NC), (Talisman, RFD), (Arkana, RJL), (Kadjar, HAxx, HLxx))

Learning throttle valve stop ((Captur-I, J5AL, 5R5A, 5R7A, 5RAA, 5RKA, 5RLA, 5RMA, 5RXA), (Kangoo-II, KW02), (Kangoo-II, FW02, KW02), (Captur-I, J5MA, J5AL, 5R5A, 5R7A, 5RAA, 5RKA, 5RLA, 5RMA, 5RXA), (Captur-I, J5MH, J5AL, 5R5A, 5R7A, 5RAA, 5RKA, 5RLA, 5RMA, 5RXA), (Kangoo-II, KW02, FW02), (Scenic-III, JZ0Y, JZ16, JZ1Y, JZD6, JZ0Z, JZ11, JZ1Z, JZ1D), (Scenic-III, JZ16, JZ0Y, JZ1Y, JZD6), (Twingo-III, BCM8), (Megane-II, LM0C), (Captur-I, 2R5A, 2RDA, 2REA, 2RFA, 2RGA, 2RHA), (Scenic-III, JZ1U), (Twingo-II, CN0K, CN04, CN0A, CN0B), (Megane-III, DZ0Z), (Megane-III,), (Clio-IV, R))

Self-adaptation of A/C system ((Scenic-IV, J9MR, R9MR), (Scenic-IV, J9A4), (Scenic-IV, J9A5), (Scenic-IV, J9A3), (Scenic-IV, J9A2), (Scenic-IV, J9MB, J9MB, R9MB), (Scenic-IV, JZ), (Megane-IV, B9A5), (Megane-IV, K9A5), (Kadjar, HLA3), (Koleos-II, HCAK), (Koleos-II, HCA4), (Scenic-IV, J9AE), (Kadjar, HLMH), (Scenic-IV, J9A9, J9N9), (Scenic-IV, J9NB, R9NB), (Scenic-IV, J9NC), (Scenic-IV, J9A7, R9A7), (Scenic-IV, J9A8, R9A8), (Koleos-II, HCA7), (Koleos-II, HCAN), (Koleos-II, None), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Scenic-IV, R9NC), (Talisman, RFD))

Resetting learned values of fuel injector of soot particulate filter ((Fluence, L30A, LZBA), (Fluence, B306, LZB6, BBB6, BLB6), (Megane-III, DZ0A), (Megane-III, DZ0B), (Megane-III, DZ0C), (Megane-III, DZ1M), (Megane-III, DZ0D, DZ09, DZ1F, DZ1G), (Megane-III, DZ0L), (Megane-III, DZ0Y), (Megane-III, KZ0A), (Megane-III, KZAA), (Megane-III, KZ0B), (Megane-III, KZ1M), (Megane-III, KZ1W), (Megane-III, KZ0Y), (Megane-III, KZ0C), (Megane-III, KZ1A), (Megane-III, KZ0D), (Megane-III, KZ1G), (Megane-III, KZ0L), (Megane-III, BZ0B), (Megane-III, BZ1M), (Megane-III, BZ1W), (Megane-III, BZ0C), (Megane-III, BZ1A), (Megane-III, BZ0D), (Megane-III, BZ10), (Megane-III, BZ0L), (Megane-III, DZ1W), (Megane-III, DZ1A), (Megane-III, DZ1G), (Scenic-III, JZ07, JZ0B), (Scenic-III, JZ0L), (Fluence, LZBS), (Megane-III, BZ09), (Megane-III, DZ09), (Fluence, B30A), (Megane-III, BZ0Y), (Megane-III, BZ1F), (Megane-III, DZ1F), (Megane-III, EZ09), (Megane-III, EZ0B), (Megane-III, EZ0D), (Megane-III, EZ0L), (Megane-III, EZ1G), (Megane-III, KZ09), (Megane-III, KZ1F), (Megane-III, EZ1W), (Fluence, LZBD), (Fluence, LZBL), (Laguna-III, BT00), (Laguna-III, KT0A), (Laguna-III, BT0R), (Laguna-III, KT03), (Scenic-III, JZ0D), (Scenic-III, JZ0B, JZ07), (Scenic-III, JZ1M), (Scenic-III, JZ0A), (Scenic-III, JZ0Y), (Megane-III, BZAB), (Megane-III, BZ0A), (Scenic-III, JZ1W), (Scenic-III, JZ1G), (Scenic-III, JZ42), (Scenic-III, JZ14), (Scenic-III, JZ09), (Megane-III, BZ1G), (Fluence, LZLL, LZVV), (Laguna-III, KT0A, KT12, KT1A, KT1R, KTE2, KTER), (Laguna-III, DT1R, DT1R, DTE2, DTER), (Laguna-III, BT0A, BT12, BT1A, BT1R, BTE2, BTER), (Scenic-III,), (Modus, JP04))

Initializing the injection pump ((Scenic-III, JZ14), (Scenic-III, JZ00, JZ12), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, DZ00), (Megane-III, DZ02), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Megane-III, EZ00), (Megane-III, DZ12), (Fluence, LZ00), (Megane-III, EZ12), (Captur-I, J5AL), (Scenic-III, JZ00, JZ02, JZ12, JZ13, JZD2, JZH0, JZNA, JZPA, JZV0, JZYA), (Scenic-III, JZ00), (Scenic-III, JZ12, JZ00), (Kangoo-II, KW05), (Kangoo-II, KW08), (Kangoo-II, KW25), (Kangoo-II, KW28),



Diagnostic devices

(Kangoo-II, KW55), (Kangoo-II, KW58), (Kangoo-II, KW45), (Kangoo-II, KW48), (Kangoo-II, KW25, FW15, FW18, FW55, FW58,), (Kangoo-II, KW28, FW15, FW18, FW55, FW58,), (Kangoo-II, KW65, FW15, FW18, FW55, FW58,), (Kangoo-II, KW68, FW15, FW18, FW55, FW58,), (Kangoo-II, KW95, FW15, FW18, FW55, FW58,), (Kangoo-II, KW98, FW15, FW18, FW55, FW58,), (Trafic-III, FGMA, FGMB, JGMA, JGMB, JRA5), (Megane-III, BZ14), (Kangoo-II, FW06, KW06), (Kangoo-II, FW06, KW06, FW16, FW56, KW16, KW56, KW66, KW96), (Kangoo-II, FW15, FW18, FW55, FW58, FWG5, FWG8, FWK5, FWK8, KW25, KW28, KW65, KW68, KW95, KW98), (Captur-I, 2RAL, 2RBL, 2REL, 2RFL), (Clio-IV, 5RBF, 5RDF, 5REF), (Clio-IV, 6RBF, 6RDF), (Clio-IV, 7RBF, 7RDF, 7REF), (Laguna-III, KT0S, KT09, KT0F, KT0M, KT0S), (Laguna-III, KT08, KT04, KT07, KT0A, KT0B, KT0J, KT0S,), (Laguna-III, KT18, KT32, KBT8, KTD2, KTE8, KTF2), (Laguna-III, BT01, DT01, DT02, DT08, DT09, DT0C, DT0D, DT0K, DT0N, DT0W), (Laguna-III, BT09, BT0F, BT0M, BT0S), (Laguna-III, BT1S, BT18, BT32, BTB8, BTD2, BTE8, BTF2), (Laguna-III, BT04, BT07, BT0A, BT0B, BT0J, BT0S), (Laguna-III, DT09, DT0F, DT0M, DT0S), (Espace-IV, JK1J, JK1F, JKFJ, JK01, JK04))

Resetting high-pressure fuel pump adaptation values ((Scenic-IV, J9A4), (Scenic-IV, J9A7, R9A7), (Scenic-IV, J9A8, R9A8), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC))

Initialising the boost pressure regulator ((Kangoo-II, FW52, FW54,), (Kangoo-II, KW*4))

Resetting the start counter ((Captur-I, J5NJ), (Captur-I, J5NK), (Kadjar, HLNB), (Kadjar, HLNC), (Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, B9NC), (Scenic-IV, J9A9, J9N9), (Twingo-III, BCMD), (Scenic-IV, J9NB, R9NB), (Scenic-IV, J9NC), (Talisman, LPNC), (Clio-V, B7MT), (Clio-V, B7MF), (Captur-II, RJB), (Twingo-III, BCME), (Twingo-III, BCM4), (Twingo-III, BCMJ), (Captur-I, J5NE), (Koleos-II, HCA), (Clio-V, RJA), (Express, F6MA), (Kadjar, HAxx, HLxx), (Scenic-IV, R9NC), (Talisman, RFD), (Arkana, RJL))

Resetting the start inhibitor of DEF injection system ((Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman,), (Espace-V, JRFC))

Learning the throttle valve ((Kangoo-II, FW52, FW54,), (Kangoo-II, KW*4), (Captur-I, J5NJ), (Captur-I, J5NK), (Kadjar, HLNB), (Kadjar, HLNC), (Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, B9NC), (Scenic-IV, J9A9, J9N9), (Twingo-III, BCMD), (Scenic-IV, J9NB, R9NB), (Scenic-IV, J9NC), (Talisman, LPNC), (Clio-V, B7MT), (Clio-V, B7MF), (Captur-II, RJB), (Twingo-III, BCME), (Twingo-III, BCM4), (Twingo-III, BCMJ), (Captur-I, J5NE), (Koleos-II, HCA), (Clio-V, RJA), (Express, F6MA), (Kadjar, HAxx, HLxx), (Scenic-IV, R9NC), (Talisman, RFD), (Arkana, RJL))

Learning the steering-angle sensor ((Arkana, RJL))

Calibrating rear radar sensors ((Espace-V, JRM1), (Espace-V, JRAL), (Espace-V, JRAM), (Talisman, KPAM), (Talisman, LPAM), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL))

Regenerating the soot particulate filter ((Fluence, L30A, LZBA), (Fluence, B306, LZB6, BBB6, BLB6), (Megane-III, DZ0A), (Megane-III, DZ0B), (Megane-III, DZ0C), (Megane-III, DZ1M), (Megane-III, DZ0D, DZ09, DZ1F, DZ1G), (Megane-III, DZ0J), (Megane-III, DZ0L), (Megane-III, DZ0Y), (Megane-III, KZ0A), (Megane-III, KZAA), (Megane-III, KZ0B), (Megane-III, KZ1M), (Megane-III, KZ1W), (Megane-III, KZ0Y), (Megane-III, KZ0C), (Megane-III, KZ1A), (Megane-III, KZ0D), (Megane-III, KZ1G), (Megane-III, KZ0J), (Megane-III, KZ0N), (Megane-III, KZ1S), (Megane-III, KZ0L), (Megane-III, BZ0B), (Megane-III, BZ1M), (Megane-III, BZ1W), (Megane-III, BZ0C), (Megane-III, BZ1A), (Megane-III, BZ0D), (Megane-III, BZ10), (Megane-III, BZ0N), (Megane-III, BZ1S), (Megane-III, BZ0L), (Trafic-II, FL0J), (Trafic-II, FL0V), (Trafic-II, JL0V), (Trafic-II, JL0R), (Megane-III, DZ0N), (Megane-III, DZ1S), (Megane-III, DZ1W), (Megane-III, DZ1A), (Megane-III, DZ1G), (Scenic-III, JZ07, JZ0B), (Scenic-III, JZ0L), (Scenic-III, JZ1S), (Kangoo-II, KW05), (Trafic-II, JL0J), (Trafic-II, EL0J), (Fluence, LZBS), (Kangoo-II, FW05), (Laguna-II, BG0F), (Scenic-II, JM0L), (Megane-III, BZ09), (Megane-III, DZ09), (Scenic-II, JM1D), (Trafic-II, FL0R), (Laguna-II, BG14), (Vel Satis, BJ03), (Vel Satis, BJ0B), (Master-II, JD0Y), (Master-II, JD11), (Master-II, JD12), (Laguna-III, DT1M), (Scenic-II,



Diagnostic devices

JM15), (Scenic-II, JM16), (Scenic-II, JM17), (Megane-II, CM17), (Megane-II, EM17), (Megane-II, KM17), (Megane-II, LM17), (Scenic-II, JM14), (Fluence, B30A), (Megane-III, BZ0Y), (Megane-III, BZ1F), (Megane-III, BZ1J), (Megane-III, BZ1K), (Megane-III, DZ1F), (Megane-III, DZ1J), (Megane-III, DZ1K), (Megane-III, EZ09), (Megane-III, EZ0B), (Megane-III, EZ0D), (Megane-III, EZ0J), (Megane-III, EZ0L), (Megane-III, EZ1G), (Megane-III, KZ09), (Megane-III, KZ1F), (Scenic-III, JZ1K), (Scenic-III, JZ1J), (Laguna-II, KG0F), (Megane-III, EZ1W), (Megane-III, EZ1S), (Trafic-II, EL0R), (Trafic-II, EL0V), (Trafic-II, FLSJ), (Trafic-II, FLSV), (Fluence, LZBD), (Fluence, LZBL), (Laguna-III, BT06), (Laguna-III, BT00), (Laguna-III, BT01), (Laguna-III, BT01, DT01, DT02, DT08, DT09, DT0C, DT0D, DT0K, DT0N, DT0W), (Laguna-III, BT08, BT04, BT07, BT0A, BT0B, BT0J, BT0S), (Laguna-III, BT08), (Laguna-III, BT09), (Laguna-III, BT0E), (Laguna-III, BT0J, BT04, BT07, BT0A, BT0B, BT0S), (Laguna-III, BT0J), (Laguna-III, BT0K), (Laguna-III, BT0M), (Laguna-III, BT0N), (Laguna-III, BT1A), (Laguna-III, BT1C), (Laguna-III, BT1D), (Laguna-III, DT1E), (Laguna-III, BT1E), (Laguna-III, KT01), (Laguna-III, KT08, KT04, KT07, KT0A, KT0B, KT0J, KT0S), (Laguna-III, KT08), (Laguna-III, KT09), (Laguna-III, KT0A), (Laguna-III, KT0J), (Laguna-III, KTOM), (Laguna-III, KT0N), (Laguna-III, KT0N, KT09, KT0F, KT0M, KT0S), (Laguna-III, KT1A), (Laguna-III, KT1D), (Laguna-III, KT1E), (Laguna-III, KT19), (Laguna-III, KT1E, KT11, KT1E, KT1N), (Laguna-III, DT1N), (Kangoo-II, FW0F), (Clio-III, KR1V), (Clio-III, KRAV), (Clio-III, BR2V, BRAV, CR2V, CRAV), (Clio-III, BRAV), (Clio-III, CR1V), (Clio-III, BR1V), (Scenic-III, JZ14), (Laguna-III, BT1S, BT18, BT32, BTB8, BTD2, BTE8, BTF2), (Laguna-II, BG05), (Laguna-II, BG09), (Laguna-II, BG12, BG42, BGE2), (Laguna-II, BG12), (Laguna-II, BG13), (Laguna-II, BG1A), (Laguna-II, BG1S), (Laguna-II, BG44), (Laguna-II, BG1V), (Laguna-II, KG05), (Laguna-II, KG09), (Laguna-II, KG12), (Laguna-II, KG13), (Laguna-II, KG1A), (Laguna-II, KG1N), (Laguna-III, KT1S, KT19, KT1F, KT1M, KT1S), (Laguna-II, KG44), (Laguna-II, KG1V), (Laguna-III, KT0M), (Laguna-III, BT12), (Laguna-III, DT12), (Laguna-III, KT12), (Laguna-III, KT1S), (Laguna-III, DT19), (Laguna-III, BT19), (Laguna-III, BT0R), (Laguna-III, KT03), (Megane-II, KM0L), (Megane-II, KM14), (Megane-II, KM1D), (Megane-II, KM1K), (Megane-II, BM0L), (Megane-II, BM14), (Megane-II, BM17), (Megane-II, BM1C), (Megane-II, BM1D), (Megane-II, BM1K), (Megane-II, CM0L), (Megane-II, CM14), (Megane-II, CM1D), (Megane-II, CM1K), (Megane-II, EM14), (Megane-II, EM1D), (Megane-II, EM1K), (Megane-II, LM0L), (Megane-II, LM13), (Megane-II, LM14), (Megane-II, LM1D), (Megane-II, LM1K), (Scenic-II, JM1K), (Vel Satis, BJ00), (Vel Satis, BJ0H), (Koleos-I, HY0A, VY0A), (Koleos-I, HY0A, VY0A, VY0V, HY0K), (Koleos-I, HY0B, HY0L), (Espace-IV, JR0S), (Espace-IV, JK01, JK1F, JKFF, JK04, JK1J), (Espace-IV, JK02, JK1H, JKFH), (Espace-IV, JK1H, JK02, JKFH), (Laguna-II, KG02), (Laguna-III, KT06, KT06, KT2D, KT2W, KT3D, KT3D, KTDD, KTDW, KTFD, KTFW,), (Laguna-II, KG0G), (Laguna-II, BG0G), (Master-II, JD1Y), (Master-II, JD01), (Master-II, JD02), (Espace-IV, JK03), (Espace-IV, JK04), (Espace-IV, JK07, JK0T), (Scenic-II, JM1G), (Laguna-II, KG43), (Scenic-II, JM17, JM14), (Scenic-III, JZ0D), (Scenic-III, JZ0B, JZ07), (Scenic-III, JZ1M), (Scenic-III, JZ0J), (Scenic-III, JZ0N), (Scenic-III, JZ0A), (Scenic-III, JZ0Y), (Kangoo-II, KW0G), (Megane-II, BMSD), (Megane-II, BMPK), (Megane-II, BMSK), (Megane-II, LMKD), (Megane-II, LMPK), (Megane-II, BMS7), (Megane-II, BM1W), (Megane-II, CM1W), (Megane-III, BZ0J), (Megane-III, BZAB), (Megane-III, BZ0A), (Espace-IV, JK1C), (Espace-IV, JK1G), (Espace-IV, JK1J, JK1F, JKFF, JK01, JK04), (Espace-IV, JK04, JK1F, JKFF, JK01, JK1J), (Scenic-III, JZ1W), (Scenic-III, JZ1G), (Kangoo-II, KW04, KW14, KW17, KW54, KW57), (Kangoo-II, KW24), (Kangoo-II, KW0H, KW2H), (Kangoo-II, KW2H), (Kangoo-II, KW4H), (Koleos-I, HY0K, VY0A), (Kangoo-II, FW05, FW15, FW18, FW55, FW58,), (Kangoo-II, KW05, FW15, FW18, FW55, FW58,), (Modus, JP04), (Scenic-III, JZ42), (Laguna-II, BG4T), (Laguna-II, BGE4), (Laguna-II, BGET), (Laguna-II, KG4T), (Laguna-II, KGET), (Twingo-II, CN00), (Twingo-II, CN03), (Kangoo-II, FW04, FW07, FW14, FW17, FW54, FW57), (Scenic-III, JZ00, JZ12), (Clio-III, KR1H), (Clio-III, KR1S, KRAS, KRCH, KR1H, KR2S,), (Koleos-I, HY0K, VY0K, VY0V, HY0A), (Koleos-I, HY0K), (Koleos-I, HY0L, VY0B), (Koleos-I, HY0L, VY0B), (Clio-III, CR1H, CRAH, CRAH), (Clio-III, BR1H, BR2H, BRAH), (Kangoo-II, FW0G), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, DZ00), (Megane-III, DZ02), (Master-II, ED02), (Master-II, ED0Y), (Master-II, ED01), (Laguna-III, DT1R, DT1R, DTE2, DTER, DT0_), (Scenic-III, JZ09), (Trafic-II,), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Megane-III, EZ00), (Megane-III, DZ12), (Master-III, FV0F), (Master-III, FV0J), (Fluence, LZ00), (Megane-III, EZ12), (Master-III, HV0F), (Master-III, HV0J), (Master-III, UV0F), (Master-III, UV0J), (Master-II, FD0Y), (Laguna-III, BT11), (Captur-I, J5AL), (Laguna-III, DT11), (Laguna-III,



Diagnostic devices

KT11), (Scenic-III, JZ00,JZ02,JZ12,JZ13,JZD2,JZH0,JZNA,JZPA,JZV0,JZYA), (Scenic-III, JZ00), (Scenic-III, JZ12,JZ00), (Kangoo-II, KW08), (Kangoo-II, KW25), (Kangoo-II, KW28), (Kangoo-II, KW55), (Kangoo-II, KW58), (Kangoo-II, KW45), (Kangoo-II, KW48), (Kangoo-II, KW25,FW15,FW18,FW55,FW58,), (Kangoo-II, KW28,FW15,FW18,FW55,FW58,), (Kangoo-II, KW65,FW15,FW18,FW55,FW58,), (Kangoo-II, KW68,FW15,FW18,FW55,FW58,), (Kangoo-II, KW95,FW15,FW18,FW55,FW58,), (Kangoo-II, KW98,FW15,FW18,FW55,FW58,), (Laguna-III, KT0R), (Megane-III, BZ1G), (Trafic-III, FGMD,FGME,JGMD,JGME), (Trafic-III, FGMA,FGMB,JGMA,JGMB,JRA5), (Koleos-I, HY0L,HY0W,VY0W,VY7W), (Trafic-III, FGMA,FGMB,JGMA,JGMB,JRA5,EGMA), (Koleos-I, HY0W,HY0K,HY0L,VY0W,VY7W), (Megane-III, BZ14), (Kangoo-II, FW06,KW06), (Kangoo-II, FW06,KW06,FW16,FW56,KW16,KW56,KW66,KW96), (Laguna-III, KT0S,KT09,KT0F,KT0M,KT0S), (Fluence, LZLL,LZVV), (Master-III, FV0F,FV0J,HV0F,HV0J,UV0F,UV0J), (Master-II, FD), (Master-II, UD), (Master-II, HD), (Master-II, ND), (Master-II, 85), (Master-II, KED), (Master-II, KUD/1), (Master-II, KGD), (Master-II, KUD), (Master-II, 65), (Master-II, X70-CAK), (Master-II, 2050), (Master-II, 2040), (Master-II, EG/R 001), (Laguna-II, BG09,BG19,BG1N,BG4N,BGEN), (Laguna-II, KG09,KG19,KG1N,KG4N,KGEN), (Laguna-II, BG14,BG1T,BG44,BG4T,BGE4,BGET), (Laguna-II, KG14,KG1T,KG44,KG4T,KGE4,KGET), (Megane-II, BM1K,BMSK), (Megane-II, LM1K,LMSK), (Megane-II, KM1K,KMSK), (Megane-II, EM1K,EMSK), (Scenic-II, JM14,JMG4,JMJ4,JMK4,JMS4,JMT4), (Scenic-II, JM1K,JMGK,JMK,JMSK), (Kangoo-II, FW15,FW18,FW55,FW58,FWG5,FWG8,FWK5,FWK8,KW25,KW28,KW65,KW68,KW95,KW98), (Laguna-II, KG12,KG42,KGE2), (Laguna-II, KG42,KGE2), (Laguna-II, BG13,BG43,BGE3), (Laguna-II, KG13,KG43,KGE3), (Laguna-II, BG05,BG15), (Laguna-II, KG05,KG15), (Megane-II, EM14,EMK4,EMS4), (Laguna-II, BG1V,BG4V,BGEV), (Laguna-II, KG1V,KG4V,KGEV), (Kangoo-II, FW1H,KW2H), (Espace-IV, JK1K), (Laguna-II, BG10,BG1A,BG1W,BG4A,BG4W,BGEA,BGEW), (Laguna-II, KG10,KG1A,KG1W,KG4A,KG4W,KGEA,KGEW), (Megane-II, KM1D,KM1G,KM2C,KMKD,KMSD,KMSG), (Megane-II, BMKD,BMSD,BMSG,CMKD,CMSD,CMSG), (Kadjar, HLA4), (Kadjar, HLA3), (Captur-I, 2RAL,2RBL,2REL,2RFL), (Clio-IV, 5RBF,5RDF,5REF), (Kangoo-II,), (Clio-IV, 6RBF,6RDF), (Clio-IV, 7RBF,7RDF,7REF), (Talisman, L2A3,LPA3), (Talisman, L2A4,LPA4), (Talisman, K2A3,KPA3), (Talisman, K2A4, KPA4), (Scenic-IV, J9A5), (Scenic-IV, J9A3), (Scenic-IV, J9A2), (Laguna-III, KT06,KT2D,KT2W,KT3D,KT3D,KTDD,KTDW,KTFD,KTFW,), (Laguna-III, KT18,KT32,KTB8,KT2D,KTE8,KTF2), (Laguna-III, KT0K,KT1K,KT2B,KT2C,KT3C,KTEK,KTFC), (Laguna-III, KT0A,KT12,KT1A,KT1R,KTE2,KTER), (Laguna-III, DT11,DT1E,DT1N), (Laguna-III, DT1R,DT1R,DTE2,DTER), (Laguna-III, BT0A,BT12,BT1A,BT1R,BTE2,BTER), (Laguna-III, BT01,BT09,BT11,BT19,BTB1,BTE1,BTE9), (Laguna-III, KT01,KT09,KT11,KT19,KTB1,KTE1,KTE9), (Laguna-III, KT0N,KT1N,KTBN,KTEN), (Laguna-III, BT0K,BT1K,BT2C,BT3C,BTEK,BTFB,BTFC), (Laguna-III, BT0N,BT1N,BTBN,BTEN), (Laguna-III, BT2D,BT2W,BT3D,BT3W,BTFD,BTFW), (Laguna-III, BT09,BT0F,BT0M,BT0S), (Laguna-III, BT01,BT0E,BT0N), (Laguna-III, BT04,BT07,BT0A,BT0B,BT0J,BT0S), (Laguna-III, DT09,DT0F,DT0M,DT0S), (Koleos-II, HC4K), (Koleos-II, HCA4), (Clio-III, CR1H,CR2S,CRAS,CRCH), (Clio-III, BR1H,BR2S,BRAS,BRCH), (Scenic-III,), (Espace-IV, JK02,JK03), (Talisman,), (Talisman, None), (Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP__), (Megane-IV, B9NC), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL), (Kadjar, HAxx,HLxx))

Adjusting/calibrating matrix LED headlight left ((Espace-V, JRM1), (Espace-V, JRAL), (Espace-V, JRAM), (Talisman, KPAM), (Talisman, LPAM), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))

Resetting gearbox learning values ((Scenic-III, JZ0Y,JZ16,JZ1Y,JZD6,JZ0Z,JZ11,JZ1Z,JZ1D), (Scenic-III, JZ16,JZ0Y,JZ1Y,JZD6), (Scenic-III,), (Espace-IV, JK04,JK1F,JKFJ,JK01,JK1J), (Scenic-III, JZ0A), (Scenic-III, JZ1Y), (Scenic-III, JZ1U), (Scenic-III, JZ0N), (Scenic-III, JZ0Y), (Scenic-III, JZ1S), (Megane-III, DZ0Z), (Megane-III,))

Initializing the exhaust gas flap ((Clio-IV, BHM4), (Clio-IV, KHM4), (Kangoo-II, FW06,KW06), (Kangoo-II, FW06,KW06,FW16,FW56,KW16,KW56,KW66,KW96), (Captur-I, 2RAJ,2RBJ2RAJ,2RBJ,5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I,



Diagnostic devices

2RAJ,2RBJ,2RAJ,2RBJ,5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 2RAR,2RBR), (Clio-IV, 5RBF,5RDF,5REF), (Clio-IV, 5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Clio-IV, 7R0J,7RBJ,7RDJ,7R,JJ,7RKJ,KHAJ), (Clio-IV, 6RBF,6RDF), (Clio-IV, 7RBF,7RDF,7REF), (Clio-IV, 7R01,KHMR), (Clio-IV, 5R01), (Kadjar, HLA3), (Captur-I, 2R06,2R07), (Captur-I, 2R00,2R01,J5AJ), (Kangoo-II, KW05), (Captur-I, J5N4), (Clio-IV, BHN4), (Clio-IV, BHN3), (Clio-IV, KHN4), (Clio-IV, KHAL), (Clio-IV, KHN3), (Espace-V, JRAL), (Espace-V, JRAM), (Kadjar, HLA6), (Megane-IV, K9A2), (Megane-IV, K9A6), (Megane-IV, B9A2), (Megane-IV, B9A6), (Talisman, LPA7), (Talisman, LPA8), (Talisman, KPA7), (Scenic-IV, J9A7,R9A7), (Scenic-IV, J9A8,R9A8), (Talisman, LPAL), (Talisman, LPAM), (Clio-V, B7AD), (Captur-II, RJB), (Kadjar, HLA7), (Talisman, KPAM), (Talisman, KPAL), (Megane-IV, B9A7), (Clio-IV, BHAL), (Trafic-III, JGMN), (Trafic-III, JGML,FGML,EGML), (Koleos-II, HCA7), (Koleos-II, HCAN), (Megane-IV, K9A7), (Trafic-III, JGMM), (Express, F6AA), (Express, F6AB), (Talisman,), (Espace-V, JRFC))

Adjusting/calibrating matrix LED headlight right ((Espace-V, JRM1), (Espace-V, JRAL), (Espace-V, JRAM), (Talisman, KPAM), (Talisman, LPAM), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))

Position the 4-wheel steering in straight forward position ((Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP__), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))

Initializing the ride height sensor ((Espace-IV, JK00), (Espace-IV, JK0G), (Espace-IV, JK09), (Espace-IV, JK0K), (Espace-IV, JK0L), (Espace-IV, JK0Y), (Espace-IV, JK0U,JK0G), (Espace-IV, JK0H), (Espace-IV, JK0J,JK0V,JK0Y), (Espace-IV, JK0B), (Espace-IV, JK0J), (Espace-IV, JK0F), (Espace-IV, JK0U), (Laguna-III, DT1M), (Laguna-III, BT1H), (Espace-IV, JK0P), (Espace-IV, JK0S), (Laguna-III, BT04), (Laguna-III, BT0D), (Laguna-III, BT0U), (Laguna-III, BT06), (Laguna-III, DT0H,DT05), (Laguna-III, KT0G), (Laguna-III, KT0Y,KT1H,KT35,KTD5,KTEH,KTF5), (Laguna-III, BT05), (Laguna-III, BT0F), (Laguna-III, DT0G), (Laguna-III, BT0W), (Laguna-III, KT0F,KT1F,KT3G,KT3K,KTEF,KTFG,KTFK), (Laguna-III, KT0W), (Laguna-III, BT00), (Laguna-III, BT0A,BT12,BT1A,BT1R,BTE2,BTER), (Laguna-III, BT01), (Laguna-III, BT01,DT01,DT02,DT08,DT09,DT0C,DT0D,DT0K,DT0N,DT0W), (Laguna-III, BT08,BT04,BT07,BT0A,BT0B,BT0J,BT0S), (Laguna-III, BT08), (Laguna-III, BT09), (Laguna-III, BT0E), (Laguna-III, BT0J,BT04,BT07,BT0A,BT0B,BT0S), (Laguna-III, BT0J), (Laguna-III, BT0K), (Laguna-III, BT0M), (Laguna-III, BT0N), (Laguna-III, BT1A), (Laguna-III, BT1C), (Laguna-III, BT1D), (Laguna-III, DT1E), (Laguna-III, BT1E), (Laguna-III, KT01), (Laguna-III, KT08,KT04,KT07,KT0A,KT0B,KT0J,KT0S,), (Laguna-III, KT08), (Laguna-III, KT1H), (Laguna-III, KT09), (Laguna-III, KT0A,KT12,KT1A,KT1R,KTE2,KTER), (Laguna-III, KT0A), (Laguna-III, KT0J), (Laguna-III, KTOM), (Laguna-III, KT0N), (Laguna-III, KT0N,KT09,KT0F,KT0M,KT0S), (Laguna-III, KT1A), (Laguna-III, KT1D), (Laguna-III, KT1E), (Laguna-III, KT19), (Laguna-III, KT1E,KT11,KT1E,KT1N), (Laguna-III, DT1N), (Espace-IV, JK0K,JK09), (Laguna-III, BT1S,BT18,BT32,BTB8,BTD2,BTE8,BTF2), (Espace-IV, JK0D), (Espace-IV, JK0E), (Espace-IV, JK0N), (Espace-IV, JK0V), (Espace-IV, JK0W), (Espace-IV, JK1B), (Espace-IV, JK1D), (Laguna-III, KT1S,KT19,KT1F,KT1M,KT1S), (Laguna-III, KT0K), (Laguna-III, KT0M), (Laguna-III, BT12), (Laguna-III, DT12), (Laguna-III, KT12), (Laguna-III, KT1S), (Laguna-III, DT19), (Laguna-III, BT19), (Laguna-III, BT0R), (Laguna-III, KT03), (Espace-IV, JK08), (Espace-IV, JR0S), (Espace-IV, JK01,JK1F,JKFJ,JK04,JK1J,), (Espace-IV, JK02,JK1H,JKFH), (Espace-IV, JK1H,JK02,JKFH), (Laguna-III, KT06,KT06,KT2D,KT2W,KT3D,KT3D,KTDD,KTDW,KTFD,KTFW,), (Laguna-III, BT0H), (Laguna-III, BT0Y), (Laguna-III, KT06,KT1H,KT35,KTD5,KTEH,KTF5), (Laguna-III, BT03), (Laguna-III, BT0T,BT0A,BT12,BT1A,BT1R,BTE2,BTER), (Laguna-III, BT1J,BT0A,BT12,BT1A,BT1R,BTE2,BTER), (Laguna-III, KT1J), (Laguna-III, KT0T), (Laguna-III, BT04,BT1D,), (Laguna-III, BT0D,BT1D,), (Laguna-III, BT0U,BT1D,), (Megane-IV, B9A1), (Espace-IV, JK0A), (Espace-IV, JK03), (Espace-IV, JK04), (Espace-IV, JK07,JK0T), (Espace-IV, JK00), (Laguna-III, BT0G), (Laguna-III, BT03,BT13,BT33,BTA3,BTB3,BTE3,BTF3), (Laguna-III, BT0C), (Laguna-III, BT0P), (Laguna-III, DT0C), (Laguna-III, DT0P,DT0C), (Laguna-III, DT1P), (Laguna-III, KT13), (Laguna-III, KT0P), (Espace-IV, JK0B,JK0D), (Espace-IV, JK1C), (Espace-IV, JK1G), (Espace-IV, JK1J,JK1F,JKFJ,JK01,JK04), (Espace-IV,



Diagnostic devices

JK04,JK1F,JKFJ,JK01,JK1J), (Espace-IV, JK1L), (Espace-IV, JK09,JK0K,JK0L), (Laguna-III, DT0L), (Laguna-III, DT1R,DT1R,DTE2,DTER,DT0_), (Laguna-III, BT11), (Laguna-III, DT11), (Laguna-III, KT11), (Laguna-III, KT0R), (Laguna-III, KT0S,KT09,KT0F,KT0M,KT0S), (Espace-IV, JK1K), (Megane-IV, B9MS), (Megane-IV, B9MR), (Megane-IV, B9A3), (Megane-IV, B9A4), (Talisman, L2A3,LPA3), (Talisman, L2A5,LPA5), (Talisman, L2A4,LPA4), (Talisman, L2MJ,LPMJ), (Talisman, L2MV,LPMV), (Talisman, K2A3,KPA3), (Talisman, K2A5, KPA5), (Talisman, K2A4, KPA4), (Talisman, K2MJ), (Talisman, K2MV, KPMV), (Fluence, LZVJ), (Megane-IV, K9MS), (Megane-IV, K9MR), (Megane-IV, K9A1), (Megane-IV, K9A3), (Megane-IV, K9A4), (Megane-IV, K9M0), (Megane-IV, K9MV), (Megane-IV, B9MV), (Megane-IV, B9M0), (Scenic-IV, J9MR,R9MR), (Scenic-IV, J9A4), (Scenic-IV, J9A5), (Scenic-IV, J9A3), (Scenic-IV, J9A2), (Scenic-IV, J9MB,J9MB,R9MB), (Scenic-IV, JZ), (Scenic-IV, J9AE), (Megane-III, KZ1W), (Fluence, LZLL,LZVV), (Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, K9A2), (Megane-IV, K9A6), (Megane-IV, K9MF), (Megane-IV, B9NC), (Megane-IV, B9A2), (Megane-IV, B9A6), (Megane-IV, B9MF), (Megane-IV, B9M6), (Scenic-IV, J9A9,J9N9), (Talisman, LPA7), (Talisman, LPA8), (Talisman, LPM1), (Talisman, KPA7), (Talisman, KPM1), (Scenic-IV, J9NB,R9NB), (Scenic-IV, J9NC), (Scenic-IV, J9A7,R9A7), (Scenic-IV, J9A8,R9A8), (Megane-IV, B9), (Espace-IV, JK02,JK03), (Talisman, LPAL), (Talisman, LPAM), (Talisman, LPNC), (Talisman, KPAM), (Talisman, KPAL), (Megane-IV, B9M8), (Megane-IV, B9A7), (Talisman, L2M), (Talisman, KP_), (Megane-IV,), (Megane-IV, RFB), (Espace-V, JRFC), (Scenic-IV, R9NC), (Talisman, RFD))

Resetting catalyst adaptation values ((Captur-I, 2RAJ,2RBJ2RAJ,2RBJ,5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 2RAJ,2RBJ,2RAJ,2RBJ,5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 2RAR,2RBR), (Clio-IV, 5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Clio-IV, 7R0J,7RBJ,7RDJ,7R,JJ,7RKJ,KHAJ), (Kangoo-II, KW32,FW42,KW42), (Talisman, L2A3,LPA3), (Talisman, L2A5,LPA5), (Talisman, L2A4,LPA4), (Talisman, K2A3,KPA3), (Talisman, K2A5, KPA5), (Talisman, K2A4, KPA4), (Clio-IV, 7R01,KHMR), (Clio-IV, 5R01), (Captur-I, 2R06,2R07), (Captur-I, 2R00,2R01,J5AJ), (Kangoo-II, KWS8,KWE8,KWR8,FWG8), (Koleos-II, HCAK), (Koleos-II, HCA4), (Captur-I, J5N4), (Clio-IV, BHN4), (Clio-IV, BHN3), (Clio-IV, KHN4), (Clio-IV, KHN3), (Kangoo-II, FW17), (Kangoo-II, None), (Kangoo-II, FW0G), (Talisman,), (Talisman, None), (Kangoo-II, KW06,KW12,FW06,FW12), (Talisman, L2M), (Talisman, KP_))

Calibrate radar dynamically ((Zoe, FFFM), (Zoe, BFMC,BFMD), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL))

Initializing the intake cam phaser ((Talisman, RFD))

Initializing the intake-air flap ((Talisman, L2M), (Talisman, KP_))

Resetting catalyst adaptation values ((Megane-IV, B9A4), (Megane-IV, K9A4), (Scenic-IV, J9A4), (Scenic-IV, J9AE))

Adapting the clutch biting point ((Espace-IV, JK04,JK1F,JKFJ,JK01,JK1J))

Learning the turbocharger ((Twingo-III, BCMD), (Twingo-III, BCME))

Bleeding the brake system ((Wind, E4MB), (Wind, E4MF,EN0F,EN1F), (Wind, E4MC))

Standardizing the liftgate ((Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))

Reset learned values of the EGR bypass valve ((Talisman, L2M), (Talisman, KP_))

Resetting EGR valve learning values ((Laguna-III, DT1R,DT1R,DTE2,DTER,DT0_), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Captur-I, J5AL), (Laguna-III, KT0R), (Laguna-III, KT0S,KT09,KT0F,KT0M,KT0S), (Captur-I, 2RAL,2RBL,2REL,2RFL), (Clio-IV, 5RBF,5RDF,5REF), (Clio-IV, 6RBF,6RDF), (Clio-IV, 7RBF,7RDF,7REF), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman,), (Espace-V, JRFC))



Diagnostic devices

Resetting learned values of steering angle sensor ((Megane-III, DZ0F), (Megane-III, DZ0A), (Megane-III, DZ0B), (Megane-III, DZ0C), (Megane-III, DZ1M), (Megane-III, DZ0D,DZ09,DZ1F,DZ1G), (Megane-III, DZ03), (Megane-III, DZ0J), (Megane-III, DZ1P), (Megane-III, DZ0L), (Megane-III, DZ0Y), (Megane-III, DZ0G,DZ1E), (Megane-III, DZ0K), (Megane-III, DZ1N), (Megane-III, KZ0F), (Megane-III, KZ1V), (Megane-III, KZ0A), (Megane-III, KZAA), (Megane-III, KZ0B), (Megane-III, KZ1M), (Megane-III, KZ1W), (Megane-III, KZ0Y), (Megane-III, KZ0G), (Megane-III, KZ0K), (Megane-III, KZ0C), (Megane-III, KZ1A), (Megane-III, KZ0D), (Megane-III, KZ1G), (Megane-III, KZ03), (Megane-III, KZG3), (Megane-III, KZ0H), (Megane-III, KZ0U), (Megane-III, KZ0V), (Megane-III, KZ0J), (Megane-III, KZ0N), (Megane-III, KZ1S), (Megane-III, KZ0L), (Megane-III, BZ0F), (Megane-III, BZ1V), (Megane-III, BZ0B), (Megane-III, BZ1M), (Megane-III, BZ1W), (Megane-III, BZ0C), (Megane-III, BZ1A), (Megane-III, BZ0D), (Megane-III, BZ10), (Megane-III, BZAR), (Megane-III, BZ0H), (Megane-III, BZ03,BZM4,BZ24,BZ0U,BZ0V), (Megane-III, BZ0U), (Megane-III, BZAF), (Megane-III, BZ03), (Megane-III, BZ0N), (Megane-III, BZ1S), (Megane-III, BZ0L), (Megane-III, BZ0G), (Megane-III, BZ0K), (Megane-III, BZ1U), (Megane-III, DZ0N), (Megane-III, DZ1S), (Megane-III, DZ1V), (Megane-III, DZ1W), (Megane-III, DZ1A), (Megane-III, DZ1G), (Megane-III, DZ0U), (Megane-III, KZ1P), (Megane-III, BZ1P), (Scenic-III, JZ07,JZ0B), (Scenic-III, JZ0L), (Scenic-III, JZ1S), (Megane-III, BZ01), (Megane-III, BZ09), (Megane-III, DZ09), (Laguna-III, DT1M), (Laguna-III, BT1H), (Megane-III, BZ0Y), (Megane-III, BZ1B), (Megane-III, BZ1F), (Megane-III, BZ1H), (Megane-III, BZ1J), (Megane-III, BZ1K), (Megane-III, DZ0G), (Megane-III, BZ1E), (Megane-III, DZ0H), (Megane-III, DZ1B), (Megane-III, DZ1E), (Megane-III, DZ1F), (Megane-III, DZ1H), (Megane-III, DZ1J), (Megane-III, DZ1K), (Megane-III, EZ03), (Megane-III, EZ09), (Megane-III, EZ0B), (Megane-III, EZ0D), (Megane-III, EZ0F), (Megane-III, EZ0G), (Megane-III, EZ0J), (Megane-III, EZ0K), (Megane-III, EZ0L), (Megane-III, EZ0U), (Megane-III, EZ1E), (Megane-III, EZ1G), (Megane-III, EZ1P), (Megane-III, EZ1T), (Megane-III, EZ1U), (Megane-III, EZ1V), (Megane-III, KZ09), (Megane-III, KZ1B), (Megane-III, KZ1F), (Scenic-III, JZ1K), (Scenic-III, JZ1J), (Megane-III, EZ1W), (Megane-III, EZ1Y), (Megane-III, EZ1S), (Laguna-III, BT04), (Laguna-III, BT0D), (Laguna-III, BT0U), (Laguna-III, BT06), (Laguna-III, DT0H,DT05), (Laguna-III, KT0G), (Laguna-III, KT0Y,KT1H,KT35,KTD5,KTEH,KTF5), (Laguna-III, KT0H,KT1H,KT35,KTD5,KTEH,KTF5), (Laguna-III, BT05), (Laguna-III, BT0F), (Laguna-III, DT0G), (Laguna-III, BT0W), (Laguna-III, KT0F,KT1F,KT3G,KT3K,KTEF,KTFG,KTFK), (Laguna-III, KT0W), (Laguna-III, BT00), (Laguna-III, BT0A,BT12,BT1A,BT1R,BTE2,BTER), (Laguna-III, BT01), (Laguna-III, BT01,DT01,DT02,DT08,DT09,DT0C,DT0D,DT0K,DT0N,DT0W), (Laguna-III, BT08,BT04,BT07,BT0A,BT0B,BT0J,BT0S), (Laguna-III, BT08), (Laguna-III, BT09), (Laguna-III, BT0E), (Laguna-III, BT0J,BT04,BT07,BT0A,BT0B,BT0S), (Laguna-III, BT0J), (Laguna-III, BT0K), (Laguna-III, BT0M), (Laguna-III, BT0N), (Laguna-III, BT1A), (Laguna-III, BT1C), (Laguna-III, BT1D), (Laguna-III, DT1E), (Laguna-III, BT1E), (Laguna-III, KT01), (Laguna-III, KT08,KT04,KT07,KT0A,KT0B,KT0J,KT0S,), (Laguna-III, KT08), (Laguna-III, KT1H), (Laguna-III, KT09), (Laguna-III, KT0A,KT12,KT1A,KT1R,KTE2,KTER), (Laguna-III, KT0A), (Laguna-III, KT0J), (Laguna-III, KTOM), (Laguna-III, KT0N), (Laguna-III, KT0N,KT09,KT0F,KT0M,KT0S), (Laguna-III, KT1A), (Laguna-III, KT1D), (Laguna-III, KT1E), (Laguna-III, KT19), (Laguna-III, KT1E,KT11,KT1E,KT1N), (Laguna-III, DT1N), (Scenic-III, JZ14), (Laguna-III, BT1S,BT18,BT32,BTB8,BTD2,BTE8,BTF2), (Laguna-III, KT1S,KT19,KT1F,KT1M,KT1S), (Laguna-III, KT0K), (Laguna-III, KT0M), (Laguna-III, BT12), (Laguna-III, DT12), (Laguna-III, KT12), (Laguna-III, KT1S), (Laguna-III, DT19), (Laguna-III, BT19), (Laguna-III, BT0R), (Laguna-III, KT03), (Laguna-III, KT06,KT2D,KT2W,KT3D,KT3D,KTDD,KTDW,KTFD,KTFW,), (Laguna-III, BT0H), (Laguna-III, BT0Y), (Laguna-III, KT06,KT1H,KT35,KTD5,KTEH,KTF5), (Laguna-III, BT03), (Laguna-III, BT0T,BT0A,BT12,BT1A,BT1R,BTE2,BTER), (Laguna-III, KT1J), (Laguna-III, KT0T), (Laguna-III, BT04,BT1D,), (Laguna-III, BT0D,BT1D,), (Laguna-III, BT0U,BT1D,), (Megane-IV, B9A1), (Scenic-III, JM16), (Laguna-III, BT0G), (Laguna-III, BT03,BT13,BT33,BTA3,BTB3,BTE3,BTF3), (Laguna-III, BT0C), (Laguna-III, BT0P), (Laguna-III, DT0C), (Laguna-III, DT0P,DT0C), (Laguna-III, DT1P), (Laguna-III, KT13), (Laguna-III, KT0P), (Scenic-III, JZ0D), (Scenic-III, JZ03), (Scenic-III, JZ0U), (Scenic-III, JZ0B,JZ07), (Scenic-III, JZ1M), (Scenic-III, JZ0F,JZ1V,JZDV), (Scenic-III, JZ0G), (Scenic-III, JZ1P), (Scenic-III, JZ0J), (Scenic-III, JZ0N), (Scenic-III, JZ0A), (Scenic-III, JZ0Y), (Scenic-III, JZ1Y), (Scenic-II, JM16), (Megane-III, BZ0J), (Megane-III,



Diagnostic devices

BZAB), (Megane-III, BZ0A), (Clio-IV, BHMA), (Clio-IV, KHMA), (Scenic-III, JZ1V,JZDV,JZ0F), (Scenic-III, JZ1W), (Scenic-III, JZ1G), (Scenic-III, JZ1E), (Scenic-III, JZ1U), (Scenic-III, JZ42), (Scenic-III, JZ00,JZ12), (Laguna-III, DT0L), (Megane-III, DZ15), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, KZ01), (Megane-III, DZ00), (Megane-III, DZ02), (Megane-III, DZ11,DZ2B), (Megane-III, DZ01), (Laguna-III, DT1R,DT1R,DTER,DT0_), (Megane-III, DZ08), (Scenic-III, JZ11,JZ0Z,JZ1Z,JZD1), (Scenic-III, JZ09), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Clio-IV, BHMG), (Clio-IV, BHMK), (Clio-IV, KHMG,KHAK), (Clio-IV, KHMG), (Clio-IV, BHML), (Clio-IV, KHML), (Clio-IV, BHMH), (Clio-IV, BHMM), (Scenic-III, JZ16,JZ0Y,JZ1Y,JZD6), (Megane-III, BZ16), (Megane-III, KZ16), (Megane-III, DZ16,DZ28), (Megane-III, EZ16), (Megane-III, BZ11), (Megane-III, BZ1Y), (Megane-III, EZ00), (Megane-III, DZ12), (Megane-III, KZ1Y), (Megane-III, KZ1T), (Megane-III, DZ0_), (Megane-III, BZ1T), (Megane-III, BZ1T,BZ0K), (Megane-III, DZ17), (Megane-III, DZ18), (Megane-III, EZ12), (Megane-III, L331), (Megane-III, L332), (Megane-III, BZL2), (Laguna-III, BT11), (Captur-I, J5M0), (Captur-I, J5AL), (Captur-I, J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Laguna-III, DT11), (Laguna-III, KT11), (Scenic-III, JZ00,JZ02,JZ12,JZ13,JZD2,JZH0,JZNA,JZPA,JZV0,JZYA), (Captur-I, BHM0), (Captur-I, KHM0), (Captur-I, 5R40), (Captur-I, 5RU0), (Scenic-III, JZ09,JZ11,JZ0Z,JZ1Z,JZD1), (Scenic-III, JZ00), (Scenic-III, JZ12,JZ00), (Laguna-III, KT0R), (Megane-III, BZ23), (Megane-III, BZ1G), (Megane-III, DZ21), (Megane-III, DZ23), (Trafic-III, FGMD,FGME,JGMD,JGME), (Trafic-III, FGMA,FGMB,JGMA,JGMB,JRA5,EGMA), (Megane-III, BZ14), (Captur-I, J5MA,J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Captur-I, J5MH,J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Zoe, BFMA), (Twingo-III, BCM1), (Laguna-III, KT0S,KT09,KT0F,KT0M,KT0S), (Kadjar, HLA4), (Kadjar, HLMR), (Kadjar, HLA3), (Captur-I, 2RAU,2RBU), (Captur-I, 2RAL,2RBL,2REL,2RFL), (Captur-I, 2RAJ,2RBJ2RAJ,2RBJ,5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 2RAJ,2RBJ,2RAJ,2RBJ,5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 2RA1,2RB1,2RD1,2RE1,), (Captur-I, 2RA1,2RB1,2RD1,2RE1), (Captur-I, 2RAR,2RBR), (Clio-IV, 5RB2,5RD2,5RD3), (Clio-IV, 5RBF,5RDF,5REF), (Clio-IV, 5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Captur-I, 5R0J,5RBJ,5RDJ,5RJJ,5RKJ), (Clio-IV, 7R0J,7RBJ,7RDJ,7R,JJ,7RKJ,KHAJ), (Megane-IV, B9MS), (Megane-IV, B9MR), (Megane-IV, B9A3), (Megane-IV, B9A4), (Clio-IV, 5R22,BHM1), (Clio-IV, 6RBF,6RDF), (Clio-IV, 7R22,KHM1), (Clio-IV, 7R22,7R24,7R2R,7R32,7RB2,7RD2,7RE2,KHM1), (Clio-IV, 7RBF,7RDF,7REF), (Captur-I, 7RBU), (Clio-IV, 5R93), (Talisman, L2A3,LPA3), (Talisman, L2A5,LPA5), (Talisman, L2A4,LPA4), (Talisman, L2MJ,LPMJ), (Talisman, L2MV,LPMV), (Talisman, K2A3,KPA3), (Talisman, K2A5, KPA5), (Talisman, K2A4, KPA4), (Talisman, K2MJ), (Talisman, K2MV, KPMV), (Fluence, LZVJ), (Clio-IV, 2RAU,2RBU), (Megane-IV, K9MS), (Megane-IV, K9MR), (Megane-IV, K9A1), (Megane-IV, K9A3), (Megane-IV, K9A4), (Megane-IV, K9M0), (Megane-IV, K9MV), (Megane-IV, B9MV), (Megane-IV, B9M0), (Clio-IV, 7R01,KHMR), (Clio-IV, 6RRN,6RSN), (Clio-IV, 5RBU), (Clio-IV, 5R01), (Clio-IV, 7RBU,KHAU), (Scenic-IV, J9MR,R9MR), (Scenic-IV, J9A4), (Scenic-IV, J9A5), (Scenic-IV, J9A3), (Scenic-IV, J9A2), (Clio-IV, 7RBU, KHAU), (Scenic-IV, J9MB,J9MB,R9MB), (Scenic-IV, JZ), (Megane-IV, B9A5), (Megane-IV, K9A5), (Captur-I, 2R04,2R05), (Captur-I, 2R02,2R03), (Captur-I, 2R06,2R07), (Captur-I, 2R00,2R01,J5AJ), (Espace-V, JRM1), (Laguna-III, KT0F,KT0F,KT1F,KT3G,KT3K,KTEF,KTFG,KTFK), (Laguna-III, KT06,KT2D,KT2W,KT3D,KT3D,KTDD,KTDW,KTFD,KTFW,), (Laguna-III, KT18,KT32,KTB8,KTD2,KTE8,KTF2), (Laguna-III, KT0K,KT1K,KT2B,KT2C,KT3C,KTEK,KTFC), (Laguna-III, DT11,DT1E,DT1N), (Laguna-III, DT1R,DT1R,DTER), (Laguna-III, BT01,BT09,BT11,BT19,BTB1,BTE1,BTE9), (Laguna-III, KT01,KT09,KT11,KT19,KTB1,KTE1,KTE9), (Laguna-III, KT0N,KT1N,KTBN,KTEN), (Laguna-III, BT0K,BT1K,BT2C,BT3C,BTEK,BTFB,BTFC), (Laguna-III, BT0N,BT1N,BTBN,BTEN), (Laguna-III, BT2D,BT2W,BT3D,BT3W,BTFD,BTFW), (Laguna-III, BT09,BT0F,BT0M,BT0S), (Laguna-III, BT01,BT0E,BT0N), (Laguna-III, BT0F,BT0F,BT1F,BT3G,BT3K,BTEF,BTFG,BTFK), (Laguna-III, BT1H,BT35,BTD5,BTEH,BTF5), (Laguna-III, BT0G,BTBG), (Laguna-III, BT04,BT07,BT0A,BT0B,BT0J,BT0S), (Laguna-III, DT09,DT0F,DT0M,DT0S), (Koleos-II, HCAK), (Koleos-II, HCA4), (Scenic-III, JZ0Y,JZ16,JZ1Y,JZD6,JZ0Z,JZ11,JZ1Z,JZ1D), (Scenic-IV, J9AE), (Twingo-III, BCM8), (Fluence, LZLL,LZVV), (Captur-I, 5R33,5R24,5R2R,5R32,5RB2,5RD2,5RE2), (Captur-I, 2R5A,2RDA,2REA,2RFA,2RGA,2RHA),



Diagnostic devices

(Captur-I, 5RBU), (Kadjar, HLMH), (Espace-IV, JK1J, JK1F, JKFJ, JK01, JK04), (Scenic-III, JZ0Y, JZ16, JZ1Y, JZD6, JZ0Z, JZ11, JZ1Z, JZ1D, JZ16, JZ0Y, JZ1Y, JZD6), (Trafic-III, JGML, FGML), (Trafic-III, JGMH, EGMH), (Trafic-III, JGMJ, FGMR), (Scenic-III,), (Captur-I, J5M1, J5NF), (Captur-I, J5AU), (Captur-I, J5NJ), (Captur-I, J5NK), (Captur-I, J5N4), (Clio-IV, BHA1), (Clio-IV, BHAK), (Clio-IV, BHN4), (Clio-IV, BHN3), (Clio-IV, KHNF), (Clio-IV, KHN4), (Clio-IV, KHN3), (Espace-V, JRAL), (Espace-V, JRAM), (Kadjar, HLNB), (Kadjar, HLNC), (Kadjar, HLA6), (Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, K9A2), (Megane-IV, K9A6), (Megane-IV, K9MF), (Megane-IV, B9NC), (Megane-IV, B9A2), (Megane-IV, B9A6), (Megane-IV, B9MF), (Megane-IV, B9M6), (Megane-III, DZ16), (Scenic-IV, J9A9, J9N9), (Zoe, BFMF), (Twingo-III, BCMD), (Trafic-III, JGMK, JGMS, FGMK), (Talisman, LPA7), (Talisman, LPA8), (Talisman, LPM1), (Talisman, KPA7), (Talisman, KPM1), (Scenic-IV, J9NB, R9NB), (Scenic-IV, J9NC), (Scenic-IV, J9A7, R9A7), (Scenic-IV, J9A8, R9A8), (Megane-IV, B9), (Clio-IV, BHMM, BHJ4, BHJ6), (Talisman, LPAL), (Talisman, LPAM), (Talisman, LPNC), (Kadjar, HLA7), (Talisman, KPAM), (Talisman, KPAL), (Megane-IV, B9M8), (Megane-IV, B9A7), (Zoe, FFMA), (Zoe, FFMB), (Twingo-III, BCME), (Twingo-III, BCM4), (Twingo-III, BCMJ), (Megane-III, DZ0Z), (Megane-III,), (Megane-III, RFB), (Clio-IV, R), (Clio-IV, BHN), (Clio-IV, BHNF), (Clio-IV, BHM1, BHNF), (Clio-IV, KHNP), (Trafic-III, JGMN), (Trafic-III, JGML, FGML, EGML), (Talisman,), (Talisman, None), (Captur-I, J5NE), (Koleos-II, HCA7), (Koleos-II, HCAN), (Koleos-II, None), (Megane-IV, K9A7), (Talisman, L2M), (Talisman, KP_), (Trafic-III, JGMM), (Clio-IV, BHM0), (Koleos-II, HCA), (Megane-IV,), (Twingo-III, BCA1), (Express, F6MA), (Kadjar, HAxx, HLxx), (Megane-IV, RFB), (Espace-V, JRFC), (Scenic-IV, R9NC), (Talisman, RFD))

Resetting learned values of camshaft sensor ((Kangoo-II, KW02), (Kangoo-II, FW02, KW02), (Kangoo-II, KW02, FW02), (Clio-V, B7MT), (Captur-II, RJB))

Initialize classification resistance of transfer case ((Twingo-III, BCM1), (Twingo-III, BCM8))

De/activating the parking brake service mode ((Megane-III, DZ0F), (Megane-III, DZ0A), (Megane-III, DZ0B), (Megane-III, DZ0C), (Megane-III, DZ1M), (Megane-III, DZ0D, DZ09, DZ1F, DZ1G), (Megane-III, DZ03), (Megane-III, DZ0J), (Megane-III, DZ1P), (Megane-III, DZ0L), (Megane-III, DZ0Y), (Megane-III, DZ0G, DZ1E), (Megane-III, DZ0K), (Megane-III, DZ1N), (Megane-III, KZ0F), (Megane-III, KZ1V), (Megane-III, KZ0A), (Megane-III, KZAA), (Megane-III, KZ0B), (Megane-III, KZ1M), (Megane-III, KZ1W), (Megane-III, KZ0Y), (Megane-III, KZ0G), (Megane-III, KZ0K), (Megane-III, KZ0C), (Megane-III, KZ1A), (Megane-III, KZ0D), (Megane-III, KZ1G), (Megane-III, KZ03), (Megane-III, KZG3), (Megane-III, KZ0H), (Megane-III, KZ0U), (Megane-III, KZ0V), (Megane-III, KZ0J), (Megane-III, KZ0N), (Megane-III, KZ1S), (Megane-III, KZ0L), (Megane-III, BZ0F), (Megane-III, BZ1V), (Megane-III, BZ0B), (Megane-III, BZ1M), (Megane-III, BZ1W), (Megane-III, BZ0C), (Megane-III, BZ1A), (Megane-III, BZ0D), (Megane-III, BZ10), (Megane-III, BZAR), (Megane-III, BZ0H), (Megane-III, BZ03, BZM4, BZ24, BZ0U, BZ0V), (Megane-III, BZ0U), (Megane-III, BZAF), (Megane-III, BZ03), (Megane-III, BZ0N), (Megane-III, BZ1S), (Megane-III, BZ0L), (Megane-III, BZ0G), (Megane-III, BZ0K), (Megane-III, BZ1U), (Megane-III, DZ0N), (Megane-III, DZ1S), (Megane-III, DZ1V), (Megane-III, DZ1W), (Megane-III, DZ1A), (Megane-III, DZ1G), (Megane-III, DZ0U), (Megane-III, KZ1P), (Megane-III, BZ1P), (Scenic-III, JZ07, JZ0B), (Scenic-III, JZ0L), (Scenic-III, JZ1S), (Megane-III, BZ01), (Megane-III, BZ09), (Megane-III, DZ09), (Megane-III, BZ0Y), (Megane-III, BZ1B), (Megane-III, BZ1F), (Megane-III, BZ1H), (Megane-III, BZ1J), (Megane-III, BZ1K), (Megane-III, DZ0G), (Megane-III, BZ1E), (Megane-III, DZ0H), (Megane-III, DZ1B), (Megane-III, DZ1E), (Megane-III, DZ1F), (Megane-III, DZ1H), (Megane-III, DZ1J), (Megane-III, DZ1K), (Megane-III, EZ03), (Megane-III, EZ09), (Megane-III, EZ0B), (Megane-III, EZ0D), (Megane-III, EZ0F), (Megane-III, EZ0G), (Megane-III, EZ0J), (Megane-III, EZ0K), (Megane-III, EZ0L), (Megane-III, EZ0U), (Megane-III, EZ1E), (Megane-III, EZ1G), (Megane-III, EZ1P), (Megane-III, EZ1T), (Megane-III, EZ1U), (Megane-III, EZ1V), (Megane-III, KZ09), (Megane-III, KZ1B), (Megane-III, KZ1F), (Scenic-III, JZ1K), (Scenic-III, JZ1J), (Megane-III, EZ1W), (Megane-III, EZ1Y), (Megane-III, EZ1S), (Scenic-III, JZ14), (Scenic-III, JM16), (Scenic-III, JZ0D), (Scenic-III, JZ03), (Scenic-III, JZ0U), (Scenic-III, JZ0B, JZ07), (Scenic-III, JZ1M), (Scenic-III, JZ0F, JZ1V, JZDV), (Scenic-III, JZ0G), (Scenic-III, JZ1P), (Scenic-III, JZ0J), (Scenic-III, JZ0N), (Scenic-III, JZ0A), (Scenic-III, JZ0Y), (Scenic-III, JZ1Y), (Scenic-II, JM16), (Megane-III, BZ0J), (Megane-III, BZAB), (Megane-III, BZ0A), (Scenic-III, JZ1V, JZDV, JZ0F), (Scenic-III, JZ1W),



Diagnostic devices

(Scenic-III, JZ1G), (Scenic-III, JZ1E), (Scenic-III, JZ1U), (Scenic-III, JZ42), (Scenic-III, JZ00,JZ12), (Megane-III, DZ15), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, KZ01), (Megane-III, DZ00), (Megane-III, DZ02), (Megane-III, DZ11,DZ2B), (Megane-III, DZ01), (Megane-III, DZ08), (Scenic-III, JZ11,JZ0Z,JZ1Z,JZD1), (Scenic-III, JZ09), (Scenic-III, JZ16,JZ0Y,JZ1Y,JZD6), (Megane-III, BZ16), (Megane-III, KZ16), (Megane-III, DZ16,DZ28), (Megane-III, EZ16), (Megane-III, BZ11), (Megane-III, BZ1Y), (Megane-III, EZ00), (Megane-III, DZ12), (Megane-III, KZ1Y), (Megane-III, KZ1T), (Megane-III, DZ0_), (Megane-III, BZ1T), (Megane-III, BZ1T,BZ0K), (Megane-III, DZ17), (Megane-III, DZ18), (Megane-III, EZ12), (Megane-III, L331), (Megane-III, L332), (Megane-III, BZL2), (Scenic-III, JZ00,JZ02,JZ12,JZ13,JZD2,JZH0,JZNA,JZPA,JZV0,JZYA), (Scenic-III, JZ09,JZ11,JZ0Z,JZ1Z,JZD1), (Scenic-III, JZ00), (Scenic-III, JZ12,JZ00), (Megane-III, BZ23), (Megane-III, BZ1G), (Megane-III, DZ21), (Megane-III, DZ23), (Megane-III, BZ14), (Megane-III, DZ16), (Clio-V, B7MT), (Clio-V, B7MF), (Clio-V, B7AD), (Captur-II, RJB), (Zoe, FFFM), (Megane-III, RFB), (Zoe, BFMC,BFMD), (Clio-V, RJA), (Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Arkana,), (Arkana, RJL), (Express, F6AA), (Express, F6AB), (Megane-IV, B9NC), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))

Resetting the mixture adjustment ((Megane-III, DZ0F), (Megane-III, DZ03), (Megane-III, DZ1P), (Megane-III, DZ0G,DZ1E), (Megane-III, DZ0K), (Megane-III, DZ1N), (Megane-III, KZ0F), (Megane-III, KZ1V), (Megane-III, KZ0G), (Megane-III, KZ0K), (Megane-III, KZ03), (Megane-III, KZ0V), (Megane-III, BZ0F), (Megane-III, BZ1V), (Megane-III, BZ03,BZM4,BZ24,BZ0U,BZ0V), (Megane-III, BZ0G), (Megane-III, BZ0K), (Megane-III, BZ1U), (Megane-III, DZ1V), (Megane-III, DZ0U), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, BZ1B), (Megane-III, BZ1H), (Megane-III, DZ0G), (Megane-III, EZ0F), (Megane-III, EZ0G), (Megane-III, EZ0K), (Megane-III, EZ0U), (Megane-III, EZ1E), (Megane-III, EZ1P), (Megane-III, EZ1U), (Megane-III, EZ1V), (Megane-III, KZ1B), (Megane-III, EZ1T), (Scenic-III, JZ0F,JZ1V,JZDV), (Scenic-III, JZ0G), (Scenic-III, JZ1P), (Megane-III, BZ0H), (Clio-IV, BHMA), (Clio-IV, KHMA), (Scenic-III, JZ1V,JZDV,JZ0F), (Megane-III, BZ01), (Megane-III, DZ15), (Megane-III, KZ01), (Megane-III, DZ11,DZ2B), (Megane-III, DZ01), (Megane-III, DZ08), (Scenic-III, JZ11,JZ0Z,JZ1Z,JZD1), (Clio-IV, BHMH), (Megane-III, BZ11), (Megane-III, BZ1T), (Megane-III, KZ1T), (Megane-III, DZ17), (Megane-III, DZ18), (Captur-I, J5M0), (Captur-I, J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Captur-I, BHM0), (Captur-I, KHM0), (Captur-I, 5R40), (Captur-I, 5RU0), (Scenic-III, JZ09,JZ11,JZ0Z,JZ1Z,JZD1), (Megane-III, BZ23), (Megane-III, DZ21), (Megane-III, DZ23), (Clio-IV, KHM0), (Kangoo-II, KW02), (Kangoo-II, FW02,KW02), (Captur-I, J5MA,J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Captur-I, J5MH,J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Kangoo-II, KW02,FW02), (Kangoo-II, FW52,FW54,), (Kangoo-II, KW*4), (Captur-I, 2R5A,2RDA,2REA,2RFA,2RGA,2RHA), (Clio-IV, R), (Clio-IV, BHM0))

Adapting the variable camshaft timing ((Megane-III, DZ1P), (Megane-III, DZ0G,DZ1E), (Megane-III, DZ0K), (Megane-III, DZ1N), (Megane-III, KZ0G), (Megane-III, KZ0K), (Megane-III, BZ0G), (Megane-III, BZ0K), (Megane-III, KZ1P), (Megane-III, BZ1P), (Megane-III, DZ0G), (Megane-III, EZ0G), (Megane-III, EZ0K), (Megane-III, EZ1E), (Megane-III, EZ1P), (Megane-III, EZ1T), (Scenic-III, JZ0G), (Scenic-III, JZ1P), (Clio-IV, BHMA), (Clio-IV, KHMA), (Megane-III, BZ01), (Megane-III, DZ15), (Megane-III, KZ01), (Megane-III, DZ11,DZ2B), (Megane-III, DZ01), (Megane-III, DZ08), (Scenic-III, JZ11,JZ0Z,JZ1Z,JZD1), (Clio-IV, BHMH), (Scenic-III, JZ16,JZ0Y,JZ1Y,JZD6), (Megane-III, BZ16), (Megane-III, KZ16), (Megane-III, DZ16,DZ28), (Megane-III, EZ16), (Megane-III, BZ11), (Megane-III, BZ1T), (Megane-III, KZ1T), (Megane-III, DZ17), (Megane-III, DZ18), (Captur-I, J5M0), (Captur-I, J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Captur-I, BHM0), (Captur-I, KHM0), (Captur-I, 5R40), (Captur-I, 5RU0), (Scenic-III, JZ09,JZ11,JZ0Z,JZ1Z,JZD1), (Megane-III, BZ23), (Megane-III, DZ21), (Megane-III, DZ23), (Clio-IV, KHM0), (Kangoo-II, KW02), (Kangoo-II, FW02,KW02), (Captur-I, J5MA,J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Captur-I, J5MH,J5AL,5R5A,5R7A,5RAA,5RKA,5RLA,5RMA,5RXA), (Twingo-III, BCM1), (Kangoo-II, KW02,FW02), (Kadjar, HLMR), (Kangoo-II, FW52,FW54,), (Kangoo-II, KW*4), (Scenic-III, JZ0Y,JZ16,JZ1Y,JZD6,JZ0Z,JZ11,JZ1Z,JZ1D), (Twingo-III, BCM8), (Captur-I, 2R5A,2RDA,2REA,2RFA,2RGA,2RHA), (Megane-III, DZ16), (Twingo-III, BCMD), (Clio-V, B7MT), (Captur-II, RJB), (Twingo-III, BCME), (Twingo-III, BCM4), (Twingo-III, BCMJ),



Diagnostic devices

(Megane-III, DZ0Z), (Megane-III,), (Megane-III, RFB), (Scenic-IV, J9A9,J9N9), (Clio-IV, R), (Clio-IV, BHM0), (Clio-V, RJA), (Megane-IV, B9NC), (Arkana, RJL), (Kadjar, HAxx, HLxx), (Talisman, RFD)

Calibrating the camera ECU ((Scenic-II, JM16), (Zoe, FFMF), (Zoe, BFMC,BFMD), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL))

Initializing the EGR valve ((Talisman, L2M), (Talisman, KP_))

Bleeding the ABS hydraulic unit ((Fluence, L30Z,LZBZ,LZL6), (Zoe, BFMA), (Kadjar, HLA4), (Kadjar, HLMR), (Kadjar, HLA3), (Espace-V, JRM1), (Koleos-II, HCAK), (Koleos-II, HCA4), (Kadjar, HLMH), (Espace-V, JRAL), (Espace-V, JRAM), (Kadjar, HLNB), (Kadjar, HLNC), (Kadjar, HLA6), (Zoe, BFMF), (Kadjar, HLA7), (Zoe, FFMA), (Zoe, FFMB), (Zoe, FFFM), (Zoe, BFMC,BFMD), (Koleos-II, HCA7), (Koleos-II, HCAN), (Koleos-II, None), (Talisman, KPAM), (Talisman, LPAM), (Koleos-II, HCA), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL), (Kadjar, HAxx, HLxx))

Resetting starter learning values ((Espace-V, JRAL), (Espace-V, JRAM), (Talisman, LPA7), (Talisman, LPA8), (Talisman, KPA7), (Talisman, LPAL), (Talisman, LPAM), (Talisman, KPAM), (Talisman, KPAL), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC))

Learning the steering-angle sensor ((Modus, JP04))

Initializing the swirl flap ((Talisman, L2M), (Talisman, KP_))

Calibrating the camera and radar system ((Scenic-IV, J9A9,J9N9))

Reset low-pressure EGR learned values ((Scenic-III, JZ14), (Scenic-III, JZ00,JZ12), (Megane-III, BZ00), (Megane-III, BZ12), (Megane-III, KZ00), (Megane-III, KZ12), (Megane-III, DZ00), (Megane-III, DZ02), (Clio-IV, BHM4), (Clio-IV, KHM4), (Clio-IV, BHAL), (Clio-IV, KHAL), (Megane-III, EZ00), (Megane-III, DZ12), (Fluence, LZ00), (Megane-III, EZ12), (Captur-I, J5AL), (Scenic-III, JZ00,JZ02,JZ12,JZ13,JZD2,JZH0,JZNA,JZPA,JZV0,JZYA), (Scenic-III, JZ00), (Scenic-III, JZ12,JZ00), (Kangoo-II, KW05), (Kangoo-II, KW08), (Kangoo-II, KW25), (Kangoo-II, KW28), (Kangoo-II, KW55), (Kangoo-II, KW58), (Kangoo-II, KW45), (Kangoo-II, KW48), (Kangoo-II, KW25,FW15,FW18,FW55,FW58,), (Kangoo-II, KW28,FW15,FW18,FW55,FW58,), (Kangoo-II, KW65,FW15,FW18,FW55,FW58,), (Kangoo-II, KW95,FW15,FW18,FW55,FW58,), (Kangoo-II, KW68,FW15,FW18,FW55,FW58,), (Kangoo-II, KW98,FW15,FW18,FW55,FW58,), (Megane-III, BZ14), (Kangoo-II, FW06,KW06), (Kangoo-II, FW06,KW06,FW16,FW56,KW16,KW56,KW66,KW96), (Kangoo-II, FW15,FW18,FW55,FW58,FWG5,FWG8,FWK5,FWK8,KW25,KW28,KW68,KW95,KW98), (Captur-I, 2RAL,2RBL,2REL,2RFL), (Clio-IV, 5RBF,5RDF,5REF), (Clio-IV, 6RBF,6RDF), (Clio-IV, 7RBF,7RDF,7REF), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman,), (Espace-V, JRFC))

Initializing the brake-pressure sensor ((Espace-IV, JK04,JK1F,JKFJ,JK01,JK1J))

Codings

Coding the trailer hitch ((Scenic-IV, J9A9,J9N9))

Coding the language version ((Zoe, FFMF), (Zoe, BFMC,BFMD), (Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL), (Kadjar, HAxx, HLxx))

Coding instrument cluster units ((Zoe, FFMF), (Zoe, BFMC,BFMD), (Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL), (Kadjar, HAxx, HLxx))

Coding the tire size ((Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL))

Switching on/off the automatic parking brake application ((Zoe, FFMF), (Zoe, BFMC,BFMD), (Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))



Diagnostic devices

Airbag ECU locking/unlocking ((Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL), (Kadjar, HAxx,HLxx))

Coding the wheel sets (summer/winter) ((Kadjar, HAxx,HLxx))

Adapting the trailer hitch to advanced driver assistance systems ((Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD), (Arkana, RJL))

Coding injectors ((Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC))

Coding the country version ((Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))

De/activating the trailer hitch ((Talisman, KPAM), (Talisman, LPAM), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))

Code trailer stability program ((Talisman, KPAM), (Talisman, LPAM), (Scenic-IV, J9A9,J9N9), (Espace-V, JRAM), (Talisman, L2M), (Talisman, KP_), (Talisman,), (Espace-V, JRFC), (Talisman, RFD))

Service resets

(Espace-V, JRAM), (Kadjar, HAxx,HLxx), (Scenic-IV, J9A9,J9N9), (Talisman, KPAM)

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

(Espace-V, JRM1), (Espace-V, JRAL), (Espace-V, JRAM), (Megane-IV, B9N8), (Megane-IV, B9N9), (Megane-IV, B9NB), (Megane-IV, K9N8), (Megane-IV, K9N9), (Megane-IV, K9NC), (Megane-IV, K9NB), (Megane-IV, K9A2), (Megane-IV, K9A6), (Megane-IV, B9NC), (Megane-IV, B9A2), (Megane-IV, B9A6), (Twingo-III, BCM), (Talisman, LPA7), (Talisman, LPA8), (Talisman, LPM1), (Talisman, KPA7), (Talisman, KPM1), (Megane-IV, B9), (Talisman, LPAL), (Talisman, LPAM), (Talisman, LPNC), (Clio-V, B7MT), (Clio-V, B7MF), (Clio-V, B7AD), (Captur-II, RJB), (Talisman, KPAM), (Talisman, KPAL), (Megane-IV, B9M8), (Megane-IV, B9A7), (Zoe, FFFM), (Twingo-III, BCME), (Twingo-III, BCM4), (Twingo-III, BCMJ), (Zoe, BFMC, BFMD), (Clio-V, RJA), (Megane-IV, K9A7), (Megane-IV,), (Twingo-III, BCA1), (Arkana,), (Arkana, RJL), (Express, F6AA), (Express, F6AB), (Megane-IV, RFB), (Talisman,), (Espace-V, JRFC), (Talisman, RFD)

Saab

Trouble codes

Parameters

Actuators

Basic settings

Learning the steering-angle sensor ((9-3, YS3F))

Codings

Service resets



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

Seat

Trouble codes

Parameters

Actuators

Basic settings

Learning the steering-angle sensor ((Ibiza, 6J), (Ibiza, 6P))

Unlocking aux. heater/independent car heater ((Ateca, KH), (Leon, 5F), (Tarraco, KN), (Leon, KL))

Regenerating the soot particulate filter ((Inca, 6K), (Arosa, 6H), (Toledo, 1M), (Leon, 1M), (Ibiza, 6L), (Cordoba, 6L), (Cordoba, 6K), (Altea, 5P), (Toledo, 5P), (Leon, 1P), (Alhambra, 7V), (Ibiza, 6J), (Leon, 5F), (Ibiza, 6L1), (Ibiza, 6P), (Toledo, KG), (Alhambra, 71), (Ateca, KH), (Ibiza, KJ), (Arona, KJ), (Tarraco, KN), (Leon, KL))

Initializing the A/C flap actuators ((Arosa, 6H), (Toledo, 1M), (Leon, 1M), (Alhambra, 7V), (Toledo, 1L), (Inca, 6K), (Exeo, 3R), (Leon, 1P))

Codings

Service resets

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM) (Leon, KL), (Ateca, KH)

Capable for diagnostics
only with Cyber Security
Management

Skoda

Trouble codes

Parameters



Diagnostic devices

Actuators

Basic settings

Learning the steering-angle sensor ((Yeti, 5L), (Octavia, 1U), (Fabia, 6Y), (Octavia, 1Z), (Fabia, 54), (Roomster, 5J), (Superb, 3T), (Fabia, NJ))
Initializing the brake-pedal travel sensor ((Enyaq, 5A))
Learning the turbocharger ((Superb, 3T), (Roomster, 5J))
Adapting the soot particulate filter ((Superb, 3U), (Fabia, 6Y), (Fabia, 54), (Roomster, 5J), (Superb, 3T))
Adjusting the headlights ((Enyaq, 5A))
Initializing the ESC sensors ((Enyaq, 5A))
Air conditioning ((Enyaq, 5A))
Calibrating the camera ECU ((Enyaq, 5A))
Regenerating the soot particulate filter ((Superb, 3U), (Fabia, 6Y), (Octavia, 1Z), (Fabia, 54), (Roomster, 5J), (Superb, 3T), (Octavia, 5E), (Fabia, NJ), (Superb, 3V), (Rapid, NH), (Yeti, 5L), (Kodiaq, NS), (Karoq, NU), (Scala, NW), (Kamiq, NW))
Resetting the brake pad wear indicator ((Enyaq, 5A))
Initializing the brake-pressure sensor ((Enyaq, 5A))
Performing basic settings of emergency call system/telematics system ((Enyaq, 5A))
Initializing the A/C flap actuators ((Fabia, 6Y), (Fabia, 54))

Codings

Deactivating/activating the transport mode ((Enyaq, 5A))

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM) (Enyaq, 5A)

Capable for diagnostics only with Cyber Security Management

Smart/MCC

Trouble codes

Parameters

Actuators



Diagnostic devices

Basic settings

Performing the special bleeding without ESC ((Smart, 450341,450342,450343,450346), (Smart, 450331,450336), (Smart, 450441,450442,450443,450446), (Smart, 450300,450301,450302,450303,450306), (Smart, 450401,450402,450403,450406), (Smart, 450333,450335), (Smart, 450452,450453), (Smart, 450418), (Smart, 450414), (Smart, 450330,450332), (Smart, 450336), (Smart, 450400))

Learning the clutch position ((Smart Fortwo, 450314), (Smart Fortwo, 450414), (Smart Fortwo, 450336), (Smart Fortwo, 450.341), (Smart Fortwo, 450.342), (Smart Fortwo, 450.343))

Learning the steering-angle sensor ((Smart Forfour, 454032), (Smart Fortwo, 450300,450301,450302,450303,450306), (Smart Fortwo, 450400), (Smart Fortwo, 450330), (Smart Fortwo, 450432), (Smart Fortwo, 450332,450336,450352,450353), (Smart Roadster/Coupe, 452334), (Smart Roadster/Coupe, 452434), (Smart Roadster/Coupe, 452432), (Smart Fortwo, 450333,450335), (Smart Fortwo, 450433,450435), (Smart Forfour, 454000), (Smart Forfour, 454030), (Smart Forfour, 454001), (Smart Forfour, 454031), (Smart Roadster/Coupe, 452333), (Smart Roadster/Coupe, 452433), (Smart Roadster/Coupe, 452332), (Smart Forfour, 454033), (Smart Forfour, 454034), (Smart, 450331,450335,450336,450341,450342,450343,450344), (Smart, 450314), (Smart, 450432), (Smart, 450433,450435), (Smart Fortwo, 451400), (Smart Fortwo, 451330), (Smart Fortwo, 451330,451334), (Smart Fortwo, 451331,451380), (Smart Fortwo, 451431,451480), (Smart Fortwo, 451332), (Smart Fortwo, 451432), (Smart Fortwo, 451433), (Smart Fortwo, 451333), (Smart Fortwo, 451300), (Smart Fortwo, 451391), (Smart Fortwo, 451491), (Smart Fortwo, 451490), (Smart Fortwo, 451390), (Smart Fortwo, 451392), (Smart Fortwo, 451492), (Smart Fortwo, 450332), (Smart Fortwo, 450347), (Smart Fortwo, 450441,450442,450443,450452), (Smart Fortwo, 451401,451403), (Smart Fortwo, 451301,451303), (Smart Fortwo, 450335), (Smart Fortwo, 450314), (Smart Fortwo, 450414), (Smart Fortwo, 451380), (Smart Fortwo, 450336), (Smart Fortwo, 450.341), (Smart Fortwo, 450.342), (Smart Fortwo, 450.343), (Smart Fortwo,))

Activating the roller test stand mode ((Smart Fortwo, 450300,450301,450302,450303,450306), (Smart Fortwo, 450400), (Smart Fortwo, 450330), (Smart Fortwo, 450432), (Smart Fortwo, 450332,450336,450352,450353), (Smart Fortwo, 450333,450335), (Smart Fortwo, 450433,450435), (Smart Fortwo, 450332), (Smart Fortwo, 450347), (Smart Fortwo, 450441,450442,450443,450452), (Smart Fortwo, 450335), (Smart Fortwo, 450314), (Smart Fortwo, 450414), (Smart Fortwo, 450336), (Smart Fortwo, 450.341), (Smart Fortwo, 450.342), (Smart Fortwo, 450.343))

Performing the special bleeding with ESC ((Smart, 450341,450342,450343,450346), (Smart, 450331,450336), (Smart, 450441,450442,450443,450446), (Smart, 450300,450301,450302,450303,450306), (Smart, 450401,450402,450403,450406), (Smart, 450333,450335), (Smart, 450452,450453), (Smart, 450418), (Smart, 450414), (Smart, 450330,450332), (Smart, 450336), (Smart, 450400), (Smart, 450331), (Smart, 450335,450336,450341,450342,450343,450344), (Smart, 450314), (Smart, 450432), (Smart, 450433,450435))

Bleeding the ABS hydraulic unit ((Smart Roadster/Coupe, 452334), (Smart Roadster/Coupe, 452434), (Smart Roadster/Coupe, 452432), (Smart Roadster/Coupe, 452333), (Smart Roadster/Coupe, 452433), (Smart Roadster/Coupe, 452332), (Smart Fortwo, 451400), (Smart Fortwo, 451330), (Smart Fortwo, 451330,451334), (Smart Fortwo, 451331,451380), (Smart Fortwo, 451431,451480), (Smart Fortwo, 451332), (Smart Fortwo, 451432), (Smart Fortwo, 451433), (Smart Fortwo, 451333), (Smart Fortwo, 451300), (Smart Fortwo, 451391), (Smart Fortwo, 451491), (Smart Fortwo, 451490), (Smart Fortwo, 451390), (Smart Fortwo, 451392), (Smart Fortwo, 451492), (Smart Fortwo, 451401,451403), (Smart Fortwo, 451301,451303), (Smart Fortwo, 451380), (Smart Fortwo,))

Codings

Service resets



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

Subaru

Trouble codes

Parameters

Actuators

Basic settings

Initializing the rain/light sensor ((Impreza, G4), (Impreza, G3), (XV, G4), (Forester, SJ),
(Legacy/Outback, BS), (WRX, V1), (Levorg, VM), (Forester, SHS), (Impreza, G5), (Levorg, V1))
Calibrating the camera ECU ((Impreza, G5))
De/activating the parking brake service mode ((XV, G5), (Impreza, G5), (Impreza, GK),
(Legacy/Outback, BS))

Codings

Service resets

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

Suzuki

Trouble codes

Parameters

Actuators

Basic settings

Initializing the ride height sensor ((Swift, AZ), (Vitara, LY), (SX4, JY))



Diagnostic devices

Resetting the start counter ((Swift, NZ))

Learning the throttle valve ((Kizashi, FR), (Grand Vitara, JT), (Swift, EZ), (SX4, EY), (Swift, MZ), (SX4, GY), (Splash, EX), (Jimny, FJ))

Calibrating the radar sensor ((SX4, JY))

Initializing the electronic stability control sensors ((Celerio,), (SX4, JY), (Jimny, FJ), (Vitara, LY), (Swift, AZ), (Ignis, MF), (Jimny, GJ))

Resetting gearbox learning values ((Jimny, FJ))

Initializing the neutral position sensor ((Swift, AZ), (Vitara, LY), (SX4, JY))

Codings

Service resets

DolP/CAN

Capable for diagnostics only with mega macs X

Cyber Security Management (CSM)

Capable for diagnostics only with Cyber Security Management

Toyota

Trouble codes

Parameters

Actuators

Basic settings

Learning the steering-angle sensor ((Proace, MDZ), (Proace, MPY), (Proace, BKY), (Proace, BPZ), (Proace, E))

Resetting mass airflow sensor adaptation values ((RAV 4, ALA30), (Corolla, AUR10), (Avensis, ADT271), (Avensis, ADT251), (Avensis, ADT250), (Auris, ADE150), (Auris, ADE157), (Verso, AUR20), (Verso, AUR21), (RAV 4, ALA35))

Configuring the lane change assist ((Yaris, MXPH10,MXPH11), (Yaris, MXPA11), (RAV 4, AXAP54), (Yaris, GXPA16), (Yaris, MXPB10), (Yaris, MXPJ10), (Yaris, MXPJ15))

Replace brake parts ((Proace, MDZ), (Proace, MPY), (Proace, BKY), (Proace, BPZ))

Service mode (engine immobilizer can be deactivated > gasoline engine runs) ((Prius, ZVW50), (Prius, ZVW52))

Adapting the brake system ((Camry, GSV70), (C-HR, MAXH10))

Codings

Service resets



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM)

Capable for diagnostics
only with Cyber Security
Management

Volkswagen

Trouble codes (Crafter, 2E), (Crafter, 2F), (ID.4, E2)

Parameters (Crafter, 2E), (Crafter, 2F), (ID.4, E2)

Actuators (Crafter, 2E), (Crafter, 2F), (ID.4, E2)

Basic settings Initializing electric seats ((ID.4, E2))

Learning the steering-angle sensor ((Caddy, 2C), (Golf6, AJ), (Passat, 36), (Transporter, 70), (Tiguan, 5N), (Jetta, 16), (Golf6, 51), (Touran, 1T), (CC, 35), (Golf6, 5K), (Bora, 1J), (Caddy, SA), (Sharan, 7M), (Passat, 3B), (Passat, 35/3A), (Transporter, 7D), (Golf3, 1H), (Golf4, 1J), (New Beetle, 1C/9C), (Passat, 3A), (Polo, 6R), (Phaeton, 3D), (Polo, 6K/6V), (Polo, 9N), (New Beetle, 1Y), (Touareg, 7L), (Caddy, 2K), (Transporter, 7H), (Golf5, 1K), (Polo, 6C), (Transporter, 7J), (Jetta, 1K), (Golf5, 5M), (Fox, 5Z), (Passat, 3C), (Transporter, 7E), (Eos, 1F), (Jetta, 1H), (Jetta, 9M), (CC, 35), (Scirocco, 13), (Golf6, 52), (New Beetle, 5C), (New Beetle, 9C), (New Beetle, 1C), (Lupo, 6X), (CC, 3C), (Bora,), (Caddy,))

Initializing the adaptive cruise control ((Touran, 5T), (Golf6, 5K), (ID.4, E2))

Filling fuel lines of parking heater/auxiliary heater ((Crafter, SY))

Learning the steering-angle sensor ((ID.4, E2))

Adjusting the headlights ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Initializing the ESC sensors ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Air conditioning ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Adapting the electronic damper control ((ID.4, E2))

Performing maintenance work on the refrigerant circuit ((Golf7, BE), (Crafter, SX))

Performing transmission adaptations ((Touareg, CR))

Adapting the longitudinal acceleration sensor ((Passat, 3C), (CC, 3C))

Bringing gear actuator of direct shift transmission in neutral position ((New Beetle, 5C))

Standardizing the liftgate ((ID.4, E2))

Learning the turbocharger ((Caddy, 2C), (Passat, 36), (Sharan, 7N), (Golf6, 51), (CC, 35), (Caddy, SA), (Golf6, AJ), (Golf6, 5K), (Golf6, 52), (Transporter, 7F), (Transporter, 7E), (CC, 35), (Tiguan, 5N), (Polo, 6R), (Touran, 1T), (Eos, 1F), (Scirocco, 13), (Jetta, 16), (New Beetle, 5C), (Jetta, 1K), (Transporter, SG), (Transporter, SF), (Passat, 3C), (Caddy,))

Resetting the start inhibitor of DEF injection system ((Crafter, SY))



Diagnostic devices

Performing engine adaptations ((Crafter, SY))

Regenerating the soot particulate filter ((Caddy, 2C), (Golf6, AJ), (Passat, 36), (Caddy, 2K), (Touareg, 7P), (Sharan, 7N), (Golf6, 51), (Touran, 1T), (Golf7, 5G), (CC, 35), (Golf7, BA), (Golf7, AM), (Jetta, 16), (Touran, 5T), (Tiguan, AD), (Amarok, S6/S7), (Crafter, SY), (Crafter, SZ), (Golf7, AN), (New Beetle, 1C/9C), (Lupo, 6X), (Passat, 3B), (Caddy, SA), (Polo, 9N), (Polo, 6R), (Lupo, 6E), (Transporter, 7H), (Caddy, 9K), (Caddy, 9U), (New Beetle, 1Y), (Golf5, 1K), (Polo, 6C), (Transporter, 7J), (Jetta, 1K), (Golf5, 5M), (Fox, 5Z), (Sharan, 7M), (Passat, 3C), (Jetta, 9M), (Eos, 1F), (Touareg, 7L), (Golf6, 52), (Golf6, 5K), (CC, 35), (Tiguan, 5N), (Scirocco, 13), (New Beetle, 5C), (New Beetle, 1C), (Passat, 3G), (Transporter, SG), (Transporter, SF), (Golf7, BQ), (Golf7, BV), (Arteon, 3H), (Tiguan, BW), (Polo, AW), (T-Roc, A1), (T-Cross, C1), (Passat, CB), (Transporter, SH), (Transporter, SJ), (Crafter, SC), (Caddy,))

Resetting the brake pad wear indicator ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Resetting gearbox learning values ((Touareg, 7P))

Initializing the brake-pressure sensor ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Performing basic settings of emergency call system/telematics system ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Initializing the brake-pedal travel sensor ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Retracting parking brake ((ID.4, E2))

Initializing the adaptive cruise control ((Sharan, 7N), (Transporter, ST))

Initializing the alternator ((Crafter, SY))

Adapting the radiator shutter ((ID.4, E2))

Initializing the oxidation catalyst ((Crafter, SY))

Adapting the electronic climate control ((Tiguan, 5N), (Jetta, 16), (CC, 35), (Polo, 6R), (Passat, 3C), (Eos, 1F), (Golf5, 1K), (CC, 35), (Scirocco, 13), (Golf6, 52), (Jetta, 1K), (Golf6, 5K), (Golf6, AJ), (New Beetle, 5C), (Passat, 36), (CC, 3C))

Resetting the diesel exhaust fluid level ((Crafter, SY))

Initializing the EGR valve ((Golf5, 5M))

Bleeding the cooling system ((Crafter, SY), (ID.4, E2))

Calibrating the camera ECU ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Extending parking brake ((ID.4, E2))

Calibrating the tire pressure monitoring system ((Golf6, 51), (Touran, 1T), (Tiguan, 5N), (Polo, 6R), (Passat, 3C), (Golf5, 5M), (Golf5, 1K), (CC, 35), (CC, 3C), (Golf6, 52), (Golf6, AJ))

Initializing the transmission ECU ((New Beetle, 5C))

Codings

Adjust parking assistance volume ((ID.4, E2))

Coding the trailer detection ((ID.4, E2))

Coding the rain/light sensor ((ID.4, E2))

Deactivating/activating the transport mode ((ID.3, E1), (ID.4, E2), (ID.5, E3))

Service resets

(ID.4, E2)



Diagnostic devices

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security Management (CSM) (ID.3, E1), (ID.4, E2), (Transporter, ST), (ID.5, E3)

Capable for diagnostics
only with Cyber Security Management

Volvo

Trouble codes

Parameters

Actuators

Basic settings

Adapting the longitudinal acceleration sensor ((XC60-I, DZ), (S80-II, AR, AS))

Resetting learned values of side obstacle detection ((XC40, XZ))

Initializing the air distribution flaps ((V60-I, FW), (S60-II, FS), (V60-I, GWAA), (V60-I, GW), (V60-I, FZ), (XC60-I, DZ), (V40-II, MV), (V40-II, MZ), (V70-II, BZ), (V60-I, F), (S60-III, ZS))

Adapting the installation position of side obstacle detection ECU ((XC40, XZ), (V40-II, MV), (V60-II, ZW), (V40-II, MZ), (V90-II, PW), (S60-III, Z))

Resetting the air-fuel ratio adaptation values ((XC40, XZ), (V40-II, MV), (V60-II, ZW), (S60-III, Z))

De/activating the parking brake service mode ((V90-II, ZW))

Resetting learned values of throttle valve actuator ((V60-I, FW), (V60-I, GWAA), (V60-I, GW), (V60-I, FZ), (S60-II, FS), (XC60-I, DZ), (V60-I, F))

Learning the lambda sensor ((V60-I, FW), (V60-I, GWAA), (V60-I, GW), (V60-I, FZ), (S60-II, FS), (V60-I, F))

Resetting the air flow sensor adaptation values ((V60-I, FW), (V60-I, GWAA), (V60-I, GW), (V60-I, FZ), (S60-II, FS), (XC60-I, DZ), (V60-I, F))

Resetting differential pressure sensor learning values ((V60-I, FW), (V60-I, GWAA), (V60-I, GW), (V60-I, FZ), (S60-II, FS), (XC60-I, DZ), (V60-I, F))

Resetting the impact mode ((XC60-I, DZ), (S80-II, AR, AS))

Resetting gearbox learning values ((V60-I, FW), (V60-I, GWAA), (V60-I, GW), (V60-I, FZ), (S60-II, FS), (V90-II, PZ), (V90-II, PW), (XC60-II, UZ), (XC60-I, DZ), (S80-II, AR, AS), (V60-I, F), (S60-III, ZS), (V60-II, ZW), (V60-II, ZZ), (V90-II, ZW), (V60-II, Z), (XC90-II, LC, LF))

Resetting EGR valve learning values ((V60-I, FW), (V60-I, FZ), (S60-II, FS))

Initializing the A/C flap actuators ((XC40, XZ), (V40-II, MV), (V60-II, ZW), (V40-II, MZ), (V90-II, PW), (S60-III, Z))

Resetting the soot particulate filter ((C30, MK), (S40-II, MS), (V50, MVV))

Initialising the boost pressure regulator ((C30, MK), (C30, M1), (V50, MVV), (S40-II, MS), (C70-II, MC))



Diagnostic devices

Codings

Service resets

DolP/CAN

Capable for diagnostics
only with mega macs X

Cyber Security
Management (CSM)

Capable for diagnostics
only with Cyber Security
Management